

αSTEP

AR Series/

Motorized actuator equipped with AR Series

AC power input/DC power input FLEX

Built-in controller type

USER MANUAL

Introduction

AC power input type

DC power input type

AC power input type/
DC power input type
Common

Operation type and
setting

Method of control via
Modbus RTU (RS-485
communication)

Method of control via
industrial network

Appendix

Thank you for purchasing an Oriental Motor product.
This Manual describes product handling procedures and safety precautions.

- Please read it thoroughly to ensure safe operation.
- Always keep the manual where it is readily available.

1 Introduction

1	Before use	8
2	Overview of the product.....	9
3	Safety precautions	11
3-1	Safety precautions.....	11
3-2	Graphical symbols on the driver's front panel	13
3-3	Warning sign (AC input driver).....	13
4	Precautions for use	14

2 AC power input type

1	System configuration	18
2	Preparation.....	19
2-1	Checking the product	19
2-2	How to identify the product model	20
2-3	Information about nameplate	22
2-4	Combinations of motors and drivers.....	22
2-5	Input/output power ratings.....	23
2-6	Names and functions of parts	24
3	Installation.....	27
3-1	Location for installation.....	27
3-2	Installing the motor	27
3-3	Installing a load	28
3-4	Permissible radial load and permissible axial load	29
3-5	Installing the driver	32
3-6	Installing the regeneration resistor.....	33
4	Connection	34
4-1	Connection example	34
4-2	Grounding the motor and driver	35
4-3	Connecting the main power supply	36
4-4	Connecting the 24 VDC power supply, regeneration resistor and electromagnetic brake	37
4-5	Connecting the I/O signals.....	39
4-6	Connecting the data setter	42
4-7	Connecting the RS-485 cable	42
4-8	Noise elimination measures.....	43
4-9	Conformity to the EMC Directive	44
5	Cables	46
5-1	Connection cable set.....	46
5-2	Extension cable set.....	47
5-3	Communication cable for the support software.....	48
5-4	RS-485 cable	48
5-5	I/O signal cable	48
6	Accessories	49
6-1	Setting tools.....	49
6-2	Wiring support tools.....	49

3 DC power input type

1	System configuration	52
2	Preparation.....	53
2-1	Checking the product.....	53
2-2	How to identify the product model.....	54
2-3	Information about nameplate	55
2-4	Combinations of motors and drivers.....	56
2-5	Input/output power ratings.....	57
2-6	Names and functions of parts	57
3	Installation.....	60
3-1	Location for installation.....	60
3-2	Installing the motor	60
3-3	Installing a load	61
3-4	Permissible radial load and permissible axial load.....	62
3-5	Installing the driver	65
4	Connection	67
4-1	Connection example	67
4-2	Grounding the motor and the driver.....	68
4-3	Connecting the power supply and electromagnetic brake	68
4-4	Connecting the I/O signals.....	69
4-5	Connecting the data setter	73
4-6	Connecting the RS-485 cable	73
4-7	Noise elimination measures.....	74
4-8	Conformity to the EMC Directive	75
5	Cables	77
5-1	Connection cable set.....	77
5-2	Extension cable set.....	78
5-3	Communication cable for the support software.....	79
5-4	RS-485 cable	79
5-5	I/O signal cable	80
6	Accessories	81
6-1	Setting tools.....	81
6-2	Wiring support tools.....	81

4 AC power input type/DC power input type Common

1	Explanation of I/O signals.....	84
1-1	Assignment of direct I/O	84
1-2	Assignment of remote I/O	88
1-3	Input signals	92
1-4	Output signals.....	98
1-5	Sensor inputs.....	103
1-6	General signals (R0 to R15).....	104
2	Method of control via I/O.....	105
2-1	Guidance.....	105
2-2	Operation data.....	109
2-3	Parameter	110
3	Operation using the OPX-2A	121
3-1	Overview of the OPX-2A	121
3-2	Names and functions of parts	122
3-3	How to read the display	122

3-4	OPX-2A error display	123
3-5	Screen transitions	124
3-6	Monitor mode	128
3-7	Data mode.....	129
3-8	Parameter mode.....	132
3-9	Test mode	139
3-10	Copy mode.....	141
4	Inspection and maintenance	142
4-1	Inspection.....	142
4-2	Warranty.....	142
4-3	Disposal	142
5	Alarms and warnings.....	143
5-1	Alarms	143
5-2	Warning	150
5-3	Communication errors.....	151
6	Troubleshooting and remedial actions.....	152

5 Operation type and setting

1	Guidance	154
2	Adjustment and setting	158
2-1	Resolution.....	158
2-2	Operating current	159
2-3	Standstill current.....	159
2-4	Acceleration/deceleration rate and acceleration/deceleration time	160
2-5	Smooth drive.....	160
2-6	Speed filter	161
2-7	Moving average filter	162
2-8	Speed error gain.....	162
2-9	Control mode	163
2-10	Position loop gain, speed loop gain, speed loop integral time constant.....	163
3	Operation type and function list.....	164
4	Positioning operation.....	165
4-1	Operation data.....	165
4-2	Starting method of positioning operation	167
4-3	Operation function.....	172
4-4	Push-motion operation	176
5	Return-to-home operation.....	179
5-1	Operation sequence	182
5-2	Position preset	187
6	Continuous operation	188
6-1	Starting method of continuous operation	189
6-2	Variable speed operation.....	191
7	Other operation.....	193
7-1	JOG operation	193
7-2	Test operation	194
7-3	Automatic return operation.....	195
7-4	Stop operation	196
8	Coordination management.....	198
8-1	Position coordinate management.....	198
8-2	Wrap function	198

6 Method of control via Modbus RTU (RS-485 communication)

1	Guidance	202
2	Communication specifications	208
3	Setting the switches	211
3-1	Setting the AC power input	211
3-2	Setting the DC power input	213
4	Setting of RS-485 communication	215
5	Communication mode and communication timing	216
5-1	Communication mode	216
5-2	Communication timing	216
6	Message	218
6-1	Query	218
6-2	Response	220
7	Function code	222
7-1	Reading from a holding register(s) (03h)	222
7-2	Writing to a holding register (06h)	223
7-3	Diagnosis (08h)	224
7-4	Writing to multiple holding registers (10h)	225
8	Register address list	227
8-1	Operation commands	227
8-2	Maintenance commands	229
8-3	Monitor commands	230
8-4	Parameter R/W commands	233
9	Group send	244
10	Setting example of the operation	246
10-1	Positioning operation	246
10-2	Continuous operation	249
10-3	Return-to-home operation	251
11	Detection of communication errors	253
11-1	Communication errors	253
11-2	Alarms and warnings	253
12	Timing charts	254

7 Method of control via industrial network

1	Setting the switches	258
1-1	Setting the AC power input	258
1-2	Setting the DC power input	260
2	Method of control via CC-Link communication	262
2-1	Guidance	262
2-2	Operation example of command selection method	267
2-3	Operation example of command fixation method	274
3	Method of control via EtherCAT communication	281
3-1	Guidance	281
3-2	Basic operating procedures	287

4	Method of control via MECHATROLINK communication	290
4-1	Guidance.....	290
4-2	Basic operation procedure	295
4-3	Field map of the NETC01-M2	298
4-4	Field map of the NETC01-M3	299
4-5	Communication formats	300
5	Details of remote I/O	302
5-1	Input signals to the driver.....	302
5-2	Output signals from the driver	303
6	Command code list	305
6-1	Group function	305
6-2	Maintenance command	306
6-3	Monitor command	307
6-4	Operation data.....	309
6-5	User parameters	310

8 Appendix

1	Timing charts	320
2	Specifications	331
3	General specifications	332
3-1	AC power input.....	332
3-2	DC power input	333
4	Regulations and standards.....	334
4-1	UL Standards, CSA Standards	334
4-2	CE Marking (AC power input type)	334
4-3	CE Marking (DC power input type)	335
4-4	Republic of Korea, Radio Waves Act.....	335

1 Introduction



This part explains the product overview and safety precautions in addition to the types and descriptions about operating manuals.

◆ Table of contents

1	Before use	8
2	Overview of the product.....	9
3	Safety precautions	11
	3-1 Safety precautions.....	11
	3-2 Graphical symbols on the driver's front panel.....	13
	3-3 Warning sign (AC input driver)	13
4	Precautions for use.....	14

1 Before use

Only qualified personnel of electrical and mechanical engineering should work with the product. Use the product correctly after thoroughly reading the section "3 Safety precautions" on p.11. In addition, be sure to observe the contents described in warning, caution, and note in this manual. The product described in this manual is designed and manufactured to be incorporated in general industrial equipment. Do not use for any other purpose. Oriental Motor Co., Ltd. is not responsible for any compensation for damage caused through failure to observe this warning.

■ Related operating manuals

For operating manuals, download from Oriental Motor Website Download Page or contact your nearest Oriental Motor sales office.

- **AR Series/Motorized Actuator equipped with AR Series USER MANUAL (this document)**

Read the following operating manuals for motorized actuators.

- OPERATING MANUAL Actuator Edition
- Motorized Actuator OPERATING MANUAL Function Setting Edition

■ About terms and units

Terms and units to be used vary depending on a motor or motorized actuator. This manual explains by using the terms of the motor.

When the motorized actuator is used, read this manual by replacing the terms.

	Motor	Motorized actuator
Term	Torque	Thrust
	Moment of inertia	Mass
	Rotation	Movement
	CW direction	FWD direction
	CCW direction	RVS direction
	Rotation speed	Speed
	Resolution	Minimum travel amount
Unit	N·m	N
	kHz/s	m/s ²

2 Overview of the product

The **AR** Series consists of a driver with built-in controller function and a motor with built-in rotor position detection sensor. This product can be controlled via I/O, Modbus (RTU), or industrial network communication using the network converter. Operation data and parameters can be set using any of our support software **MEXE02**, data setter **OPX-2A**, or RS-485 communication.

■ Main features

● Introducing closed loop control

The **AR** Series can continue its operation even upon encountering quick acceleration or an abrupt change in load. Monitoring the speed and amount of rotation while the motor is running, the **AR** Series performs the closed-loop control under overload and similar conditions to continue its operation at the maximum torque.

● Three operation types

Positioning operation, return-to-home operation, and continuous operation can be performed. Up to 64 operation data points can be set, and multi-point positioning is also possible.

● Compatible with Modbus RTU (RS-485 communication)

Operation data and parameters can be set from the host controller, and start and stop commands of operation can be executed as well.

Up to 31 drivers can be connected to one client.

● Energy-saving

Motor and driver losses have been substantially reduced to achieve low heat generation and save energy.

Since the motor and driver generate much less heat, they can now be operated for longer hours at high speed, which was not possible with conventional motors/drivers.

● Supporting sink output and source output

The driver supports both the current sink output circuit and the current source output circuit.

● Automatic control of the electromagnetic brake

The driver automatically controls the electromagnetic brake, so the control signal input or the troublesome ladder logic design can be saved.

● Alarm and warning functions

The driver provides alarms that are designed to protect the driver from overheating, poor connection, error in operation, etc. (protective functions), as well as warnings that are output before the corresponding alarms generate (warning functions).

■ Accessories

Operation data and parameters can be set using any of the support software **MEXE02**, data setter **OPX-2A**, or RS-485 communication. Provide the **MEXE02** or **OPX-2A** as necessary.

- **MEXE02**The **MEXE02** can be downloaded from Oriental Motor Website Download Page.
When the **MEXE02** is used, our communication cable for the support software **CC051F-USB** is needed to connect a PC and driver. Be sure to purchase it.
- **OPX-2A**.....This product can be purchased separately.

■ Related products

The **AR** Series FLEX built-in controller type can be used via various network when connecting to our network converter.

Network converter model	Supported network
NETC01-CC	CC-Link version 1.1
NETC02-CC	CC-Link version 2
NETC01-ECT	EtherCAT

Network converter model	Supported network
NETC01-M2	MECHATROLINK-II
NETC01-M3	MECHATROLINK-III

■ **Function list**

Main functions

Return-to-home operation [Setting by parameters]	<ul style="list-style-type: none"> ● 2-sensor mode ● 3-sensor mode 	<ul style="list-style-type: none"> ● Push-mode ● Data setting mode (Position preset)
--	--	--

Motor operation [Setting by operation data and parameters]	<ul style="list-style-type: none"> ● Positioning operation <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 10px; text-align: center; width: 200px;"> <p>Operation function</p> <p>Single-motion operation Linked-motion operation Linked-motion operation 2 Push-motion</p> </div> + <div style="border: 1px solid black; border-radius: 50%; padding: 10px; text-align: center; width: 200px;"> <p>Starting method</p> <p>Data number selecting operation Direct positioning operation Sequential positioning operation</p> </div> </div> <ul style="list-style-type: none"> ● Continuous operation 	
--	---	--

Other operations [Setting by parameters]	<ul style="list-style-type: none"> ● JOG operation ● Automatic return operation
--	---

Support functions

[Setting by parameters]	<ul style="list-style-type: none"> ● Protective function Alarm detection Warning detection ● I/O function Input function selection Output function selection Input logic level setting ● Coordination setting Resolution (Electronic gear) Wrap function Motor rotation direction 	<ul style="list-style-type: none"> ● Return-to-home function Home offset External sensor signal detection ● Stop operation STOP input action Hardware overtravel Software overtravel ● Motor function setting Operating current Standstill current Speed filter Moving average filter
-------------------------	---	--

External interface




Data setter	<ul style="list-style-type: none"> ● Monitor function ● Operation data setting ● Parameter setting 	<ul style="list-style-type: none"> ● Data storing ● Download/Upload ● Data initialization 	<ul style="list-style-type: none"> ● Test function Test operation Teaching I/O test
--------------------	---	--	--

RS-485 communication	<ul style="list-style-type: none"> ● Operation start ● Operation data setting ● Parameter setting 	<ul style="list-style-type: none"> ● Monitor function ● Maintenance function
-----------------------------	--	--

3 Safety precautions

3-1 Safety precautions

The precautions described below are intended to ensure the safe and correct use of the product, and to prevent the customer and others from exposure to the risk of injury. Use the product only after carefully reading and fully understanding these instructions.

 WARNING	Handling the product without observing the instructions that accompany a "WARNING" symbol may result in serious injury or death.
 CAUTION	Handling the product without observing the instructions that accompany a "CAUTION" symbol may result in injury or property damage.
 Note	The items under this heading contain important handling instructions that the user should observe to ensure the safe use of the product.

WARNING

■ AC power input/DC power input common

General

- Do not use the product in explosive or corrosive environments, in the presence of flammable gases, in places subjected to splashing water, or near combustibles. Doing so may result in fire, electric shock, or injury.
- Assign qualified personnel to the task of installing, wiring, operating/controlling, inspecting, and troubleshooting the product. Handling by unqualified personnel may result in fire, electric shock, injury, or damage to equipment.
- Do not transport, install, connect or inspect the product while the power is supplied. Always turn the power off before carrying out these operations. Failure to do so may result in electric shock.
- Take measures to keep the moving part in position if the product is used in vertical operations such as elevating equipment. The motor loses holding torque when the power is shut off, allowing the moving parts to fall and possibly cause injury or damage to equipment.
- The brake mechanism of an electromagnetic brake motor is used for the purpose to hold the moving part and motor in position. Do not use it as a braking/safety brake. Doing so may result in injury or damage to the equipment.
- When an alarm is generated in the driver (any of the driver's protective functions is triggered), the motor will stop and lose its holding torque. Accordingly, provide measures to hold the moving part in place in the event of an alarm. Failure to do so may result in injury or damage to equipment.
- When an alarm is generated in the driver (any of the driver's protective functions is triggered), remove the cause before clearing the alarm. Continuing the operation without removing the cause of the problem may cause malfunction of the motor and driver, leading to injury or damage to equipment.

Installation

- Install the motor and driver inside an enclosure. Failure to do so may result in electric shock or injury.

Connection

- Always keep the power supply voltage of the driver within the specified range. Failure to do so may result in fire or electric shock.
- Connect the cables securely according to the wiring diagram. Failure to do so may result in fire or electric shock.
- Do not forcibly bend, pull, or pinch the cable. Doing so may result in fire or electric shock.
- Turn off the power to both the PC and driver before connecting your PC to the driver. Failure to do so may result in electric shock.

Operation

- Turn off the driver power supply in the event of a power failure. Otherwise, the motor may suddenly start when the power is restored, causing injury or damage to equipment.
- Take safety measures in the event of a momentary voltage drop. This may cause the motor to stop or reduce the holding force or rotational torque, resulting in injury or damage to equipment.
- Do not remove the motor excitation during operation. Doing so may cause the motor to stop and lose the holding force, resulting in injury or damage to equipment.

Repair, disassembly, and modification

- Do not disassemble or modify the motor and driver. Doing so may result in electric shock or injury. Refer all such internal inspections and repairs to the Oriental Motor sales office from which you purchased the product.

■ AC power input

Installation

- Be sure to ground the motor and the driver as they are Class I equipment. Failure to do so may result in electric shock.

Connection

- Use a 24 VDC power supply that has been given reinforced insulation between the primary side and secondary side. Failure to do so may cause electric shock.

Maintenance and inspection

- Do not touch the connection terminal of the driver while the power is supplied or for at least 10 minutes after turning off the power. Turn off the power to check the CHARGE LED being turned off before starting connection or inspection. The residual voltage may cause electric shock.

■ DC power input

Connection

- For the driver power supply, use a DC power supply with reinforced insulation on its primary and secondary sides. Failure to do so may result in electric shock.



■ AC power input/DC power input common

General

- Do not use the motor and driver beyond its specifications. Doing so may result in electric shock, injury, or damage to equipment.
- Keep your fingers and objects out of the openings in the motor and driver. Failure to do so may result in fire, electric shock, or injury.
- Do not touch the motor and driver during operation or immediately after stopping. The surface is hot, and this may cause a skin burn(s).

Transportation

- Do not carry the motor by holding the output shaft or cable. Doing so may cause injury.

Installation

- Provide a cover over the rotating parts (output shaft) of the motor. Failure to do so may result in injury.
- Do not leave anything around the motor and driver that would obstruct ventilation. Doing so may result in damage to equipment.

Operation

- Use a motor and driver only in the specified combination. An incorrect combination may cause a fire.
- Provide an emergency-stop device or emergency-stop circuit external to the equipment so that the entire equipment will operate safely in the event of a system failure or malfunction. Failure to do so may result in injury.
- Before supplying power to the driver, turn all input signals to the driver to OFF. Otherwise, the motor may suddenly start when the power is turned on, leading to injury or damage to equipment.
- When moving the moving part manually, put the motor into a non-excitation state. Continuing the work while the motor is in an excitation state may result in injury.
- Do not touch the rotating part (output shaft) during operation. Doing so may cause injury.
- When an abnormal condition has occurred, immediately stop operation to turn off the main power supply and the control power supply. Failure to do so may result in fire, electric shock, or injury.
- The motor surface temperature may exceed 70 °C (158 °F) even under normal operating conditions. If the operator is allowed to approach the motor in operation, affix a warning label shown in the figure on a conspicuous position. Failure to do so may result in skin burn(s).
- Use only an insulated slotted screwdriver to adjust the driver's switches. Failure to do so may result in electric shock.



Warning label

Maintenance and inspection

- Do not touch the terminals while conducting the insulation resistance measurement or dielectric strength test. Doing so may cause electric shock.

■ AC power input**Connection**

- The data edit connector (CN4) and RS-485 connectors (CN6/CN7) are not insulated. When grounding the positive terminal of the power supply, do not connect any equipment (PC, etc.) whose negative terminal is grounded. Doing so may cause the driver and these equipment to short, damaging both.



■ DC power input**Connection**

- The power supply connector (CN1), data edit connector (CN3), and RS-485 connectors (CN6/CN7) are not insulated. When grounding the positive terminal of the power supply, do not connect any equipment (PC, etc.) whose negative terminal is grounded. Doing so may cause the driver and these equipment to short, damaging both.
- When connecting, check the silk screen of the driver and pay attention to the polarity of the power supply. Reverse-polarity connection may cause damage to the driver. The power-supply circuit and the RS-485 communication circuit are not insulated. Therefore, when controlling multiple drivers via RS-485 communication, the reverse polarity of the power supply will cause a short circuit and may result in damage to the drivers.

Operation

- For the power supply to the electromagnetic brake, use a DC power supply with reinforced insulation on its primary and secondary sides. Failure to do so may result in electric shock.

3-2 Graphical symbols on the driver's front panel

	⚠ WARNING This is the Protective Earth Terminal. Be sure to ground because improper grounding may result in electric shock.
	⚠ WARNING A high voltage is applied to the motor connector (CN2) and the main power supply input terminal (CN3). Do not touch these terminals while the power is on. Doing so may result in fire or electric shock. (AC power input)

3-3 Warning sign (AC input driver)

A warning about handling precautions is described on the driver. Be sure to observe the description contents when handling the product.

Electrical hazard warning label

⚠ WARNING – Risk of electric shock.	
	• Read manual before installing. (Multiple rated)
	• Do not touch the driver immediately after the power is cut off, or until the CHARGE LED (lit in red) turns off. Doing so may result in electric shock due to residual voltage.
⚠ AVERTISSEMENT – Risque de décharge électrique.	
	• Lire le manuel avant l'installation.
	• Ne pas toucher au variateur immédiatement après la mise hors tension ou avant que la LED "présence de la tension" (Rouge) ne soit éteinte. Le non respect de ces règles pourrait entraîner un choc électrique.
⚠ 警 告 – けが・感電のおそれがあります。	
	• 据え付け、運転の前には必ず取扱説明書をお読み下さい。
	• 電源を切った直後、CHARGE LED(赤色点灯)が消灯するまでドライバに触れないで下さい。残留電圧により感電の原因になります。

Material: PET

4 Precautions for use

This chapter covers restrictions and requirements the user should consider when using the product.

■ AC power input/DC power input common

● Be sure to use our cable to connect the motor and the driver.

Check the cable models on p.46 (AC power input), p.77 (DC power input).



Precautions for when the connection cable is used are described on p.16. Be sure to read before use.

● When conducting the insulation resistance measurement or the dielectric strength test, be sure to separate the connection between the motor and the driver.

Conducting the insulation resistance measurement or dielectric strength test with the motor and driver connected may result in damage to the product.

● Do not apply a radial load and axial load in excess of the specified permissible limit.

Operating the motor under an excessive radial load or axial load may damage the motor bearings (ball bearings). Be sure to operate the motor within the specified permissible limit of radial load and axial load. For details, refer to p.29 (AC power input) or p.62 (DC power input).

● Use the motor in conditions where the motor surface temperature does not exceed 100 °C (212 °F).

The driver has an overheat protection function, but the motor has no such feature. The motor surface temperature may exceed 100 °C (212 °F) under certain conditions (ambient temperature, operating speed, duty cycle, etc.). To prevent the motor bearings (ball bearings) from reaching its usable life quickly, use the motor in conditions where the surface temperature does not exceed 100 °C (212 °F).

Use the geared motor in a condition where the gear case temperature does not exceed 70 °C (158 °F), in order to prevent deterioration of grease and parts in the gear case.

If the motor is to be operated continuously, install the motor in a location where heat dissipation capacity equivalent to a level achieved with a heat sink [made of aluminum, 250×250×6 mm (9.84×9.84×0.24 in.)] is ensured.

● Holding torque at standstill

The motor holding torque is reduced by the current cutback function of the driver at motor standstill. When selecting a motor, check the holding torque at motor standstill in the specifications on the catalog.

● Do not use the electromagnetic brake for braking or as a safety brake.

Do not use the electromagnetic brake as a means to decelerate and stop the motor. The brake hub of the electromagnetic brake will wear significantly and the braking force will drop. Since the power off activated type electromagnetic brake is equipped, it helps maintain the position of the load when the power is cut off, but this brake cannot securely hold the load in place. Accordingly, do not use the electromagnetic brake as a safety brake. To use the electromagnetic brake to hold the load in place, do so after the motor has stopped.

● Double shaft type motor

Do not apply a load torque, radial load, or axial load to the rear shaft on the opposite side of the motor output shaft.

● Noise elimination measures

For measures with regard to noise, refer to p.43 (AC power input) or p.74 (DC power input).

● Storing data in non-volatile memory

Do not turn off the main power supply or DC power supply while writing the data to the non-volatile memory, and also do not turn off for 5 seconds after the completion of writing the data. Doing so may abort writing the data and cause an alarm of EEPROM error to generate. The non-volatile memory can be rewritten approximately 100,000 times.


● Motor excitation at power ON

The motor is excited when the DC power supply and main power supply are on. If the motor is required to be in a non-excitation state when turning on the power, assign the C-ON input to direct I/O or remote I/O.

● **Rotating direction of output shaft**


The motor output shaft rotates in the figure at the factory setting. The rotation direction can be changed by the parameter.

- When setting the position (travel amount) to a positive value



CW direction

- When setting the position (travel amount) to a negative value



CCW direction

The relationship between the rotating direction of the motor output shaft and that of the gear output shaft changes as follows, depending on the gear type and gear ratio. Check with the table.

Type of gear	Gear ratio	Rotating direction of the gear output shaft (relative to the motor output shaft)
TH geared Motor frame size: 28 mm (1.10 in.)	7.2, 10	Opposite direction
	20, 30	Same direction
TH geared Motor frame size: 42 mm (1.65 in.) 60 mm (2.36 in.) 90 mm (3.54 in.)	3.6, 7.2, 10	Same direction
	20, 30	Opposite direction
FC geared, PS geared, PN geared	All gear ratios	Same direction
Harmonic geared	All gear ratios	Opposite direction

● **Peak torque of geared motor**

Always operate the geared motor under a load not exceeding the peak torque. If the load exceeds the peak torque, the gear part will be damaged.

● **Do not perform push-motion operation with geared motors.**

Doing so may result in damage to the motor or gear part.

● **About grease of geared motor**

On rare occasions, a small amount of grease may ooze out from the geared motor. If there is concern over possible environmental damage resulting from the leakage of grease, check for grease stains during regular inspections. Alternatively, install an oil pan or other device to prevent leakage from causing further damage. Oil leakage may lead to problems in the customer's equipment or products.

■ **AC power input**

● **Preventing leakage current**

Stray capacitance exists between the driver's current-carrying line and other current-carrying lines, the earth and the motor, respectively. A high-frequency current may leak out through such capacitance, having a detrimental effect on the surrounding equipment. The actual leakage current depends on the driver's switching frequency, the length of wiring between the driver and motor, and so on. When providing a leakage current breaker, use the following products, for example, which have high-frequency signal protection:
Mitsubishi Electric Corporation: NV series

● **When an alarm of overvoltage protection is generated**

If vertical drive (gravitational operation) such as elevator applications is performed or if sudden start-stop operation of a large inertia load is repeated frequently, an alarm of overvoltage protection may be detected. If an alarm of overvoltage protection is detected, adjust the driving condition or use our regeneration resistor **RGB100**.

● **Note on connecting a power supply whose positive terminal is grounded**

The data edit connector (CN4) and RS-485 connectors (CN6/CN7) are not insulated. When grounding the positive terminal of the power supply, do not connect any equipment (PC, etc.) whose negative terminal is grounded. Doing so may cause the driver and these equipment to short, damaging both. Use the **OPX-2A** to set data, etc.

■ DC power input

● When an alarm of overvoltage protection is generated

If vertical drive (gravitational operation) such as elevator applications is performed or if sudden start-stop operation of a large inertia load is repeated frequently, an alarm of overvoltage protection may be detected. If the overvoltage protection alarm is detected, adjust the driving condition.

● Note on connecting a power supply whose positive terminal is grounded

The power supply connector (CN1), data edit connector (CN3), and RS-485 connectors (CN6/CN7) are not insulated. When grounding the positive terminal of the power supply, do not connect any equipment (PC, etc.) whose negative terminal is grounded. Doing so may cause the driver and these equipment to short, damaging both. Use the **OPX-2A** to set data, etc.

■ Notes when the connection cable is used

Note the following points when our cable is used.

● When inserting the connector


Hold the connector main body, and insert it in straight securely. Inserting the connector in an inclined state may result in damage to terminals or a connection failure.

● When pulling out the connector

Pull out the connector in straight while releasing the lock part of the connector. Pulling out the connector with holding the cable may result in damage to the connector.


● Bending radius of cable

Use the cable in a state where the bending radius of the cable is more than six times of the cable diameter. Do not bend the lead wires part or fix it with a clamp. Doing so may cause damage to the connector.



● How to fix the cable

Fix the cable near the connectors at two places as shown in the figure or fix it with a wide clamp to take measures to prevent stress from being applied to the connectors.



2 AC power input type


This part explains contents specific to the AR Series AC power input type.

◆Table of contents

1	System configuration.....	18	4	Connection	34
2	Preparation	19	4-1	Connection example	34
2-1	Checking the product	19	4-2	Grounding the motor and driver	35
2-2	How to identify the product model	20	4-3	Connecting the main power supply	36
2-3	Information about nameplate	22	4-4	Connecting the 24 VDC power supply, regeneration resistor and electromagnetic brake.....	37
2-4	Combinations of motors and drivers.....	22	4-5	Connecting the I/O signals.....	39
2-5	Input/output power ratings.....	23	4-6	Connecting the data setter	42
2-6	Names and functions of parts.....	24	4-7	Connecting the RS-485 cable	42
3	Installation	27	4-8	Noise elimination measures	43
3-1	Location for installation.....	27	4-9	Conformity to the EMC Directive	44
3-2	Installing the motor	27	5	Cables	46
3-3	Installing a load	28	5-1	Connection cable set.....	46
3-4	Permissible radial load and permissible axial load.....	29	5-2	Extension cable set	47
3-5	Installing the driver.....	32	5-3	Communication cable for the support software	48
3-6	Installing the regeneration resistor.....	33	5-4	RS-485 cable	48
			5-5	I/O signal cable	48
			6	Accessories.....	49
			6-1	Setting tools	49
			6-2	Wiring support tools.....	49

1 System configuration

2 AC power input type



*1 This cable is provided as our product. Purchase it separately.

*2 The PC must be supplied by the user. Use our communication cable for the support software **CC05IF-USB** when connecting the PC and driver.

*3 These products are provided as our accessories.

2 Preparation

This chapter explains the items you should check, as well as the name and function of each part.

2-1 Checking the product

Verify that the items listed below are included. Report any missing or damaged items to the Oriental Motor sales office from which you purchased the product.

● Motor

- Motor 1 unit
- Parallel key 1 pc. *1
- Instructions and Precautions for Safe Use 1 copy
- APPENDIX UL Standards for **AR** Series 1 copy *2

*1 Included with geared types; except for the **ARM46-T** and **ARM66-T**.

*2 Included with products conform to the UL Standards.

● Driver

- Driver 1 unit
- CN1 connector (6 pins) 1 pc.
- CN3 connector (5 pins) 1 pc.
- CN5 connector (5 pins) 1 pc.
- CN8 connector (9 pins) 1 pc.
- CN9 connector (7 pins) 1 pc.
- Connector wiring lever (for CN3) 1 pc.
- Instructions and Precautions for Safe Use 1 copy

Included connector model

Type	Model (Manufacturer)
CN1 connector	MC1,5/6-STF-3,5 (PHOENIX CONTACT GmbH & Co. KG)
CN3 connector	721-205 (WAGO Corporation)
CN5 connector	FK-MC0,5/5-ST-2,5 (PHOENIX CONTACT GmbH & Co. KG)
CN8 connector	FK-MC0,5/9-ST-2,5 (PHOENIX CONTACT GmbH & Co. KG)
CN9 connector	FK-MC0,5/7-ST-2,5 (PHOENIX CONTACT GmbH & Co. KG)

2-2 How to identify the product model

Check the model name of the motor and driver against the number shown on the nameplate. Refer to p.22 for how to identify the nameplate.

Motor

Standard type


ARM 6 6 A 0 C
 1 2 3 4 5 6

Geared type (except for FC geared type)

ARM 6 6 A C - T 7.2 U
 1 2 3 4 6 7 8 9

1	Series name	ARM: AR Series motor
2	Motor frame size	4: 42 mm (1.65 in.) 6: 60 mm (2.36 in.) 9: 85 mm (3.35 in.) [90 mm (3.54 in.) for geared type]
3	Motor length	
4	Motor type	A: Single shaft B: Double shaft M: With electromagnetic brake
5	Additional function	0: Round shaft without shaft flat Blank: Round shaft with shaft flat on one side
6	Motor power supply input	C: AC power input type
7	Type of gear	T: TH geared PS: PS geared N: PN geared H: Harmonic geared Blank: Standard
8	Gear ratio	Indicates a number representing the gear ratio. Refer to the following table for the gear type and gear ratio.
9	Cable outlet direction * (TH geared type only)	U: Upward direction L: Leftward direction R: Rightward direction Blank: Downward direction

* The cable outlet direction represents the one as viewed from the output shaft side in a state of placing it upward.



Type of gear ratio

Type of gear	Gear ratio
TH geared	3.6, 7.2, 10, 20, 30
PS geared	5, 7.2 (*), 10, 25, 36, 50
PN geared	ARM46: 5, 7.2, 10 ARM66, ARM98: 5, 7.2, 10, 25, 36, 50
Harmonic geared	50, 100

* The model name is "7" for the gear ratio 7.2 of the **PS** geared type.

● **FC geared type**



ARM 6 6 A C - FC 7.2 L A
 1 2 3 4 5 6 7 8 9

1	Series name	ARM: AR Series motor
2	Motor frame size	4: 42 mm (1.65 in.) 6: 60 mm (2.36 in.)
3	Motor length	
4	Motor type	A: Single shaft
5	Motor power supply input	C: AC power input type
6	Type of gear	FC: FC geared
7	Gear ratio	7.2, 10, 20, 30
8	Output shaft direction *	L: L shaft (Leftward direction) R: R shaft (Rightward direction)
9	Motor identification	A: Solid shaft

* The direction of the output shaft represents that as the view from the motor cable outlet side.

L: L shaft (Leftward direction)

R: R shaft (Rightward direction)




■ **Driver**

ARD - C D 2
 1 2 3 4

1	Series name	ARD: AR Series driver
2	Power supply input	A: Single-phase 100-120 V C: Single-phase 200-240 V
3	Type	D: Built-in controller type
4	Reference number	

2-3 Information about nameplate

The figure shows an example.



memo The position describing the information may vary depending on the product.

2-4 Combinations of motors and drivers

■ Standard type

Single shaft		Double shaft		With electromagnetic brake	
Motor model	Driver model	Motor model	Driver model	Motor model	Driver model
ARM46AC	ARD-AD2 ARD-CD2	ARM46BC	ARD-AD2 ARD-CD2	ARM46MC	ARD-AD2 ARD-CD2
ARM46A0C		ARM46B0C		ARM46M0C	
ARM66AC		ARM66BC		ARM66MC	
ARM66A0C		ARM66B0C		ARM66M0C	
ARM69AC		ARM69BC		ARM69MC	
ARM69A0C		ARM69B0C		ARM69M0C	
ARM98AC		ARM98BC		ARM98MC	
ARM98A0C		ARM98B0C		ARM98M0C	
ARM911AC		ARM911BC			
ARM911A0C		ARM911B0C			

■ Geared type

- The box (●) in the model name indicates a number representing the gear ratio.
- The box (◆) in the model name indicates **U** (upward direction), **L** (left direction), or **R** (right direction) representing the cable outlet direction.
The box (◆) is blank when the cable outlet direction is downward.


Type of gear	Single shaft		With electromagnetic brake	
	Motor model	Driver model	Motor model	Driver model
TH geared	ARM46AC-T●◆	ARD-AD2 ARD-CD2	ARM46MC-T●◆	ARD-AD2 ARD-CD2
	ARM66AC-T●◆		ARM66MC-T●◆	
	ARM98AC-T●◆		ARM98MC-T●◆	
FC geared	ARM46AC-FC●LA	ARD-AD2 ARD-CD2	-	-
	ARM46AC-FC●RA			
	ARM66AC-FC●LA			
	ARM66AC-FC●RA			
PS geared	ARM46AC-PS●	ARD-AD2 ARD-CD2	ARM46MC-PS●	ARD-AD2 ARD-CD2
	ARM66AC-PS●		ARM66MC-PS●	
	ARM98AC-PS●		ARM98MC-PS●	
PN geared	ARM46AC-N●	ARD-AD2 ARD-CD2	ARM46MC-N●	ARD-AD2 ARD-CD2
	ARM66AC-N●		ARM66MC-N●	
	ARM98AC-N●		ARM98MC-N●	
Harmonic geared	ARM46AC-H●	ARD-AD2 ARD-CD2	ARM46MC-H●	ARD-AD2 ARD-CD2
	ARM66AC-H●		ARM66MC-H●	
	ARM98AC-H●		ARM98MC-H●	

2-5 Input/output power ratings


Motor model	Driver model	Input			Output current per phase
		Voltage	Frequency	Current	
ARM46	ARD-AD2	Single-phase 100-120 V	50/60 Hz	2.4 A	0.49 A
ARM66				3.6 A	0.74 A
ARM69				4.9 A	0.92 A
ARM98				4.6 A	1.13 A
ARM911				5.9 A	1.27 A
ARM46	ARD-CD2	Single-phase 200-240 V	50/60 Hz	1.5 A	0.49 A
ARM66				2.3 A	0.74 A
ARM69				3.0 A	0.92 A
ARM98				2.9 A	1.13 A
ARM911				3.7 A	1.27 A

2-6 Names and functions of parts

■ Motor (Example: ARM66MC)



■ Driver (Example: ARD-CD2)



2 AC power input type

Name	Description	Page
PWR/ALM LED	<ul style="list-style-type: none"> • PWR (Green): This LED is lit while the 24 VDC power is input. • ALM (Red): This LED will blink if an alarm generates (a protective function is triggered). It is possible to check the generated alarm by counting the number of times the LED blinks. 	p.143
C-DAT/C-ERR LED	<ul style="list-style-type: none"> • C-DAT (Green): This LED blinks or is lit when the driver is communicating with the host controller properly via RS-485 communication. • C-ERR (Red): This LED will be lit if a RS-485 communication error occurs with the host controller. 	–
Address number setting switch (ID)	This switch is used when controlling the system via RS-485 communication. Sets the address number of RS-485 communication using this switch and SW4-No.1 of the function setting switch. Factory setting: 0	p.212 p.258
Termination resistor setting switch (TERM.)	This switch is used when controlling the system via RS-485 communication. Sets the termination resistor (120 Ω) of RS-485 communication. Factory setting: OFF	p.212 p.259
RS-485 connectors (CN6/CN7)	Connects the RS-485 cable.	p.42
Output signal connector (CN9)	Connects the output signals.	p.39
Input signal connector (CN8)	Connects the input signals.	
Sensor signal connector (CN5)	Connects the sensor signals.	
Data edit connector (CN4)	Connects a PC in which the MEXE02 has been installed, or the OPX-2A .	p.42
Protective Earth Terminals	Ground using a wire of AWG16 to 14 (1.25 to 2.0 mm ³).	p.35
24 VDC power supply input terminals (CN1-24V)	Connects a power supply for control circuit of the driver. +: +24 VDC power supply input –: Power supply GND	p.37
Regeneration resistor thermal input terminals (CN1-TH1/TH2)	Connects our regeneration resistor RGB100 . If no regeneration resistor is connected, short the TH1 and TH2 terminals.	
Electromagnetic brake terminals (CN1-MB1/MB2)	Connects the cable for electromagnetic brake. MB1: Electromagnetic brake – (black) MB2: Electromagnetic brake + (white)	
Motor connector (CN2)	Connects the motor.	p.34
CHARGE LED (Red)	This LED is lit while the main power is input. After the main power has been turned off, the LED will turn off once the residual voltage in the driver drops to a safe level.	–
Regeneration resistor terminals (CN3-RG1/RG2)	Connects our regeneration resistor RGB100 .	p.38
Main power supply input terminals (CN3-L/N)	Connects the main power supply. L: Live N: Neutral	p.36
Mounting holes (2 places at the back)	These mounting holes are used to secure the driver with screws.	p.32
Transmission rate setting switch (SW2)	This switch is used when controlling the system via RS-485 communication. Sets the transmission rate of RS-485 communication. Factory setting: 7	p.211 p.258
Function setting switch (SW4)	This switch is used when controlling the system via RS-485 communication. No.1: Sets the address number using this switch and the address number setting switch (ID). Factory setting: OFF No.2: Sets the protocol of RS-485 communication. Factory setting: OFF	

3 Installation

In addition to the installation locations and methods for the motor and driver, this chapter explains how to install a regenerative resistor.

3-1 Location for installation

The motor and driver are designed and manufactured to be incorporated in equipment. Install them in a well-ventilated location that provides easy access for inspection.

The location must also satisfy the following conditions:

- Inside an enclosure that is installed indoors (provide vent holes)
- Operating ambient temperature
 - Motor: -10 to $+50$ °C ($+14$ to $+122$ °F) (non-freezing)
 - Harmonic geared type: 0 to $+40$ °C ($+32$ to $+104$ °F) (non-freezing)
 - Driver: 0 to $+55$ °C ($+32$ to $+131$ °F) (non-freezing)
- Operating ambient humidity 85 % or less (non-condensing)
- Area free of explosive atmosphere, toxic gas (such as sulfuric gas), or liquid
- Area not exposed to direct sun
- Area free of excessive amount of dust, iron particles or the like
- Area not subject to splashing water (rain, water droplets), oil (oil droplets) or other liquids
- Area free of excessive salt
- Area not subject to continuous vibrations or excessive shocks
- Area free of excessive electromagnetic noise (from welders, power machinery, etc.)
- Area free of radioactive materials, magnetic fields or vacuum
- 1,000 m (3,300 ft.) or lower above sea level


3-2 Installing the motor

The motor can be installed in any direction.


To allow for heat dissipation and prevent vibration, install the motor on a metal surface of sufficient strength.

Values of the tightening torque are recommended. Tighten the screws with a suitable torque according to the design conditions of the metal plate to be installed.


● Installation method A



● Installation method B



● Installation method B (FC geared type)



Type	Frame size [mm (in.)]	Screw size	Tightening torque [N·m (oz-in)]	Effective depth of screw thread [mm (in.)]	Installation method
Standard	42 (1.65)	M3	1 (142)	4.5 (0.177)	A
	60 (2.36)	M4	2 (280)	-	B
	85 (3.35)	M6	3 (420)		
TH geared	42 (1.65) 60 (2.36)	M4	2 (280)	8 (0.315)	A
	90 (3.54)	M8	12 (1,700)	15 (0.591)	
FC geared	42 (1.65) 60 (2.36)	M4 M5	2 (280) 3 (420)	-	B
	PS geared PN geared Harmonic geared *1	M4 M5 M8	2 (280) 3 (420) 12 (1,700)		
Harmonic geared *2	90 (3.54)	M8	15 (2,100)	-	B

*1 **ARM46** and **ARM66** type only.

*2 **ARM98** type only.

3-3 Installing a load

This section describes how to install a load to the motor. Flexible couplings are provided in Oriental Motor products.

- Note**
- When installing a load on the output shaft, pay attention to centering, belt tension, parallelism of pulleys, etc. Also, securely tighten the screws of a coupling or pulley.
 - When installing a coupling or pulley on the output shaft, be careful not to damage to the output shaft or the bearing (ball bearings).
 - Do not modify or machine the output shaft. Doing so may damage the bearing (ball bearings), resulting in damage to the motor.
 - When removing the parallel key from the output shaft, be careful not to apply excessive force with a hammer or other tool. Doing so may damage the output shaft or bearing (ball bearings).

● **Using a coupling**

Align the axis of rotation for the output shaft and load in a straight line.


● **Using a belt**

- Align the axis of rotation for the output shaft and load parallel to each other.
- Make the axis of rotation for the output shaft and load perpendicular to a line connecting the centers of the two pulleys.


● **Using a gear drive**

- Align the output shaft and gear axis parallel to each other.
- Properly engage the centers of the gear tooth surfaces.


Using a coupling



Using a belt



Using a gear drive




● **Using a key to fasten (geared motor)**

When installing a load on the output shaft with a machined key slot, machine a key slot on the load side and secure the load and output shaft with the included key.

● **Harmonic geared type; Installing the load on the flange surface**

With a Harmonic geared type (excluding **ARM98**), a load can be installed directly to the gear using the load mounting screw holes provided on the flange surface.



Motor model	Screw size	Number of screw	Tightening torque [N·m (oz·in)]	Effective depth of screw thread [mm (in.)]
ARM46	M3	6	1.4 (198)	5 (0.197)
ARM66	M4	6	2.5 (350)	6 (0.236)

- memo**
- When installing a load on the flange surface, the load cannot be mounted using the key slot in the output shaft.
 - Design an appropriate installation layout so that the load will not contact the metal plate or screws used for installing the motor.

3-4 Permissible radial load and permissible axial load

- Note**
- If the radial load or axial load exceeds the specified allowable value, repeated load applications may cause the bearing (ball bearings) or output shaft of the motor to undergo a fatigue failure.
 - For the double shaft type, do not apply a load torque, radial load, or axial load to the rear shaft on the opposite side of the motor output shaft.

memo The permissible radial load and permissible axial load of the **PS** geared type and **PN** geared type represent the value that the service life of the gear part satisfies 20,000 hours when either of the radial load or axial load is applied to the gear output shaft.

Type	Motor model	Gear ratio	Permissible radial load [N (lb.)]					Permissible axial load [N (lb.)]
			Distance from the tip of output shaft [mm (in.)]					
			0 (0)	5 (0.2)	10 (0.39)	15 (0.59)	20 (0.79)	
Standard	ARM46	-	35 (7.8)	44 (9.9)	58 (13)	85 (19.1)	-	15 (3.3)
	ARM66 ARM69		90 (20)	100 (22)	130 (29)	180 (40)	270 (60)	30 (6.7)
	ARM98 ARM911		260 (58)	290 (65)	340 (76)	390 (87)	480 (108)	60 (13.5)
TH geared	ARM46	All gear ratio	10 (2.2)	14 (3.1)	20 (4.5)	30 (6.7)	-	15 (3.3)
	ARM66		70 (15.7)	80 (18)	100 (22)	120 (27)	150 (33)	40 (9)
	ARM98		220 (49)	250 (56)	300 (67)	350 (78)	400 (90)	100 (22)
FC geared	ARM46	All gear ratio	180 (40)	200 (45)	220 (49)	250 (56)	-	100 (22)
	ARM66		270 (60)	290 (65)	310 (69)	330 (74)	350 (78)	200 (45)
PS geared	ARM46	5	70 (15.7)	80 (18)	95 (21)	120 (27)	-	100 (22)
		7.2	80 (18)	90 (20)	110 (24)	140 (31)	-	
		10	85 (19.1)	100 (22)	120 (27)	150 (33)	-	
		25	120 (27)	140 (31)	170 (38)	210 (47)	-	
		36	130 (29)	160 (36)	190 (42)	240 (54)	-	
		50	150 (33)	170 (38)	210 (47)	260 (58)	-	

Type	Motor model	Gear ratio	Permissible radial load [N (lb.)]					Permissible axial load [N (lb.)]	
			Distance from the tip of output shaft [mm (in.)]						
			0 (0)	5 (0.2)	10 (0.39)	15 (0.59)	20 (0.79)		
PS geared	ARM66	5	170 (38)	200 (45)	230 (51)	270 (60)	320 (72)	200 (45)	
		7.2	200 (45)	220 (49)	260 (58)	310 (69)	370 (83)		
		10	220 (49)	250 (56)	290 (65)	350 (78)	410 (92)		
		25	300 (67)	340 (76)	400 (90)	470 (105)	560 (126)		
		36	340 (76)	380 (85)	450 (101)	530 (119)	630 (141)		
		50	380 (85)	430 (96)	500 (112)	600 (135)	700 (157)		
	ARM98	5	380 (85)	420 (94)	470 (105)	540 (121)	630 (141)	600 (135)	
		7.2	430 (96)	470 (105)	530 (119)	610 (137)	710 (159)		
		10	480 (108)	530 (119)	590 (132)	680 (153)	790 (177)		
		25	650 (146)	720 (162)	810 (182)	920 (200)	1,070 (240)		
		36	730 (164)	810 (182)	910 (200)	1,040 (230)	1,210 (270)		
		50	820 (184)	910 (200)	1,020 (220)	1,160 (260)	1,350 (300)		
PN geared	ARM46	5	80 (18)	95 (21)	120 (27)	160 (36)	–	100 (22)	
		7.2	90 (20)	110 (24)	130 (29)	180 (40)	–		
		10	100 (22)	120 (27)	150 (33)	200 (45)	–		
	ARM66	5	240 (54)	260 (58)	280 (63)	300 (67)	330 (74)	200 (45)	
		7.2	270 (60)	290 (65)	310 (69)	340 (76)	370 (83)		
		10	300 (67)	320 (72)	350 (78)	380 (85)	410 (92)		
		25	410 (92)	440 (99)	470 (105)	520 (117)	560 (126)		
		36	360 (81)	410 (92)	480 (108)	570 (128)	640 (144)		
		50	360 (81)	410 (92)	480 (108)	570 (128)	700 (157)		
	ARM98	5	370 (83)	390 (87)	410 (92)	430 (96)	460 (103)	600 (135)	
		7.2	410 (92)	440 (99)	460 (103)	490 (110)	520 (117)		
		10	460 (103)	490 (110)	520 (117)	550 (123)	580 (130)		
		25	630 (141)	660 (148)	700 (157)	740 (166)	790 (177)		
		36	710 (159)	750 (168)	790 (177)	840 (189)	900 (200)		
		50	790 (177)	840 (189)	890 (200)	940 (210)	1,000 (220)		
	Harmonic geared	ARM46	All gear ratio	180 (40)	220 (49)	270 (60)	360 (81)	510 (114)	220 (49)
		ARM66		320 (72)	370 (83)	440 (99)	550 (123)	720 (162)	450 (101)
		ARM98		1,090 (240)	1,150 (250)	1,230 (270)	1,310 (290)	1,410 (310)	1,300 (290)

■ Permissible moment load of the Harmonic geared type

If an eccentric load is applied on the flange surface when installing an arm or a table, do not exceed the permissible value shown in the table.

Motor model	Permissible moment load (N·m)
ARM46	5.6
ARM66	11.6

Calculate the moment load using the International System of Units (N, N·m).


● **Example 1;**

When an external force F is applied on the position of distance L from the center of the output flange

L: Distance from the center of the output flange (m)

F: External force (N)

Moment load: $M \text{ (N·m)} = F \times L$



● **Example 2;**


When external forces F is applied on the position of distance L from the mounting face of the output flange

L: Distance from the mounting face of the output flange (m)

F: External force (N)

Moment load: $M \text{ (N·m)} = F \times (L + \text{coefficient "a"})$

Motor model	Coefficient "a"
ARM46	0.009
ARM66	0.0114




3-5 Installing the driver

The driver is designed so that heat is dissipated via air convection and conduction through the enclosure. Install the driver on a flat metal plate [material: aluminium, 200×200×2 mm (7.87×7.87×0.08 in.) equivalent] having excellent heat conductivity. When two or more drivers are to be installed side by side, provide 20 mm (0.79 in.) and 25 mm (0.98 in.) clearances in the horizontal and vertical directions, respectively. When installing the driver inside an enclosure, use two screws (M4, not included) to secure the driver through the mounting holes.




- Install the driver in an enclosure whose degree of protection is IP54 minimum when used in a pollution degree 3 environment.
- Do not install any equipment that generates a large amount of heat or noise near the driver.
- Do not install the driver underneath the controller or other equipment vulnerable to heat.
- If the ambient temperature of the driver exceeds 55 °C (131 °F), improve the ventilation condition.
- Be sure to install the driver vertically (vertical position).



Unit: mm (in.)


Dimension [unit: mm (in.)]

Mass: 0.75 kg (1.65 lb.)



3-6 Installing the regeneration resistor

Install our regeneration resistor **RGB100** in a location where heat dissipation capacity equivalent to a level achieved with a heat sink [made of aluminum, 350×350×3 mm (13.78×13.78×0.12 in.)] is ensured.
Affix the regeneration resistor on a smooth metal plate offering high heat conductivity, using two screws (M4, not included).



4 Connection


This chapter explains how to connect the motor, I/O signals and power supply to the driver, as well as grounding method. The installation and wiring methods in compliance with the EMC Directive as well as protection against noise are also explained.

⚠ WARNING

- For protection against electric shock, do not turn on the power supply until the wiring is completed.
- A high voltage is applied to the motor connector (CN2) and the main power supply input terminal (CN3). Do not touch these terminals while the power is on. Doing so may result in fire or electric shock.

4-1 Connection example

The figure shows models for the electromagnetic brake motor and single-phase 200 to 240 VAC input.



*1 Keep 30 m (98.4 ft.) or less for the wiring distance between the motor and driver.
 *2 These cables are provided as our products. Purchase them separately.

Note

- Connect the connectors securely. Insecure connections may cause malfunction or damage to the motor or driver.
- When cycling the main power supply or connecting/disconnecting the connector, turn off the power and wait for the CHARGE LED to turn off before doing so. The residual voltage may cause electric shock.
- Do not wire the power supply cable of the driver in the same cable duct with other power lines or motor cables. Doing so may cause malfunction due to noise.
- The lead wires of the "cable for electromagnetic brake" have polarities, so connect them in the correct polarities. If the lead wires are connected with their polarities reversed, the electromagnetic brake will not operate properly.

memo

- When disconnecting the connector, pull out while pressing the latches on the connector with fingers.
- When installing the motor on a moving part, use our flexible cable. Refer to p.46 for the model name.

● Cable size and tightening torque

Connector	Terminal symbol	Recommended cable size	Screw size	Tightening torque [N·m (oz·in)]
CN1	24V+, 24V-	Stranded wire AWG28 to 16 (0.08 to 1.25 mm ²)	M2	0.22 to 0.25 (31 to 35)
	TH1, TH2	Stranded wire AWG22 (0.3 mm ²)		
	MB1, MB2	Stranded wire AWG20 (0.5 mm ²)		
CN3	RG1, RG2	Stranded wire AWG18 (0.75 mm ²)	-	-
	L, N	Stranded wire AWG16 to 14 (1.25 to 2.0 mm ²)		
CN5	-	Stranded wire AWG26 to 20 (0.14 to 0.5 mm ²)	-	-
CN8	-	Stranded wire AWG26 to 20 (0.14 to 0.5 mm ²)	-	-
CN9	-	Stranded wire AWG26 to 20 (0.14 to 0.5 mm ²)	-	-


4-2 Grounding the motor and driver

■ Grounding the motor

Be sure to ground the Protective Earth Terminal of the motor.

- Grounding wire: AWG18 (0.75 mm²) or more
- Screw size: M4
- Tightening torque: 1.2 N·m (170 oz·in)

Use a round terminal when grounding, and secure it with a mounting screw with a washer. Ground wires and crimp terminals are not included.




■ Grounding the driver

Be sure to ground the Protective Earth Terminal of the driver.

- Grounding wire: AWG16 to 14 (1.25 to 2.0 mm²)
- Screw size: M4
- Tightening torque: 1.2 N·m (170 oz·in)


You can ground either of the two Protective Earth Terminals. The terminal that is not grounded is used as a service terminal. Use the service terminal according to your specific need, such as connecting it to the motor in order to ground the motor. Do not share the grounding wire with a welder or any other power equipment.

When grounding the Protective Earth Terminal, use a round terminal and secure the grounding point near the driver.



4-3 Connecting the main power supply

Use the CN3 connector (5 pins) to connect the power supply cable (AWG16 to 14: 1.25 to 2.0 mm²) to the main power supply connector (CN3) on the driver.




Note

- Do not wire the power supply cable of the driver in the same cable duct with other power lines or motor cables. Doing so may cause malfunction due to noise.
- When cycling the power or connecting/disconnecting the connector, turn off the power and wait for the CHARGE LED to turn off. The residual voltage may cause electric shock.

■ Wiring method


- Applicable lead wire: AWG16 to 14 (1.25 to 2.0 mm²)
- Stripping length of wire insulation : 8 to 9 mm (0.31 to 0.35 in.)

1. Insert the connector wiring lever.
2. Insert the lead wire while pushing down the connector wiring lever.



You can also connect the power supply cable using a slotted screwdriver.

Insert the lead wire while pushing the insertion port using a slotted screwdriver with a tip of 3.0 to 3.5 mm (0.12 to 0.14 in.) in width.



■ Power supply current capacity

The current capacity of the main power supply varies depending on the motor combined.

Check the current capacity in reference to the equipped motor model when using the **EAS** Series, **EAC** Series, **EZS** Series, or **EZSH** Series.

Model	Single-phase 100-120 V -15 to +6 % 50/60 Hz	Single-phase 200-240 V -15 to +6 % 50/60 Hz
ARM46	2.4 A or more	1.5 A or more
ARM66	3.6 A or more	2.3 A or more
ARM69	4.9 A or more	3.0 A or more
ARM98	4.6 A or more	2.9 A or more
ARM911	5.9 A or more	3.7 A or more
DGM85	2.4 A or more	1.5 A or more
DGM130	3.6 A or more	2.3 A or more
DGM200	5.9 A or more	3.7 A or more


4-4 Connecting the 24 VDC power supply, regeneration resistor and electromagnetic brake

Use the CN1 connector (6 pins) to connect the 24 VDC power supply, regeneration resistor and electromagnetic brake. Connect the lead wire (AWG28 to 16: 0.08 to 1.25 mm²) to the connector while checking the pin numbers in below.

Display	Description
24V+	24 VDC power supply input
24V-	
TH1	Regeneration resistor thermal input (If these pins are not used, short it using a jumper wire.)
TH2	
MB1	Electromagnetic brake – (Connect the black lead wire of the electromagnetic brake.)
MB2	Electromagnetic brake + (Connect the white lead wire of the electromagnetic brake.)

■ Connecting method

1. Strip the insulation cover of the lead wire by 7 mm (0.28 in.)
2. Insert each lead wire into the CN1 connector and tighten the screw with a slotted screwdriver.
Connector screw size: M2
Tightening torque: 0.22 to 0.25 N·m (31 to 35 oz-in)
3. Insert the CN1 connector into the CN1, and tighten the screw.
Connector screw size: M2.5
Tightening torque: 0.4 N·m (56 oz-in)



■ Connecting the 24 VDC power supply

Connect a 24 VDC power supply of the current capacity shown in the following table. Check the current capacity in reference to the equipped motor model when using the **EAS** Series, **EAC** Series, **EZS** Series, or **EZSH** Series.

The 24 VDC power supply is for the control circuit. Be sure to connect it.

Model	Input power supply voltage	Power supply current capacity	
		Without electromagnetic brake	With electromagnetic brake
ARM46	24 VDC±5 %*	0.25 A or more	0.33 A or more
ARM66, ARM69, ARM98			0.5 A or more
ARM911			–
DGM85	24 VDC±5 %		–
DGM130	24 VDC±5 %*		0.5 A or more
DGM200			


* Use a power supply of 24 VDC ±4 % when extending the wiring distance between a product with an electromagnetic brake and a driver to 20 m (65.6 ft.) to 30 m (98.4 ft.).



When turning on the 24 VDC power supply again, turn off the 24VDC power supply and wait for at least 1 second before doing so.

■ Connecting the regeneration resistor

If vertical drive (gravitational operation) such as elevator applications is performed or if sudden start-stop operation of a large inertia load is repeated frequently, connect our regeneration resistor **RGB100**.



- The two thin lead wires (AWG22: 0.3 mm²) of the regeneration resistor are the thermostat outputs. Connect them to the TH1 and TH2 terminals using the CN1 connector.
- Regenerative current flows through the two thick lead wires (AWG18: 0.75 mm²) of the regeneration resistor. Connect them to the RG1 and RG2 terminals using the CN3 connector.



- Before connecting the regeneration resistor, be sure to remove the jumper wire from the CN1 connector.
- If the allowable power consumption of the regeneration resistor exceeds the allowable level, the thermostat will be triggered and an alarm of regeneration resistor overheat is generated. If an alarm of regeneration resistor overheat is generated, turn off the main power supply and check the content of the error.

Regeneration resistor specifications

Model	RGB100
Allowable current consumption	Continuous regenerative power: 50 W * Instantaneous regenerative power: 600 W
Resistance	150 Ω
Operating temperature of thermostat	Operation: Opens at 150±7 °C (302±12.6 °F) Reset: Closes at 145±12 °C (293±21.6 °F) (normally closed)
Electrical rating of thermostat	120 VAC 4 A, 30 VDC 4 A (minimum current: 5 mA)

* Install the regeneration resistor in a location where heat dissipation capacity equivalent to a level achieved with a heat sink [made of aluminum, 350×350×3 mm (13.78×13.78×0.12 in.)] is ensured.


■ Connecting the electromagnetic brake

When the electromagnetic brake is connected, it can automatically be controlled by interlocking with the C-ON input or the FREE input. Refer to p.34 for connection method.

4-5 Connecting the I/O signals

■ Wiring method


- Applicable lead wire: AWG26 to 20 (0.14 to 0.5 mm²)
 - Stripping length of wire insulation: 8 mm (0.31 in.)
1. Strip the insulation cover of the lead wire.
 2. Insert the lead wire while pushing the button of the orange color on the connector with a slotted screwdriver.
 3. After having inserted, release the button to secure the lead wire.



■ Pin assignment


● Sensor signals (CN5)

Pin No.	Signal name	Description
1	+LS	Limit sensor input +
2	-LS	Limit sensor input -
3	HOMES	Mechanical home sensor input
4	SLIT	Slit sensor input
5	IN-COM2	Sensor signals common



● Input signals (CN8)


Pin No.	Signal name	Description *
1	IN0	Control input 0 (HOME)
2	IN1	Control input 1 (START)
3	IN2	Control input 2 (M0)
4	IN3	Control input 3 (M1)
5	IN4	Control input 4 (M2)
6	IN5	Control input 5 (FREE)
7	IN6	Control input 6 (STOP)
8	IN7	Control input 7 (ALM-RST)
9	IN-COM1	Input signals common



* (): Initial value

● Output signals (CN9)


Pin No.	Signal name	Description *
1	OUT0	Control output 0 (HOME-P)
2	OUT1	Control output 1 (END)
3	OUT2	Control output 2 (AREA1)
4	OUT3	Control output 3 (READY)
5	OUT4	Control output 4 (WNG)
6	OUT5	Control output 5 (ALM)
7	OUT-COM	Output signals common



* (): Initial value

2 AC power input type

■ Connection example with a current source output circuit (PNP specifications)




- Use input signals at 24 VDC.
- Use output signals at 12 to 24 VDC 10 mA or less. If the current exceeds 10 mA, connect an external resistor R0 so that the current becomes 10 mA or less.
- The saturated voltage of the output signal is 3 VDC maximum.

2 AC power input type

4-6 Connecting the data setter

Connect the communication cable for the support software or **OPX-2A** cable to the data edit connector (CN4) on the driver.




CAUTION

The data edit connector (CN4) and RS-485 connectors (CN6/CN7) of the driver are not insulated. When grounding the positive terminal of the power supply, do not connect any equipment (PC, etc.) whose negative terminal is grounded. Doing so may cause the driver and these equipment to short, damaging both.


4-7 Connecting the RS-485 cable

Connect this cable if you want to control your product via RS-485 communication. Connect the RS-485 cable to CN6 or CN7 on the driver.

You can use the vacant connectors to connect a different driver. A driver link cable is also available in our products. Refer to p.48 for the model name. You can also use a commercial LAN cable (straight cable) to link drivers.




Internal input circuit



CN6/CN7 pin assignment

Pin No.	Signal name	Description
1	N.C.	Not used.
2	GND	GND
3	TR+	RS-485 communication signal (+)
4	N.C.	Not used.
5	N.C.	
6	TR-	RS-485 communication signal (-)
7	N.C.	Not used.
8	N.C.	



4-8 Noise elimination measures

The electrical noise is of two types: One is a noise to invade into the driver from the outside and cause the driver malfunction, and the other is a noise to emit from the driver and cause peripheral equipments malfunction. For the noise that is invaded from the outside, take measures to prevent the driver malfunction. It is needed to take adequate measures because signal lines are very likely to be affected by the noise. For the noise that is emitted from the driver, take measures to suppress it.

■ Measures against electrical noise


There are the following three methods mainly to take measures against the electrical noise.

● Noise suppression

- When relays or electromagnetic switches are used together with the system, use noise filters and CR circuits to suppress surges generated by them.
- Use our connection cable or extension cable when extending a wiring distance between the motor and driver. Refer to p.46 for the model name.
- Cover the driver by a metal plate such as aluminum. This is effective in shielding the electrical noise emitted from the driver.

● Prevention of noise propagation

- Connect a noise filter in the power supply cable of driver.
- Place the power lines, such as the motor and power supply cables, keeping a distance of 200 mm (7.87 in.) or more from the signal lines, and also do not bundle them or wire them in parallel. If the power cables and signal cables have to cross, cross them at a right angle.
- Use shielded twisted pair cables for power lines and signal lines.
- Keep cables as short as possible without coiling and bundling extra lengths.
- Grounding multiple points will increase effect to block electrical noise because impedance on the grounding points is decreased. However, ground them so that a potential difference does not occur among the grounding points. I/O signal cables that include a ground wire are provided in our product line. Refer to p.48 for the model name.
- To ground a shielded cable, use a metal cable clamp that will maintain contact with the entire circumference of the cable. Ground the cable clamp near the product.



● Suppression of effect by noise propagation

Loop the noise propagated cable around a ferrite core. Doing so will prevent the propagated noise invades into the driver or emits from the driver. The frequency band in which an effect by the ferrite core can be seen is generally 1 MHz or more. Check the frequency characteristics of the ferrite core used. To increase the effect of noise attenuation by the ferrite core, loop the cable a lot.

■ Noise suppression products

● Noise filter

- Connect the following noise filter (or equivalent) to the power line. Doing so will prevent the propagated noise through the power line. Install the noise filter as close to the driver as possible.

Manufacture	Model
SOSHIN ELECTRIC CO., LTD.	HF2010A-UPF
Schaffner EMC	FN2070-10-06

- Use the AWG18 (0.75 mm²) or thicker wire for the input and output cables of the noise filter, and secure firmly using a cable clamp or others so that the cable does not come off the enclosure.
- Place the input cable as far apart as possible from the output cable, and do not wire the cables in parallel. If the input and output cable are placed at a close distance or if they are wired in parallel, the noise inside the enclosure affects the power cable through stray capacitance, and the noise suppressing effect will reduce.
- Connect the ground terminal of the noise filter to the grounding point, using as thick and short a wire as possible.
- When connecting a noise filter inside an enclosure, wire the input cable of the noise filter as short as possible. Wiring in long distance may reduce the noise suppressing effect.

- **Surge arrester**

A surge arrester is effective for reduction of the surge voltage of the lightning surge generated between the AC power line and earth or between AC power lines. Connect the following surge arrester.
R-A-V-781BWZ-4 (OKAYA ELECTRIC INDUSTRIES CO., LTD.)



When measuring dielectric strength of the equipment, be sure to remove the surge arrester, or the surge arrester may be damaged.

- **Our noise suppression products**

Refer to p.48 for the model name.

- **I/O signal cable**

This cable is a shielded twisted pair cable for good noise immunity to connect the driver and host controller. The ground wires useful to grounding are provided at both ends of the cable. The EMC testing is conducted using our I/O signal cable.

- **Surge suppressor**

This product is effective to suppress the surge which occurs in a relay contact part. Connect it when using a relay or electromagnetic switch. CR circuit for surge suppression and CR circuit module are provided.

4-9 Conformity to the EMC Directive

Effective measures must be taken against the EMI that the motor and driver may give to adjacent control-system equipment, as well as the EMS of the motor and driver itself, in order to prevent a serious functional impediment in the machinery. The use of the following installation and wiring methods will enable the motor and driver to be compliant with the EMC Directive.

Oriental Motor conducts EMC testing on its motors and drivers in accordance with "Example of installation and wiring" on p.45.

The user is responsible for ensuring the machine's compliance with the EMC Directive, based on the installation and wiring explained below.



CAUTION This equipment is not intended for use in residential environments nor for use on a low-voltage public network supplied in residential premises, and it may not provide adequate protection to radio reception interference in such environments.

- **Connecting noise filter**

In large electrically noisy environments, connect a noise filter. Refer to "Noise filter" on p.43.

- **Connecting surge arrester**

Refer to "Surge arrester" in the above.

- **Connecting the 24 VDC power supply**

Use a 24 VDC power supply that conforms to the EMC Directive.

Use a shielded twisted pair cable for wiring. Refer to "Prevention of noise propagation" on p.43 for wiring method.

- **Connecting the motor cable**

Use our connection cable or extension cable when extending the wiring distance between the motor and driver. Refer to "Connection cable set model" on p.46 for the model name.


- **Connecting the signal cable**

Refer to "Prevention of noise propagation" on p.43.

- **How to ground**

- The cable used to ground the motor, driver and noise filter must be as thick and short as possible so that no potential difference is generated.
- Choose a large, thick and uniformly conductive surface for the grounding point.
- Be sure to ground the Protective Earth Terminal of the motor and driver. Refer to p.35 for grounding method.

● Example of installation and wiring



Note The driver uses parts that are sensitive to electrostatic charge. Take measures against static electricity since static electricity may cause the driver to malfunction or suffer damage.

2 AC power input type

5 Cables




When installing the motor on a moving part, use a flexible cable.

5-1 Connection cable set

Use when connecting a motor and a driver.

The cable set for electromagnetic brake motors consists of two cables, one for motor and the other for electromagnetic brake.



* Only when the motor is of electromagnetic brake type.

2 AC power input type

● Connection cable set model


Length [m (ft.)]	For standard type motor	For electromagnetic brake type motor
0.5 (1.6)	CC005VAF	CC005VAFB
1 (3.3)	CC010VAF	CC010VAFB
1.5 (4.9)	CC015VAF	CC015VAFB
2 (6.6)	CC020VAF	CC020VAFB
2.5 (8.2)	CC025VAF	CC025VAFB
3 (9.8)	CC030VAF	CC030VAFB
4 (13.1)	CC040VAF	CC040VAFB
5 (16.4)	CC050VAF	CC050VAFB
7 (23)	CC070VAF	CC070VAFB
10 (32.8)	CC100VAF	CC100VAFB
15 (49.2)	CC150VAF	CC150VAFB
20 (65.6)	CC200VAF	CC200VAFB
30 (98.4)	CC300VAF	CC300VAFB

● Flexible connection cable set model

Length [m (ft.)]	For standard type motor	For electromagnetic brake type motor
0.5 (1.6)	CC005VAR	CC005VARB
1 (3.3)	CC010VAR	CC010VARB
1.5 (4.9)	CC015VAR	CC015VARB
2 (6.6)	CC020VAR	CC020VARB
2.5 (8.2)	CC025VAR	CC025VARB
3 (9.8)	CC030VAR	CC030VARB
4 (13.1)	CC040VAR	CC040VARB
5 (16.4)	CC050VAR	CC050VARB
7 (23)	CC070VAR	CC070VARB
10 (32.8)	CC100VAR	CC100VARB
15 (49.2)	CC150VAR	CC150VARB
20 (65.6)	CC200VAR	CC200VARB
30 (98.4)	CC300VAR	CC300VARB

5-2 Extension cable set

Use when extending the distance between a motor and a driver or when the length of the connection cable used is not enough. Extend the distance by connecting the extension cable to the connection cable. The cable set for electromagnetic brake motors consists of two cables, one for motor and the other for electromagnetic brake.



*1 Use the connection cable used.

*2 Only when the motor is of electromagnetic brake type.



When extending the wiring length by connecting an extension cable to the connection cable, keep the total cable length to 30 m (98.4 ft.) or less.

● Extension cable set model

Length [m (ft.)]	For standard type motor	For electromagnetic brake type motor
0.5 (1.6)	CC005VAFT	CC005VAFBT
1 (3.3)	CC010VAFT	CC010VAFBT
1.5 (4.9)	CC015VAFT	CC015VAFBT
2 (6.6)	CC020VAFT	CC020VAFBT
2.5 (8.2)	CC025VAFT	CC025VAFBT
3 (9.8)	CC030VAFT	CC030VAFBT
4 (13.1)	CC040VAFT	CC040VAFBT
5 (16.4)	CC050VAFT	CC050VAFBT
7 (23)	CC070VAFT	CC070VAFBT
10 (32.8)	CC100VAFT	CC100VAFBT
15 (49.2)	CC150VAFT	CC150VAFBT
20 (65.6)	CC200VAFT	CC200VAFBT

● Flexible extension cable set model

Length [m (ft.)]	For standard type motor	For electromagnetic brake type motor
0.5 (1.6)	CC005VART	CC005VARBT
1 (3.3)	CC010VART	CC010VARBT
1.5 (4.9)	CC015VART	CC015VARBT
2 (6.6)	CC020VART	CC020VARBT
2.5 (8.2)	CC025VART	CC025VARBT
3 (9.8)	CC030VART	CC030VARBT
4 (13.1)	CC040VART	CC040VARBT
5 (16.4)	CC050VART	CC050VARBT
7 (23)	CC070VART	CC070VARBT
10 (32.8)	CC100VART	CC100VARBT
15 (49.2)	CC150VART	CC150VARBT
20 (65.6)	CC200VART	CC200VARBT

5-3 Communication cable for the support software

Be sure to purchase the communication cable for the support software when connecting a driver and PC in which the support software **MEXE02** has been installed.

This is a set of a PC interface cable and USB cable. The cable is connected to the USB port on the PC.

The **MEXE02** can be downloaded from Oriental Motor Website Download Page.

Model: **CC05IF-USB** [5 m (16.4 ft.)]

5-4 RS-485 cable

You can link drivers using this cable connected to the RS-485 connectors (CN6, CN7).

Model: **CC002-RS4** [0.25 m (1 ft.)]

5-5 I/O signal cable

A shielded cable for driver control I/O signals offering excellent noise resistance. The ground wires useful to grounding are provided at both ends of the cable.

Select the cable suitable for the number of I/O signals connected.

General-purpose type

Cable length [m (ft.)]	Number of lead wire			
	6 pcs.	10 pcs.	12 pcs.	16 pcs.
0.5 (1.6)	CC06D005B-1	CC10D005B-1	CC12D005B-1	CC16D005B-1
1 (3.3)	CC06D010B-1	CC10D010B-1	CC12D010B-1	CC16D010B-1
1.5 (4.9)	CC06D015B-1	CC10D015B-1	CC12D015B-1	CC16D015B-1
2 (6.6)	CC06D020B-1	CC10D020B-1	CC12D020B-1	CC16D020B-1

6 Accessories

6-1 Setting tools

■ Data setter

The data setter lets you set operation data and parameters for your **AR** Series with ease and also functions as a monitor.

Model: **OPX-2A**

6-2 Wiring support tools

■ Regeneration resistor

If vertical drive (gravitational operation) such as elevating applications is performed or if sudden start-stop operation of a large inertia is repeated frequently, connect the regeneration resistor. Always connect the regeneration resistor if an overvoltage protection warning or alarm generates.

Model: **RGB100**

■ CR circuit for surge suppression

This product is effective to suppress the surge which occurs in a relay contact part. Use it to protect the contacts of the relay or switch.

Model: **EPCR1201-2**

■ CR circuit module

This product is effective to suppress the surge which occurs in a relay contact part. Use this product to protect the contacts of the relay or switch.

Four pieces of CR circuit for surge suppression are mounted on the compact circuit, and this product can be installed to the DIN rail. This product can make the wiring easily and securely since it also supports terminal block connection.

Model: **VCS02**


3 DC power input type

This part explains contents specific to the AR Series DC power input type.

◆ Table of contents

1	System configuration.....	52	4	Connection	67
2	Preparation	53	4-1	Connection example.....	67
2-1	Checking the product	53	4-2	Grounding the motor and the driver	68
2-2	How to identify the product model	54	4-3	Connecting the power supply and electromagnetic brake.....	68
2-3	Information about nameplate	55	4-4	Connecting the I/O signals.....	69
2-4	Combinations of motors and drivers.....	56	4-5	Connecting the data setter	73
2-5	Input/output power ratings.....	57	4-6	Connecting the RS-485 cable.....	73
2-6	Names and functions of parts.....	57	4-7	Noise elimination measures	74
3	Installation	60	4-8	Conformity to the EMC Directive	75
3-1	Location for installation.....	60	5	Cables	77
3-2	Installing the motor	60	5-1	Connection cable set.....	77
3-3	Installing a load	61	5-2	Extension cable set	78
3-4	Permissible radial load and permissible axial load.....	62	5-3	Communication cable for the support software	79
3-5	Installing the driver.....	65	5-4	RS-485 cable	79
			5-5	I/O signal cable.....	80
			6	Accessories.....	81
			6-1	Setting tools	81
			6-2	Wiring support tools.....	81

1 System configuration



- *1 This cable is provided as our product. When the length of the motor cable is not enough, purchase it separately.
- *2 The PC must be supplied by the user. Use our communication cable for the support software **CC051F-USB** when connecting the PC and driver.
- *3 These products are provided as our accessories.

2 Preparation

This chapter explains the items you should check, as well as the name and function of each part.

2-1 Checking the product

Verify that the items listed below are included. Report any missing or damaged items to the Oriental Motor sales office from which you purchased the product.

● Motor

- Motor 1 unit
- Parallel key 1 pc. *1
- Varistor 1 pc. *2
- Instructions and Precautions for Safe Use 1 copy
- APPENDIX UL Standards for **AR** Series 1 copy *3

*1 Included with geared types. However, the following geared types are excluded.

TH geared: **ARM24-T**, **ARM46-T**, and **ARM66-T**

PS geared: **ARM24-PS**

PN geared: **ARM24-N**

Harmonic geared: **ARM24-H**

*2 Included with the electromagnetic brake motor. It is not used for the built-in controller type driver.

*3 Included with products conform to the UL Standards.

● Driver

- Driver 1 unit
- CN1 connector (5 pins) 1 pc.
- CN5 connector (5 pins) 1 pc.
- CN8 connector (9 pins) 1 pc.
- CN9 connector (7 pins) 1 pc.
- Instructions and Precautions for Safe Use 1 copy

Included connector model

Type	Model (Manufacturer)
CN1 connector	MC1,5/5-STF-3,5 (PHOENIX CONTACT GmbH & Co. KG)
CN5 connector	FK-MC0,5/5-ST-2,5 (PHOENIX CONTACT GmbH & Co. KG)
CN8 connector	FK-MC0,5/9-ST-2,5 (PHOENIX CONTACT GmbH & Co. KG)
CN9 connector	FK-MC0,5/7-ST-2,5 (PHOENIX CONTACT GmbH & Co. KG)

2-2 How to identify the product model

Check the model name of the motor and driver against the number shown on the nameplate. Refer to p.55 for how to identify the nameplate.

■ Motor

● Standard type


ARM 2 4 S A 0 K
1 2 3 4 5 6 7

● Geared type

ARM 4 6 S A K - T 7.2 U
1 2 3 4 5 7 8 9 10

1	Series name	ARM: AR Series motor
2	Motor frame size	1: 20 mm (0.79 in.) 2: 28 mm (1.10 in.) [30 mm (1.18 in.) for Harmonic geared type] 4: 42 mm (1.65 in.) 6: 60 mm (2.36 in.) 9: 85 mm (3.35 in.) [90 mm (3.54 in.) for geared type]
3	Motor length	
4	Motor identification	S: Without connector cover for cable Blank: With connector cover for cable
5	Motor type	A: Single shaft B: Double shaft M: With electromagnetic brake
6	Additional function	0: Round shaft without shaft flat Blank: Round shaft with shaft flat on one side
7	Motor power supply input	K: DC power input type
8	Type of gear	T: TH geared PS: PS geared N: PN geared H: Harmonic geared Blank: Standard
9	Gear ratio	Indicates a number representing the gear ratio. Refer to p.55 for the gear type and gear ratio.
10	Cable outlet direction * (TH geared type only)	U: Upward direction L: Leftward direction R: Rightward direction Blank: Downward direction

* The cable outlet direction represents the one as viewed from the output shaft side in a state of placing it upward.



Type of gear ratio

Type of gear	Gear ratio
TH geared	ARM24: 7.2, 10, 20, 30 ARM46, ARM66, ARM98: 3.6, 7.2, 10, 20, 30
PS geared	ARM24: 5, 7.2 (*), 10 ARM46, ARM66, ARM98: 5, 7.2 (*), 10, 25, 36, 50
PN geared	ARM24, ARM46: 5, 7.2, 10 ARM66, ARM98: 5, 7.2, 10, 25, 36, 50
Harmonic geared	50, 100

* The model name is "7" for the gear ratio 7.2 of the PS geared type.


■ Driver

ARD - K D 2
 1 2 3 4

1	Series name	ARD: AR Series driver
2	Power supply input	K: 24 VDC/48 VDC
3	Type	D: Built-in controller type
4	Reference number	

2-3 Information about nameplate

The figure shows an example.



The position describing the information may vary depending on the product.

2-4 Combinations of motors and drivers

■ Standard type

Single shaft		Double shaft		With electromagnetic brake	
Motor model	Driver model	Motor model	Driver model	Motor model	Driver model
ARM14SAK	ARD-KD2	ARM14SBK	ARD-KD2	ARM24SMK	ARD-KD2
ARM14SA0K		ARM14SB0K		ARM24SM0K	
ARM15SAK		ARM15SBK		ARM26SMK	
ARM15SA0K		ARM15SB0K		ARM26SM0K	
ARM24SAK		ARM24SBK		ARM46SMK	
ARM24SA0K		ARM24SB0K		ARM46SM0K	
ARM26SAK		ARM26SBK		ARM46MK	
ARM26SA0K		ARM26SB0K		ARM66SMK	
ARM46SAK		ARM46SBK		ARM66SM0K	
ARM46SA0K		ARM46SB0K		ARM66MK	
ARM46AK		ARM46BK		ARM69SMK	
ARM66SAK		ARM66SBK		ARM69SM0K	
ARM66SA0K		ARM66SB0K		ARM69MK	
ARM66AK		ARM66BK		ARM98SMK	
ARM69SAK		ARM69SBK		ARM98SM0K	
ARM69SA0K		ARM69SB0K		ARM98MK	
ARM69AK		ARM69BK			
ARM98SAK		ARM98SBK			
ARM98SA0K	ARM98SB0K				
ARM98AK	ARM98BK				

■ Geared type

- The box (●) in the model name indicates a number representing the gear ratio.
- The box (◆) in the model name indicates **U** (upward direction), **L** (left direction), or **R** (right direction) representing the cable outlet direction.
The box (◆) is blank when the cable outlet direction is downward.

Type of gear	Single shaft		With electromagnetic brake	
	Motor model	Driver model	Motor model	Driver model
TH geared	ARM24SAK-T●	ARD-KD2	ARM24SMK-T●	ARD-KD2
	ARM46SAK-T◆		ARM46SMK-T◆	
	ARM46AK-T◆		ARM46MK-T◆	
	ARM66SAK-T◆		ARM66SMK-T◆	
	ARM66AK-T◆		ARM66MK-T◆	
	ARM98SAK-T◆		ARM98SMK-T◆	
	ARM98AK-T◆		ARM98MK-T◆	
PS geared	ARM24SAK-PS●	ARD-KD2	—	—
	ARM46SAK-PS●		ARM46SMK-PS●	ARD-KD2
	ARM46AK-PS●		ARM46MK-PS●	
	ARM66SAK-PS●		ARM66SMK-PS●	
	ARM66AK-PS●		ARM66MK-PS●	
	ARM98SAK-PS●		ARM98SMK-PS●	
	ARM98AK-PS●		ARM98MK-PS●	


Type of gear	Single shaft		With electromagnetic brake	
	Motor model	Driver model	Motor model	Driver model
PN geared	ARM24SAK-N●	ARD-KD2	—	—
	ARM46SAK-N●		ARM46SMK-N●	ARD-KD2
	ARM46AK-N●		ARM46MK-N●	
	ARM66SAK-N●		ARM66SMK-N●	
	ARM66AK-N●		ARM66MK-N●	
	ARM98SAK-N●		ARM98SMK-N●	
	ARM98AK-N●		ARM98MK-N●	
Harmonic geared	ARM24SAK-H●	ARD-KD2	ARM24SMK-H●	ARD-KD2
	ARM46SAK-H●		ARM46SMK-H●	
	ARM46AK-H●		ARM46MK-H●	
	ARM66SAK-H●		ARM66SMK-H●	
	ARM66AK-H●		ARM66MK-H●	
	ARM98SAK-H●		ARM98SMK-H●	
	ARM98AK-H●		ARM98MK-H●	

2-5 Input/output power ratings


Motor model	Driver model	Input		Output current per phase
		Voltage	Current	
ARM14	ARD-KD2	24 VDC	0.4 A	0.43 A
ARM15			0.5 A	0.52 A
ARM24 ARM26			1.3 A	0.88 A
ARM46		24 VDC 48 VDC	1.8 A	1.48 A
ARM66			3.8 A	2.55 A
ARM69			3.7 A	
ARM98			3.1 A	

2-6 Names and functions of parts

■ Motor (Example: ARM66SMK)



■ Driver



Name	Description	Page
POWER LED (Green)	This LED is lit while the power is input.	–
ALARM LED (Red)	This LED will blink if an alarm generates (a protective function is triggered). It is possible to check the generated alarm by counting the number of times the LED blinks.	p.143
C-DAT LED (Green)	This LED blinks or is lit when the driver is communicating with the host controller properly via RS-485 communication.	–
C-ERR LED (Red)	This LED will be lit if a RS-485 communication error occurs with the host controller.	–
Address number setting switch (SW1)	This switch is used when controlling the system via RS-485 communication. Sets the address number of RS-485 communication using this switch and SW3-No.1 of the function setting switch. Factory setting: 0	p.213 p.214 p.260
Transmission rate setting switch (SW2)	This switch is used when controlling the system via RS-485 communication. Sets the transmission rate of RS-485 communication. Factory setting: 7	

Name	Description	Page
Function setting switch (SW3)	This switch is used when controlling the system via RS-485 communication. No.1: Sets the address number using this switch and the address number setting switch (SW1). Factory setting: OFF No.2: Sets the protocol of RS-485 communication. Factory setting: OFF No.3: Not used. No.4: Sets the termination resistor (120 Ω) of RS-485 communication. Factory setting: OFF	p.213 p.214 p.260
Electromagnetic brake terminals (CN1-MB1/MB2)	Connects the cable for electromagnetic brake. MB1: Electromagnetic brake – (black) MB2: Electromagnetic brake + (white)	p.68
Power supply input terminals (CN1)	Connects the driver power supply. +: +24 VDC/48 VDC power supply input –: Power supply GND	
Frame Ground Terminal (CN1)	Ground using a wire of AWG24 to 16 (0.2 to 1.25 mm ²).	p.68
Motor connector (CN2)	Connects the motor.	p.67
Data edit connector (CN3)	Connects a PC in which the MEXE02 has been installed, or the OPX-2A .	p.73
Sensor signal connector (CN5)	Connects the sensor signals.	p.69
RS-485 connectors (CN6/CN7)	Connects the RS-485 cable.	p.73
Input signal connector (CN8)	Connects the input signals.	p.69
Output signal connector (CN9)	Connects the output signals.	

3 Installation

This chapter explains the installation location and installation methods of the motor and driver, along with load installation.

3-1 Location for installation

The motor and driver are designed and manufactured to be incorporated in equipment. Install them in a well-ventilated location that provides easy access for inspection.

The location must also satisfy the following conditions:

- Inside an enclosure that is installed indoors (provide vent holes)
- Operating ambient temperature
 Motor: -10 to +50 °C (+14 to +122 °F) (non-freezing)
 Harmonic geared type: 0 to +40 °C (+32 to +104 °F) (non-freezing)
 Driver: 0 to +50 °C (+32 to +122 °F) (non-freezing)
- Operating ambient humidity 85 % or less (non-condensing)
- Area free of explosive atmosphere, toxic gas (such as sulfuric gas), or liquid
- Area not exposed to direct sun
- Area free of excessive amount of dust, iron particles or the like
- Area not subject to splashing water (rain, water droplets), oil (oil droplets) or other liquids
- Area free of excessive salt
- Area not subject to continuous vibrations or excessive shocks
- Area free of excessive electromagnetic noise (from welders, power machinery, etc.)
- Area free of radioactive materials, magnetic fields or vacuum
- 1,000 m (3,300 ft.) or lower above sea level


3-2 Installing the motor

The motor can be installed in any direction.


To allow for heat dissipation and prevent vibration, install the motor on a metal surface of sufficient strength.

Values of the tightening torque are recommended. Tighten the screws with a suitable torque according to the design conditions of the metal plate to be installed.

● **Installation method A**



● **Installation method B**



Type	Frame size [mm (in.)]	Screw size	Tightening torque [N·m (oz-in)]	Effective depth of screw thread [mm (in.)]	Installation method
Standard	20 (0.79)	M2	0.25 (35)	2.5 (0.098)	A
	28 (1.10)	M2.5	0.5 (71)	2.5 (0.098)	
	42 (1.65)	M3	1 (142)	4.5 (0.177)	
	60 (2.36)	M4	2 (280)	-	B
	85 (3.35)	M6	3 (420)		
TH geared	28 (1.10)	M2.5	0.5 (71)	4 (0.157)	A
	42 (1.65)	M4	2 (280)	8 (0.315)	
	60 (2.36)				
	90 (3.54)	M8	12 (1,700)	15 (0.591)	

Type	Frame size [mm (in.)]	Screw size	Tightening torque [N·m (oz-in)]	Effective depth of screw thread [mm (in.)]	Installation method
PS geared PN geared Harmonic geared *1	28 (1.10) 30 (1.18)	M3	1 (142)	6 (0.236)	A
	42 (1.65)	M4	2 (280)	8 (0.315)	
	60 (2.36)	M5	3 (420)	10 (0.394)	
	90 (3.54)	M8	12 (1,700)	15 (0.591)	
Harmonic geared *2	90 (3.54)	M8	15 (2,100)	—	B

*1 **ARM24**, **ARM46** and **ARM66** type only.

*2 **ARM98** type only.

3-3 Installing a load

This section describes how to install a load to the motor.
Flexible couplings are provided in Oriental Motor products.

Note

- When installing a load on the output shaft, pay attention to centering, belt tension, parallelism of pulleys, etc. Also, securely tighten the screws of a coupling or pulley.
- When installing a coupling or pulley on the output shaft, be careful not to damage to the output shaft or the bearing (ball bearings).
- Do not modify or machine the output shaft. Doing so may damage the bearing (ball bearings), resulting in damage to the motor.
- When removing the parallel key from the output shaft, be careful not to apply excessive force with a hammer or other tool. Doing so may damage the output shaft or bearing (ball bearings).

● Using a coupling

Align the axis of rotation for the output shaft and load in a straight line.


● Using a belt

- Align the axis of rotation for the output shaft and load parallel to each other.
- Make the axis of rotation for the output shaft and load perpendicular to a line connecting the centers of the two pulleys.


● Using a gear drive

- Align the output shaft and gear axis parallel to each other.
- Properly engage the centers of the gear tooth surfaces.


Using a coupling



Using a belt



Using a gear drive




● Using a key to fasten (geared motor)

When installing a load on the output shaft with a machined key slot, machine a key slot on the load side and secure the load and output shaft with the included key.

● **Harmonic geared type; Installing the load on the flange surface**

With a Harmonic geared type (excluding **ARM98**), a load can be installed directly to the gear using the load mounting screw holes provided on the flange surface.



Motor model	Screw size	Number of screw	Tightening torque [N·m (oz-in)]	Effective depth of screw thread [mm (in.)]
ARM24	M3	4	1.4 (198)	4 (0.157)
ARM46	M3	6	1.4 (198)	5 (0.197)
ARM66	M4	6	2.5 (350)	6 (0.236)



- When installing a load on the flange surface, the load cannot be mounted using the key slot in the output shaft.
- Design an appropriate installation layout so that the load will not contact the metal plate or screws used for installing the motor.

3-4 Permissible radial load and permissible axial load



- If the radial load or axial load exceeds the specified allowable value, repeated load applications may cause the bearing (ball bearings) or output shaft of the motor to undergo a fatigue failure.
- For the double shaft type, do not apply a load torque, radial load, or axial load to the rear shaft on the opposite side of the motor output shaft.



The permissible radial load and permissible axial load of the **PS** geared type and **PN** geared type represent the value that the service life of the gear part satisfies 20,000 hours when either of the radial load or axial load is applied to the gear output shaft.

Type	Motor model	Gear ratio	Permissible radial load [N (lb.)]					Permissible axial load [N (lb.)]
			Distance from the tip of output shaft [mm (in.)]					
			0 (0)	5 (0.2)	10 (0.39)	15 (0.59)	20 (0.79)	
Standard	ARM14 ARM15	-	12 (2.7)	15 (3.3)	-	-	-	3 (0.67)
	ARM24 ARM26		25 (5.6)	34 (7.6)	52 (11.7)	-	-	5 (1.12)
	ARM46		35 (7.8)	44 (9.9)	58 (13)	85 (19.1)	-	15 (3.3)
	ARM66 ARM69		90 (20)	100 (22)	130 (29)	180 (40)	270 (60)	30 (6.7)
	ARM98		260 (58)	290 (65)	340 (76)	390 (87)	480 (108)	60 (13.5)
TH geared	ARM24	All gear ratio	15 (3.3)	17 (3.8)	20 (4.5)	23 (5.1)	-	10 (2.2)
	ARM46		10 (2.2)	14 (3.1)	20 (4.5)	30 (6.7)	-	15 (3.3)
	ARM66		70 (15.7)	80 (18)	100 (22)	120 (27)	150 (33)	40 (9)
	ARM98		220 (49)	250 (56)	300 (67)	350 (78)	400 (90)	100 (22)
PS geared	ARM24	All gear ratio	45 (10.1)	60 (13.5)	80 (18)	100 (22)	-	40 (9)
	ARM46	5	70 (15.7)	80 (18)	95 (21)	120 (27)	-	100 (22)
		7.2	80 (18)	90 (20)	110 (24)	140 (31)	-	
		10	85 (19.1)	100 (22)	120 (27)	150 (33)	-	
		25	120 (27)	140 (31)	170 (38)	210 (47)	-	
		36	130 (29)	160 (36)	190 (42)	240 (54)	-	
50	150 (33)	170 (38)	210 (47)	260 (58)	-			

Type	Motor model	Gear ratio	Permissible radial load [N (lb.)]					Permissible axial load [N (lb.)]	
			Distance from the tip of output shaft [mm (in.)]						
			0 (0)	5 (0.2)	10 (0.39)	15 (0.59)	20 (0.79)		
PS geared	ARM66	5	170 (38)	200 (45)	230 (51)	270 (60)	320 (72)	200 (45)	
		7.2	200 (45)	220 (49)	260 (58)	310 (69)	370 (83)		
		10	220 (49)	250 (56)	290 (65)	350 (78)	410 (92)		
		25	300 (67)	340 (76)	400 (90)	470 (105)	560 (126)		
		36	340 (76)	380 (85)	450 (101)	530 (119)	630 (141)		
		50	380 (85)	430 (96)	500 (112)	600 (135)	700 (157)		
	ARM98	5	380 (85)	420 (94)	470 (105)	540 (121)	630 (141)	600 (135)	
		7.2	430 (96)	470 (105)	530 (119)	610 (137)	710 (159)		
		10	480 (108)	530 (119)	590 (132)	680 (153)	790 (177)		
		25	650 (146)	720 (162)	810 (182)	920 (200)	1,070 (240)		
		36	730 (164)	810 (182)	910 (200)	1,040 (230)	1,210 (270)		
		50	820 (184)	910 (200)	1,020 (220)	1,160 (260)	1,350 (300)		
PN geared	ARM24	All gear ratio	45 (10.1)	60 (13.5)	80 (18)	100 (22)	–	40 (9)	
	ARM46	5	80 (18)	95 (21)	120 (27)	160 (36)	–	100 (22)	
		7.2	90 (20)	110 (24)	130 (29)	180 (40)	–		
		10	100 (22)	120 (27)	150 (33)	200 (45)	–		
	ARM66	5	240 (54)	260 (58)	280 (63)	300 (67)	330 (74)	200 (45)	
		7.2	270 (60)	290 (65)	310 (69)	340 (76)	370 (83)		
		10	300 (67)	320 (72)	350 (78)	380 (85)	410 (92)		
		25	410 (92)	440 (99)	470 (105)	520 (117)	560 (126)		
		36	360 (81)	410 (92)	480 (108)	570 (128)	640 (144)		
		50	360 (81)	410 (92)	480 (108)	570 (128)	700 (157)		
	ARM98	5	370 (83)	390 (87)	410 (92)	430 (96)	460 (103)	600 (135)	
		7.2	410 (92)	440 (99)	460 (103)	490 (110)	520 (117)		
		10	460 (103)	490 (110)	520 (117)	550 (123)	580 (130)		
		25	630 (141)	660 (148)	700 (157)	740 (166)	790 (177)		
		36	710 (159)	750 (168)	790 (177)	840 (189)	900 (200)		
		50	790 (177)	840 (189)	890 (200)	940 (210)	1,000 (220)		
	Harmonic geared	ARM24	All gear ratio	100 (22)	135 (30)	175 (39)	250 (56)	–	140 (31)
		ARM46		180 (40)	220 (49)	270 (60)	360 (81)	510 (114)	220 (49)
ARM66		320 (72)		370 (83)	440 (99)	550 (123)	720 (162)	450 (101)	
ARM98		1,090 (240)		1,150 (250)	1,230 (270)	1,310 (290)	1,410 (310)	1,300 (290)	

■ **Permissible moment load of the Harmonic geared type**

If an eccentric load is applied on the flange surface when installing an arm or a table, do not exceed the permissible value shown in the table.

Motor model	Permissible moment load (N·m)
ARM24	2.9
ARM46	5.6
ARM66	11.6


Calculate the moment load using the International System of Units (N, N·m).

- **Example 1; When an external force F is applied on the position of distance L from the center of the output flange**

L: Distance from the center of the output flange (m)

F: External force (N)

Moment load: $M \text{ (N·m)} = F \times L$




- **Example 2; When external forces F is applied on the position of distance L from the mounting face of the output flange**

L: Distance from the mounting face of the output flange (m)

F: External force (N)

Moment load: $M \text{ (N·m)} = F \times (L + \text{coefficient "a"})$




Motor model	coefficient "a"
ARM24	0.0073
ARM46	0.009
ARM66	0.0114

3-5 Installing the driver


Mount the driver to a 35 mm (1.38 in.) width DIN rail.
 When installing two or more drivers in parallel, it is possible to install them closely in the horizontal direction. Provide a minimum clearance of 50 mm (1.97 in.) in the vertical direction.
 When installing three or more drivers closely, the heat generation of the inside drivers become high. Install the less frequently used drivers toward the inside. Use the "Overheat warning" parameter to check the inside temperature of the driver.

- memo**
- Do not install any equipment that generates a large amount of heat or noise near the driver.
 - Do not install the driver underneath the controller or other equipment vulnerable to heat.
 - If the ambient temperature of the driver exceeds 50 °C (122 °F), improve the ventilation condition.
 - Be sure to install the driver vertically (vertical position).




Unit: mm (in.)

1. Pull down the DIN lever of the driver and lock it. Hang the hook at the rear to the DIN rail.
2. Hold the driver to the DIN rail, and push up the DIN lever to secure.
3. Secure both sides of the driver using end plates.



Removing from DIN rail


Pull the DIN lever down until it locks using a slotted screwdriver, and lift the bottom of the driver to remove it from the rail.
 Use force of about 10 to 20 N (2.2 to 4.5 lb.) to pull the DIN lever to lock it.
 Excessive force may damage the DIN lever.



3 DC power input type

Dimension [unit: mm (in.)]

Mass: 0.15 kg (5.3 oz.)




3 DC power input type

4 Connection

This chapter explains how to connect the motor, I/O signals and power supply to the driver, as well as grounding method. The installation and wiring methods in compliance with the EMC Directive as well as protection against noise are also explained.

4-1 Connection example

The figure shows the electromagnetic brake type motor.



*1 Keep 30 m (98.4 ft.) or less for the wiring distance between the motor and driver.

*2 These cables are provided as our products. Purchase them separately.

Use the cable for motor when the length of the motor cable is not enough.

*3 If connector covers are attached on cables, cover the connected connectors using them.

Note

- Connect the connectors securely. Insecure connector connection may cause malfunction or damage to the motor or driver.
- When connecting/disconnecting the connector, turn off the power and wait for the POWER LED to turn off before doing so.
- When connecting, check the silk screen of the driver and pay attention to the polarity of the power supply. Reverse-polarity connection may cause damage to the driver. The power-supply circuit and the RS-485 communication circuit are not insulated. Therefore, when controlling multiple drivers via RS-485 communication, the reverse polarity of the power supply will cause a short circuit and may result in damage to the drivers.
- Do not wire the power supply cable of the driver in the same cable duct with other power lines or motor cables. Doing so may cause malfunction due to noise.
- The lead wires of the "cable for electromagnetic brake" have polarities, so connect them in the correct polarities. If the lead wires are connected with their polarities reversed, the electromagnetic brake will not operate properly.

memo

- When disconnecting the connector, pull out while pressing the latches on the connector with fingers.
- When installing the motor on a moving part, use our flexible cable. Refer to p.77 for the model name.

● **Cable size and tightening torque**

Connector	Terminal symbol	Recommended cable size	Screw size	Tightening torque [N·m (oz·in)]
CN1	24/48V+ 24/48V-	Stranded wire AWG24 to 16 (0.2 to 1.25 mm ²)	M2	0.22 to 0.25 (31 to 35)
	MB1, MB2	Stranded wire AWG20 (0.5 mm ²)		
CN5	-	Stranded wire AWG26 to 20 (0.14 to 0.5 mm ²)	-	-
CN8	-	Stranded wire AWG26 to 20 (0.14 to 0.5 mm ²)	-	-
CN9	-	Stranded wire AWG26 to 20 (0.14 to 0.5 mm ²)	-	-


4-2 Grounding the motor and the driver

■ **Grounding the motor**

Ground the functional earth terminal (M4) if necessary.

■ **Grounding the driver**

Ground the Frame Ground Terminal (CN1) as necessary. Use a grounding wire of AWG24 to 16 (0.2 to 1.25 mm²), and do not share the Frame Ground Terminal with a welder or any other power equipment.




4-3 Connecting the power supply and electromagnetic brake

Use the CN1 connector (5 pins) to connect the power supply and electromagnetic brake


■ **Connecting method**

1. Strip the insulation cover of the lead wire (AWG24 to 16: 0.2 to 1.25 mm²) by 7 mm (0.28 in.)
2. Insert each lead wire into the CN1 connector and tighten the screw with a slotted screwdriver.
Connector screw size: M2
Tightening torque: 0.22 to 0.25 N·m (31 to 35 oz·in)
3. Insert the CN1 connector into the CN1, and tighten the screw.
Connector screw size: M2.5
Tightening torque: 0.4 N·m (56 oz·in)



Pin assignment

Pin No.	Signal name	Description
1	MB1	Electromagnetic brake - (Black)
2	MB2	Electromagnetic brake + (White)
3	+	24 VDC/48 VDC power supply input
4	-	Power supply ground
5	FG	Frame ground



■ Power supply current capacity

The current capacity of the power supply varies depending on the product to be combined. Check the current capacity in reference to the equipped motor model when using the **EAS Series**, **EAC Series**, or **EZS Series**.

Model	Input power supply voltage	Power supply current capacity	
		Without electromagnetic brake	With electromagnetic brake
ARM14	24 VDC±5 % *	0.4 A or more	–
ARM15		0.5 A or more	–
ARM24, ARM26		1.25 A or more	1.3 A or more
ARM46	24 VDC±5 % * 48 VDC±5 %	1.72 A or more	1.8 A or more
ARM66		3.55 A or more	3.8 A or more
ARM69		3.45 A or more	3.7 A or more
ARM98		2.85 A or more	3.1 A or more
DGM60	24 VDC±5 %	1.25 A or more	–


* Use a power supply of 24 VDC ±4 % when extending the wiring distance between an electromagnetic brake motor and a driver to 20 m (65.6 ft.) to 30 m (98.4 ft.).

3 DC power input type

4-4 Connecting the I/O signals

■ Wiring method


- Applicable lead wire: AWG26 to 20 (0.14 to 0.5 mm²)
 - Stripping length of wire insulation: 8 mm (0.31 in.)
1. Strip the insulation cover of the lead wire.
 2. Insert the lead wire while pushing the button of the orange color on the connector with a slotted screwdriver.
 3. After having inserted, release the button to secure the lead wire.



■ Pin assignment


● Sensor signals (CN5)

Pin No.	Signal name	Description
1	+LS	Limit sensor input +
2	-LS	Limit sensor input -
3	HOMES	Mechanical home sensor input
4	SLIT	Slit sensor input
5	IN-COM2	Sensor signals common



● Input signals (CN8)


Pin No.	Signal name	Description *
1	IN0	Control input 0 (HOME)
2	IN1	Control input 1 (START)
3	IN2	Control input 2 (M0)
4	IN3	Control input 3 (M1)
5	IN4	Control input 4 (M2)
6	IN5	Control input 5 (FREE)
7	IN6	Control input 6 (STOP)
8	IN7	Control input 7 (ALM-RST)
9	IN-COM1	Input signals common



* (): Initial value


● Output signals (CN9)

Pin No.	Signal name	Description *
1	OUT0	Control output 0 (HOME-P)
2	OUT1	Control output 1 (END)
3	OUT2	Control output 2 (AREA1)
4	OUT3	Control output 3 (READY)
5	OUT4	Control output 4 (WNG)
6	OUT5	Control output 5 (ALM)
7	OUT-COM	Output signals common



* (): Initial value

■ Connection example with a current sink output circuit (NPN specifications)




3 DC power input type



- Use input signals at 24 VDC.
- Use output signals at 12 to 24 VDC 10 mA or less. If the current exceeds 10 mA, connect an external resistor R0 so that the current becomes 10 mA or less.
- The saturated voltage of the output signal is 3 VDC maximum.


■ Connection example with a current source output circuit (PNP specifications)



- Use input signals at 24 VDC.
- Use output signals at 12 to 24 VDC 10 mA or less. If the current exceeds 10 mA, connect an external resistor R0 so that the current becomes 10 mA or less.
- The saturated voltage of the output signal is 3 VDC maximum.

4-5 Connecting the data setter

Connect the communication cable for the support software or **OPX-2A** cable to the data edit connector (CN3) on the driver.




CAUTION


The power supply connector (CN1), data edit connector (CN3), and RS-485 connectors (CN6/CN7) of the driver are not insulated. When grounding the positive terminal of the power supply, do not connect any equipment (PC, etc.) whose negative terminal is grounded. Doing so may cause the driver and these equipment to short, damaging both.

4-6 Connecting the RS-485 cable

Connect this cable if you want to control your product via RS-485 communication. Connect the RS-485 cable to CN6 or CN7 on the driver. You can use the vacant connectors to connect a different driver. A driver link cable is also available in our products. Refer to p.79 for the model name. You can also use a commercial LAN cable (straight cable) to link drivers.




Internal input circuit



* The GND line is used in common with CN1 (not insulated).

CN6/CN7 pin assignment

Pin No.	Signal name	Description
1	N.C.	Not used.
2	GND	GND
3	TR+	RS-485 communication signal (+)
4	N.C.	Not used.
5	N.C.	
6	TR-	RS-485 communication signal (-)
7	N.C.	Not used.
8	N.C.	



3 DC power input type

4-7 Noise elimination measures

The electrical noise is of two types: One is a noise to invade into the driver from the outside and cause the driver malfunction, and the other is a noise to emit from the driver and cause peripheral equipments malfunction. For the noise that is invaded from the outside, take measures to prevent the driver malfunction. It is needed to take adequate measures because signal lines are very likely to be affected by the noise. For the noise that is emitted from the driver, take measures to suppress it.

■ Measures against electrical noise


There are the following three methods mainly to take measures against the electrical noise.

● Noise suppression

- When relays or electromagnetic switches are used together with the system, use noise filters and CR circuits to suppress surges generated by them.
- Use our connection cable or extension cable when extending a wiring distance between the motor and driver. Refer to p.77 for the model name.
- Cover the driver by a metal plate such as aluminum. This is effective in shielding the electrical noise emitted from the driver.

● Prevention of noise propagation

- Connect a noise filter in the power supply cable of driver.
- Place the power lines, such as the motor and power supply cables, keeping a distance of 200 mm (7.87 in.) or more from the signal lines, and also do not bundle them or wire them in parallel. If the power cables and signal cables have to cross, cross them at a right angle.
- Use shielded twisted pair cables for power lines and signal lines.
- Keep cables as short as possible without coiling and bundling extra lengths.
- Grounding multiple points will increase effect to block electrical noise because impedance on the grounding points is decreased. However, ground them so that a potential difference does not occur among the grounding points. I/O signal cables that include a ground wire are provided in our product line. Refer to p.80 for the model name.
- To ground a shielded cable, use a metal cable clamp that will maintain contact with the entire circumference of the cable. Ground the cable clamp near the product.



● Suppression of effect by noise propagation

Loop the noise propagated cable around a ferrite core. Doing so will prevent the propagated noise invades into the driver or emits from the driver. The frequency band in which an effect by the ferrite core can be seen is generally 1 MHz or more. Check the frequency characteristics of the ferrite core used. To increase the effect of noise attenuation by the ferrite core, loop the cable a lot.

■ Noise suppression products

● Noise filter

- Connect the following noise filter (or equivalent) to the DC power line. When using a power supply transformer, be sure to connect a noise filter to the AC input side of the power supply transformer. Doing so will prevent the propagated noise through the power line. Install the noise filter as close to the driver as possible.

Manufacture	Model
SOSHIN ELECTRIC CO., LTD.	HF2010A-UPF
Schaffner EMC	FN2070-10-06

- Use the AWG18 (0.75 mm²) or thicker wire for the input and output cables of the noise filter, and secure firmly using a cable clamp or others so that the cable does not come off the enclosure.
- Place the input cable as far apart as possible from the output cable, and do not wire the cables in parallel. If the input and output cable are placed at a close distance or if they are wired in parallel, the noise inside the enclosure affects the power cable through stray capacitance, and the noise suppressing effect will reduce.
- Connect the ground terminal of the noise filter to the grounding point, using as thick and short a wire as possible.
- When connecting a noise filter inside an enclosure, wire the input cable of the noise filter as short as possible. Wiring in long distance may reduce the noise suppressing effect.

■ Our noise suppression products

Refer to p.80 and p.81 for the model name.

● I/O signal cable

This cable is a shielded twisted pair cable for good noise immunity to connect the driver and host controller. The ground wires useful to grounding are provided at both ends of the cable. The EMC testing is conducted using the Oriental Motor I/O signal cable.

● Surge suppressor

This product is effective to suppress the surge which occurs in a relay contact part. Connect it when using a relay or electromagnetic switch. CR circuit for surge suppression and CR circuit module are provided.

4-8 Conformity to the EMC Directive

Effective measures must be taken against the EMI that the motor and driver may give to adjacent control-system equipment, as well as the EMS of the motor and driver itself, in order to prevent a serious functional impediment in the machinery. The use of the following installation and wiring methods will enable the motor and driver to be compliant with the EMC Directive.

Oriental Motor conducts EMC testing on its motors and drivers in accordance with "Example of installation and wiring" on p.76.

The user is responsible for ensuring the machine's compliance with the EMC Directive, based on the installation and wiring explained below.

CAUTION

This equipment is not intended for use in residential environments nor for use on a low-voltage public network supplied in residential premises, and it may not provide adequate protection to radio reception interference in such environments.

● Connecting noise filter

In large electrically noisy environments, connect a noise filter. Refer to "Noise filter" in the above.

● Connecting the power supply

Use a DC power supply that conforms to the EMC Directive.

Use a shielded twisted pair cable for wiring. Refer to "Prevention of noise propagation" on p.74 for wiring method.

● Connecting the motor cable

Use our connection cable or extension cable when extending the wiring distance between the motor and driver. Refer to p.77 for the model name.


● Connecting the signal cable

Refer to "Prevention of noise propagation" on p.74.

● How to ground

- The cable used to ground the motor, driver and noise filter must be as thick and short as possible so that no potential difference is generated.
- Choose a large, thick and uniformly conductive surface for the grounding point.
- Refer to p.68 for grounding method.

● Example of installation and wiring



Note The driver uses parts that are sensitive to electrostatic charge. Take measures against static electricity since static electricity may cause the driver to malfunction or suffer damage.

5 Cables




When installing the motor on a moving part, use a flexible cable.

5-1 Connection cable set

Use when connecting a motor and a driver.

The cable set for electromagnetic brake motors consists of two cables, one for motor and the other for electromagnetic brake.



*1 Only when the motor is of electromagnetic brake type.

*2 A connector cover may be attached depending on the specification.

● Connection cable set model


Length [m (ft.)]	For standard type motor		For electromagnetic brake type motor	
	Without connector cover	With connector cover	Without connector cover	With connector cover
0.5 (1.6)	CC005VA2F2	–	CC005VA2FB2	–
1 (3.3)	CC010VA2F2	CC010VAF2	CC010VA2FB2	CC010VAFB2
1.5 (4.9)	CC015VA2F2	–	CC015VA2FB2	–
2 (6.6)	CC020VA2F2	CC020VAF2	CC020VA2FB2	CC020VAFB2
2.5 (8.2)	CC025VA2F2	–	CC025VA2FB2	–
3 (9.8)	CC030VA2F2	CC030VAF2	CC030VA2FB2	CC030VAFB2
4 (13.1)	CC040VA2F2	–	CC040VA2FB2	–
5 (16.4)	CC050VA2F2	CC050VAF2	CC050VA2FB2	CC050VAFB2
7 (23)	CC070VA2F2	CC070VAF2	CC070VA2FB2	CC070VAFB2
10 (32.8)	CC100VA2F2	CC100VAF2	CC100VA2FB2	CC100VAFB2
15 (49.2)	CC150VA2F2	CC150VAF2	CC150VA2FB2	CC150VAFB2
20 (65.6)	CC200VA2F2	CC200VAF2	CC200VA2FB2	CC200VAFB2
30 (98.4)	CC300VA2F2	CC300VAF2	CC300VA2FB2	CC300VAFB2

● Flexible connection cable set model

Length [m (ft.)]	For standard type motor		For electromagnetic brake type motor	
	Without connector cover	With connector cover	Without connector cover	With connector cover
0.5 (1.6)	CC005VA2R2	–	CC005VA2RB2	–
1 (3.3)	CC010VA2R2	CC010VAR2	CC010VA2RB2	CC010VARB2
1.5 (4.9)	CC015VA2R2	–	CC015VA2RB2	–
2 (6.6)	CC020VA2R2	CC020VAR2	CC020VA2RB2	CC020VARB2
2.5 (8.2)	CC025VA2R2	–	CC025VA2RB2	–
3 (9.8)	CC030VA2R2	CC030VAR2	CC030VA2RB2	CC030VARB2
4 (13.1)	CC040VA2R2	–	CC040VA2RB2	–
5 (16.4)	CC050VA2R2	CC050VAR2	CC050VA2RB2	CC050VARB2
7 (23)	CC070VA2R2	CC070VAR2	CC070VA2RB2	CC070VARB2
10 (32.8)	CC100VA2R2	CC100VAR2	CC100VA2RB2	CC100VARB2
15 (49.2)	CC150VA2R2	CC150VAR2	CC150VA2RB2	CC150VARB2
20 (65.6)	CC200VA2R2	CC200VAR2	CC200VA2RB2	CC200VARB2
30 (98.4)	CC300VA2R2	CC300VAR2	CC300VA2RB2	CC300VARB2

5-2 Extension cable set

Use when extending the distance between a motor and a driver or when the length of the connection cable used is not enough. Extend the distance by connecting the extension cable to the connection cable. The cable set for electromagnetic brake motors consists of two cables, one for motor and the other for electromagnetic brake.



- *1 Use the connection cable used.
- *2 Only when the motor is of electromagnetic brake type.
- *3 A connector cover may be attached depending on the specification.

memo When extending the wiring length by connecting an extension cable to the connection cable, keep the total cable length to 30 m (98.4 ft.) or less.

- Extension cable set model

Length [m (ft.)]	For standard type motor		For electromagnetic brake type motor	
	Without connector cover	With connector cover	Without connector cover	With connector cover
0.5 (1.6)	CC005VA2F2	–	CC005VA2FBT2	–
1 (3.3)	CC010VA2F2	CC010VAFT2	CC010VA2FBT2	CC010VAFBT2
1.5 (4.9)	CC015VA2F2	–	CC015VA2FBT2	–
2 (6.6)	CC020VA2F2	CC020VAFT2	CC020VA2FBT2	CC020VAFBT2
2.5 (8.2)	CC025VA2F2	–	CC025VA2FBT2	–
3 (9.8)	CC030VA2F2	CC030VAFT2	CC030VA2FBT2	CC030VAFBT2
4 (13.1)	CC040VA2F2	–	CC040VA2FBT2	–
5 (16.4)	CC050VA2F2	CC050VAFT2	CC050VA2FBT2	CC050VAFBT2
7 (23)	CC070VA2F2	CC070VAFT2	CC070VA2FBT2	CC070VAFBT2
10 (32.8)	CC100VA2F2	CC100VAFT2	CC100VA2FBT2	CC100VAFBT2
15 (49.2)	CC150VA2F2	CC150VAFT2	CC150VA2FBT2	CC150VAFBT2
20 (65.6)	CC200VA2F2	CC200VAFT2	CC200VA2FBT2	CC200VAFBT2

- Flexible extension cable set model

Length [m (ft.)]	For standard type motor		For electromagnetic brake type motor	
	Without connector cover	With connector cover	Without connector cover	With connector cover
0.5 (1.6)	CC005VA2R2	–	CC005VA2RBT2	–
1 (3.3)	CC010VA2R2	CC010VART2	CC010VA2RBT2	CC010VARBT2
1.5 (4.9)	CC015VA2R2	–	CC015VA2RBT2	–
2 (6.6)	CC020VA2R2	CC020VART2	CC020VA2RBT2	CC020VARBT2
2.5 (8.2)	CC025VA2R2	–	CC025VA2RBT2	–
3 (9.8)	CC030VA2R2	CC030VART2	CC030VA2RBT2	CC030VARBT2
4 (13.1)	CC040VA2R2	–	CC040VA2RBT2	–
5 (16.4)	CC050VA2R2	CC050VART2	CC050VA2RBT2	CC050VARBT2
7 (23)	CC070VA2R2	CC070VART2	CC070VA2RBT2	CC070VARBT2
10 (32.8)	CC100VA2R2	CC100VART2	CC100VA2RBT2	CC100VARBT2
15 (49.2)	CC150VA2R2	CC150VART2	CC150VA2RBT2	CC150VARBT2
20 (65.6)	CC200VA2R2	CC200VART2	CC200VA2RBT2	CC200VARBT2

5-3 Communication cable for the support software

Be sure to purchase the communication cable for the support software when connecting a driver and PC in which the support software **MEXE02** has been installed.

This is a set of a PC interface cable and USB cable. The cable is connected to the USB port on the PC.

The **MEXE02** can be downloaded from Oriental Motor Website Download Page.

Model: **CC05IF-USB** [5 m (16.4 ft.)]

5-4 RS-485 cable

You can link drivers using this cable connected to the RS-485 connectors (CN6, CN7).

Model: **CC001-RS4** [0.1 m (0.3 ft.)]

CC002-RS4 [0.25 m (0.8 ft.)]

5-5 I/O signal cable

A shielded cable for driver control I/O signals offering excellent noise resistance. The ground wires useful to grounding are provided at both ends of the cable.

Select the cable suitable for the number of I/O signals connected.

General-purpose type

Cable length [m (ft.)]	Number of lead wire			
	6 pcs.	10 pcs.	12 pcs.	16 pcs.
0.5 (1.6)	CC06D005B-1	CC10D005B-1	CC12D005B-1	CC16D005B-1
1 (3.3)	CC06D010B-1	CC10D010B-1	CC12D010B-1	CC16D010B-1
1.5 (4.9)	CC06D015B-1	CC10D015B-1	CC12D015B-1	CC16D015B-1
2 (6.6)	CC06D020B-1	CC10D020B-1	CC12D020B-1	CC16D020B-1

6 Accessories

6-1 Setting tools

■ Data setter

The data setter lets you set operation data and parameters for your **AR** Series with ease and also functions as a monitor.

Model: **OPX-2A**

6-2 Wiring support tools

■ CR circuit for surge suppression

This product is effective to suppress the surge which occurs in a relay contact part. Use it to protect the contacts of the relay or switch.

Model: **EPCR1201-2**

■ CR circuit module

This product is effective to suppress the surge which occurs in a relay contact part. Use this product to protect the contacts of the relay or switch.

Four pieces of CR circuit for surge suppression are mounted on the compact circuit, and this product can be installed to the DIN rail. This product can make the wiring easily and securely since it also supports terminal block connection.

Model: **VCS02**

3 DC power input type

4 AC power input type/ DC power input type Common

This part explains common contents to the AR Series AC power input type and DC power input type.

◆ Table of contents

1	Explanation of I/O signals	84			
1-1	Assignment of direct I/O	84	3-5	Screen transitions	124
1-2	Assignment of remote I/O	88	3-6	Monitor mode	128
1-3	Input signals	92	3-7	Data mode	129
1-4	Output signals	98	3-8	Parameter mode	132
1-5	Sensor inputs	103	3-9	Test mode	139
1-6	General signals (R0 to R15)	104	3-10	Copy mode	141
2	Method of control via I/O	105	4	Inspection and maintenance	142
2-1	Guidance	105	4-1	Inspection	142
2-2	Operation data	109	4-2	Warranty	142
2-3	Parameter	110	4-3	Disposal	142
3	Operation using the OPX-2A	121	5	Alarms and warnings	143
3-1	Overview of the OPX-2A	121	5-1	Alarms	143
3-2	Names and functions of parts	122	5-2	Warning	150
3-3	How to read the display	122	5-3	Communication errors	151
3-4	OPX-2A error display	123	6	Troubleshooting and remedial actions	152

1 Explanation of I/O signals

In this manual, I/O signals are described as follows.

- Direct I/O: I/O signals accessed via input signal connector (CN8) and output signal connector (CN9)
- Remote I/O: I/O signals accessed via RS-485 communication

Set the following parameters using the **MEXE02**, **OPX-2A** or RS-485 communication.

1-1 Assignment of direct I/O

■ Assignment to the input terminals

The input signals shown below can be assigned to the input terminals IN0 to IN7 of CN8 by setting parameters. For details on input signals, refer to p.92.

Direct I/O signal name	Initial value
IN0	3: HOME
IN1	4: START
IN2	48: M0
IN3	49: M1

Direct I/O signal name	Initial value
IN4	50: M2
IN5	16: FREE
IN6	18: STOP
IN7	24: ALM-RST

Assignment No.	Signal name	Function
0	No function	Set when the input terminal is not used.
1	FWD	Execute continuous operation in the positive direction.
2	RVS	Execute continuous operation in the negative direction.
3	HOME	Execute return-to-home operation.
4	START	Execute positioning operation.
5	SSTART	Execute sequential positioning operation.
6	+JOG	Execute JOG operation in the positive direction.
7	-JOG	Execute JOG operation in the negative direction.
8	MS0	Execute direct positioning operation.
9	MS1	
10	MS2	
11	MS3	
12	MS4	
13	MS5	
16	FREE	Stop the motor excitation and release the electromagnetic brake.
17	C-ON	Switch the motor excitation between excitation and non-excitation.
18	STOP	Stop of the motor operation.
24	ALM-RST	Reset the current alarm.
25	P-PRESET	Execute position preset.
26	P-CLR	This cannot be used.
27	HMI	Release of the function limitation of the MEXE02 or OPX-2A .
32	R0	General signals. Use these signals when controlling the system via RS-485 communication.
33	R1	
34	R2	
35	R3	
36	R4	
37	R5	
38	R6	

Assignment No.	Signal name	Function
39	R7	General signals. Use these signals when controlling the system via RS-485 communication.
40	R8	
41	R9	
42	R10	
43	R11	
44	R12	
45	R13	
46	R14	
47	R15	
48	M0	
49	M1	
50	M2	
51	M3	
52	M4	
53	M5	

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O function [Input]	IN0 input function selection	Assigns the following input signals to IN0 to IN7 of the input terminals. [Setting range] Refer to the following table.	3: HOME
	IN1 input function selection		4: START
	IN2 input function selection		48: M0
	IN3 input function selection		49: M1
	IN4 input function selection		50: M2
	IN5 input function selection		16: FREE
	IN6 input function selection		18: STOP
	IN7 input function selection		24: ALM-RST

0: No function	8: MS0	18: STOP	35: R3	43: R11	51: M3
1: FWD	9: MS1	24: ALM-RST	36: R4	44: R12	52: M4
2: RVS	10: MS2	25: P-PRESET	37: R5	45: R13	53: M5
3: HOME	11: MS3	26: P-CLR*	38: R6	46: R14	
4: START	12: MS4	27: HMI	39: R7	47: R15	
5: SSTART	13: MS5	32: R0	40: R8	48: M0	
6: +JOG	16: FREE	33: R1	41: R9	49: M1	
7: -JOG	17: C-ON	34: R2	42: R10	50: M2	

* It cannot be used.



- Do not assign the same input signal to multiple input terminals. When the same input signal is assigned to multiple input terminals, the function will be executed if any of the terminals becomes active.
- The ALM-RST input will be executed when turning from ON to OFF. The P-PRESET input will be executed when turning from OFF to ON.
- When the C-ON input and HMI input are not assigned to the input terminals, these inputs will always be set to ON. When assigning to both direct I/O and remote I/O, the function will be executed when both of them are set to ON.

■ Changing the logic level setting of input signals

You can change the logic level setting for input terminals IN0 to IN7 using the parameter.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O function [Input]	IN0 input logic level setting	Changes the logic level setting for input terminals IN0 to IN7. [Setting range] 0: Make (N.O.) 1: Brake (N.C.)	0
	IN1 input logic level setting		
	IN2 input logic level setting		
	IN3 input logic level setting		
	IN4 input logic level setting		
	IN5 input logic level setting		
	IN6 input logic level setting		
	IN7 input logic level setting		

■ Assignment to the output terminals

The output signals shown below can be assigned to the output terminals OUT0 to OUT5 of CN9 by setting parameters. For details on output signals, refer to p.98.

Direct I/O signal name	Initial value	Direct I/O signal name	Initial value
OUT0	70: HOME-P	OUT3	67: READY
OUT1	69: END	OUT4	66: WNG
OUT2	73: AREA1	OUT5	65: ALM

Assignment No.	Signal name	Function
0	No function	Set when the output terminal is not used.
1	FWD_R	Output in response to the FWD input.
2	RVS_R	Output in response to the RVS input.
3	HOME_R	Output in response to the HOME input.
4	START_R	Output in response to the START input.
5	SSTART_R	Output in response to the SSTART input.
6	+JOG_R	Output in response to the +JOG input.
7	-JOG_R	Output in response to the -JOG input.
8	MS0_R	Output in response to the MS0 to MS5 input.
9	MS1_R	
10	MS2_R	
11	MS3_R	
12	MS4_R	
13	MS5_R	
16	FREE_R	Output in response to the FREE input.
17	C-ON_R	Output in response to the C-ON input.
18	STOP_R	Output in response to the STOP input.
32	R0	Output the status of the general signal R0 to R9.
33	R1	
34	R2	
35	R3	
36	R4	
37	R5	
38	R6	
39	R7	
40	R8	
41	R9	

Assignment No.	Signal name	Function
42	R10	Output the status of the general signal R10 to R15.
43	R11	
44	R12	
45	R13	
46	R14	
47	R15	Output in response to the M0 to M5 input.
48	M0_R	
49	M1_R	
50	M2_R	
51	M3_R	
52	M4_R	Output in response to the +LS input.
53	M5_R	
60	+LS_R	
61	-LS_R	
62	HOMES_R	
63	SLIT_R	Output in response to the SLIT input.
65	ALM	Output the alarm status of the driver (normally closed).
66	WNG	Output the warning status of the driver.
67	READY	Output when the driver is ready.
68	MOVE	Output when the motor operates.
69	END	Output when the positioning operation is completed.
70	HOME-P	Output when the motor is in home.
71	TLC	Output when the load is outside of the motor torque range.
72	TIM	Output once every 7.2° rotation of the motor output shaft.
73	AREA1	Output when the motor is within the area 1.
74	AREA2	Output when the motor is within the area 2.
75	AREA3	Output when the motor is within the area 3.
80	S-BSY	Output when the driver is in internal processing state.
82	MPS *	Output the ON-OFF state of the main power supply.

* AC power input only

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O function [Output]	OUT0 output function selection	Assigns the following output signals to OUT0 to OUT5 of the output terminals. [Setting range] Refer to the following table.	70: HOME-P
	OUT1 output function selection		69: END
	OUT2 output function selection		73: AREA1
	OUT3 output function selection		67: READY
	OUT4 output function selection		66: WNG
	OUT5 output function selection		65: ALM

0: No function	10: MS2_R	35: R3	45: R13	61: -LS_R	72: TIM
1: FWD_R	11: MS3_R	36: R4	46: R14	62: HOMES_R	73: AREA1
2: RVS_R	12: MS4_R	37: R5	47: R15	63: SLIT_R	74: AREA2
3: HOME_R	13: MS5_R	38: R6	48: M0_R	65: ALM	75: AREA3
4: START_R	16: FREE_R	39: R7	49: M1_R	66: WNG	80: S-BSY
5: SSTART_R	17: C-ON_R	40: R8	50: M2_R	67: READY	82: MPS *
6: +JOG_R	18: STOP_R	41: R9	51: M3_R	68: MOVE	
7: -JOG_R	32: R0	42: R10	52: M4_R	69: END	
8: MS0_R	33: R1	43: R11	53: M5_R	70: HOME-P	
9: MS1_R	34: R2	44: R12	60: +LS_R	71: TLC	

* AC power input only

1-2 Assignment of remote I/O

Assign the I/O function via RS-485 communication.

■ Assignment of input signals

The input signals shown below can be assigned to the NET-IN0 to NET-IN15 of the remote I/O by setting parameters. Refer to each command description for the assignment of the NET-IN0 to NET-IN15.

Assignment No.	Signal name	Function	Setting range
0	No function	Set when the input terminal is not used.	—
1	FWD	Execute continuous operation in the positive direction.	0: Deceleration stop 1: Operation
2	RVS	Execute continuous operation in the negative direction.	
3	HOME	Execute return-to-home operation.	0: No operation 1: Start operation
4	START	Execute positioning operation.	
5	SSTART	Execute sequential positioning operation.	
6	+JOG	Execute JOG operation in the positive direction.	
7	−JOG	Execute JOG operation in the negative direction.	
8	MS0	Execute direct positioning operation of the operation data No. set by the I/O parameter.	
9	MS1		
10	MS2		
11	MS3		
12	MS4		
13	MS5		
16	FREE	Stop the motor excitation and release the electromagnetic brake.	0: No operation 1: Electromagnetic brake release+motor non-excitation
17	C-ON	Switch the motor excitation between excitation and non-excitation.	0: Motor non-excitation 1: Motor excitation
18	STOP	Stop of the motor operation.	0: No operation 1: Stop operation
24	ALM-RST	Reset the current alarm.	0: No operation 1: Reset alarm
25	P-PRESET	Execute position preset.	0: No operation 1: Execute preset
26	P-CLR	This cannot be used.	—
27	HMI	Release of the function limitation of the MEXE02 or OPX-2A	0: Function limitation 1: Function limitation release
32	R0	General signals. Use these signals when controlling the system via RS-485 communication.	0: OFF 1: ON
33	R1		
34	R2		
35	R3		
36	R4		
37	R5		
38	R6		
39	R7		
40	R8		
41	R9		
42	R10		

Assignment No.	Signal name	Function	Setting range
43	R11	General signals. Use these signals when controlling the system via RS-485 communication.	0: OFF 1: ON
44	R12		
45	R13		
46	R14		
47	R15		
48	M0	Select the operation data No. using these six bits. Refer to p.93 for details on the combination.	0: OFF 1: ON (Operation data No.0 to 63 can be selected.)
49	M1		
50	M2		
51	M3		
52	M4		
53	M5		

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O function [RS-485]	NET-IN0 input function selection	Assigns the following input signals to NET-IN0 to NET-IN15. [Setting range] Refer to the following table.	48: M0
	NET-IN1 input function selection		49: M1
	NET-IN2 input function selection		50: M2
	NET-IN3 input function selection		4: START
	NET-IN4 input function selection		3: HOME
	NET-IN5 input function selection		18: STOP
	NET-IN6 input function selection		16: FREE
	NET-IN7 input function selection		0: No function
	NET-IN8 input function selection		8: MS0
	NET-IN9 input function selection		9: MS1
	NET-IN10 input function selection		10: MS2
	NET-IN11 input function selection		5: SSTART
	NET-IN12 input function selection		6: +JOG
	NET-IN13 input function selection		7: -JOG
	NET-IN14 input function selection		1: FWD
NET-IN15 input function selection	2: RVS		

0: No function	7: -JOG	16: FREE	32: R0	39: R7	46: R14
1: FWD	8: MS0	17: C-ON	33: R1	40: R8	47: R15
2: RVS	9: MS1	18: STOP	34: R2	41: R9	48: M0
3: HOME	10: MS2	24: ALM-RST	35: R3	42: R10	49: M1
4: START	11: MS3	25: P-PRESET	36: R4	43: R11	50: M2
5: SSTART	12: MS4	26: P-CLR *	37: R5	44: R12	51: M3
6: +JOG	13: MS5	27: HMI	38: R6	45: R13	52: M4
					53: M5

* It cannot be used.



- Do not assign the same input signal to multiple input terminals. When the same input signal is assigned to multiple input terminals, the function will be executed if any of the terminals becomes active.
- The ALM-RST input will be executed when turning from ON to OFF.
The P-PRESET input will be executed when turning from OFF to ON.
- When the C-ON input and HMI input are not assigned to the input terminals, these inputs will always be set to ON. When assigning to both direct I/O and remote I/O, the function will be executed when both of them are set to ON.

■ Assignment to the output terminals

The output signals shown below can be assigned to the NET-OUT0 to NET-OUT15 of the remote I/O by setting parameters. Refer to each command description for the assignment of the NET-OUT0 to NET-OUT15.

Assignment No.	Signal name	Function	Data read
0	No function	Set when the output terminal is not used.	–
1	FWD_R	Output in response to the FWD input.	0: OFF 1: ON
2	RVS_R	Output in response to the RVS input.	
3	HOME_R	Output in response to the HOME input.	
4	START_R	Output in response to the START input.	
5	SSTART_R	Output in response to the SSTART input.	
6	+JOG_R	Output in response to the +JOG input.	
7	–JOG_R	Output in response to the –JOG input.	
8	MS0_R	Output in response to the MS0 input.	
9	MS1_R	Output in response to the MS1 input.	
10	MS2_R	Output in response to the MS2 input.	
11	MS3_R	Output in response to the MS3 input.	
12	MS4_R	Output in response to the MS4 input.	
13	MS5_R	Output in response to the MS5 input.	
16	FREE_R	Output in response to the FREE input.	
17	C-ON_R	Output in response to the C-ON input.	
18	STOP_R	Output in response to the STOP input.	
32	R0	Output the status of the general signal R0 to R15.	
33	R1		
34	R2		
35	R3		
36	R4		
37	R5		
38	R6		
39	R7		
40	R8		
41	R9		
42	R10		
43	R11		
44	R12		
45	R13		
46	R14		
47	R15		
48	M0_R	Output in response to the M0 to M5 input.	
49	M1_R		
50	M2_R		
51	M3_R		
52	M4_R		
53	M5_R		
60	+LS_R	Output in response to the +LS input.	
61	–LS_R	Output in response to the –LS input.	
62	HOMES_R	Output in response to the HOMES input.	
63	SLIT_R	Output in response to the SLIT input.	
65	ALM	Output the alarm status of the driver (normally open).	0: Alarm not present 1: Alarm present

4 AC power input type/DC power input type Common

Assignment No.	Signal name	Function	Data read
66	WNG	Output the warning status of the driver.	0: Warning not present 1: Warning present
67	READY	Output when the driver is ready.	0: Not ready 1: Ready
68	MOVE	Output when the motor operates.	0: Motor stopped 1: Motor operating
69	END	Output when the positioning operation is completed.	0: Motor operating 1: Motor operating completion
70	HOME-P	Output when the motor is in home.	0: Not home 1: Home
71	TLC	Output when the load is outside of the motor torque range.	0: Inside torque range 1: Outside torque range
72	TIM	Output once every 7.2° rotation of the motor output shaft.	0: OFF 1: ON
73	AREA1	Output when the motor is within the area 1.	0: Outside area 1: Inside area
74	AREA2	Output when the motor is within the area 2.	
75	AREA3	Output when the motor is within the area 3.	
80	S-BSY	Output when the driver is in internal processing state.	0: OFF 1: ON
82	MPS *	Output the ON-OFF state of the main power supply.	

* AC power input only

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O function [RS-485]	NET-OUT0 output function selection	Assigns the following output signals to NET-OUT0 to NET-OUT15. [Setting range] Refer to the following table.	48: M0_R
	NET-OUT1 output function selection		49: M1_R
	NET-OUT2 output function selection		50: M2_R
	NET-OUT3 output function selection		4: START_R
	NET-OUT4 output function selection		70: HOME-P
	NET-OUT5 output function selection		67: READY
	NET-OUT6 output function selection		66: WNG
	NET-OUT7 output function selection		65: ALM
	NET-OUT8 output function selection		80: S-BSY
	NET-OUT9 output function selection		73: AREA1
	NET-OUT10 output function selection		74: AREA2
	NET-OUT11 output function selection		75: AREA3
	NET-OUT12 output function selection		72: TIM
	NET-OUT13 output function selection		68: MOVE
	NET-OUT14 output function selection		69: END
NET-OUT15 output function selection	71: TLC		

0: No function	10: MS2_R	35: R3	45: R13	61: -LS_R	72: TIM
1: FWD_R	11: MS3_R	36: R4	46: R14	62: HOMES_R	73: AREA1
2: RVS_R	12: MS4_R	37: R5	47: R15	63: SLIT_R	74: AREA2
3: HOME_R	13: MS5_R	38: R6	48: M0_R	65: ALM	75: AREA3
4: START_R	16: FREE_R	39: R7	49: M1_R	66: WNG	80: S-BSY
5: SSTART_R	17: C-ON_R	40: R8	50: M2_R	67: READY	82: MPS *
6: +JOG_R	18: STOP_R	41: R9	51: M3_R	68: MOVE	
7: -JOG_R	32: R0	42: R10	52: M4_R	69: END	
8: MS0_R	33: R1	43: R11	53: M5_R	70: HOME-P	
9: MS1_R	34: R2	44: R12	60: +LS_R	71: TLC	

* AC power input only


4 AC power input type/DC power input type Common

1-3 Input signals

All input signals of the driver are photocoupler inputs.

- Direct I/O I/O for normally open: "ON: Current-carrying", "OFF: Not current-carrying"
I/O for normally closed: "ON: Not current-carrying", "OFF: Current-carrying"
- Remote I/O..... "ON: 1", "OFF: 0"

■ Internal input circuit



■ M0 to M5 inputs

Select a desired operation data number for positioning operation or continuous operation based on the combination of ON/OFF states of the M0 to M5 inputs.

Operation data No.	M5	M4	M3	M2	M1	M0	Operation data No.	M5	M4	M3	M2	M1	M0
0	OFF	OFF	OFF	OFF	OFF	OFF	32	ON	OFF	OFF	OFF	OFF	OFF
1	OFF	OFF	OFF	OFF	OFF	ON	33	ON	OFF	OFF	OFF	OFF	ON
2	OFF	OFF	OFF	OFF	ON	OFF	34	ON	OFF	OFF	OFF	ON	OFF
3	OFF	OFF	OFF	OFF	ON	ON	35	ON	OFF	OFF	OFF	ON	ON
4	OFF	OFF	OFF	ON	OFF	OFF	36	ON	OFF	OFF	ON	OFF	OFF
5	OFF	OFF	OFF	ON	OFF	ON	37	ON	OFF	OFF	ON	OFF	ON
6	OFF	OFF	OFF	ON	ON	OFF	38	ON	OFF	OFF	ON	ON	OFF
7	OFF	OFF	OFF	ON	ON	ON	39	ON	OFF	OFF	ON	ON	ON
8	OFF	OFF	ON	OFF	OFF	OFF	40	ON	OFF	ON	OFF	OFF	OFF
9	OFF	OFF	ON	OFF	OFF	ON	41	ON	OFF	ON	OFF	OFF	ON
10	OFF	OFF	ON	OFF	ON	OFF	42	ON	OFF	ON	OFF	ON	OFF
11	OFF	OFF	ON	OFF	ON	ON	43	ON	OFF	ON	OFF	ON	ON
12	OFF	OFF	ON	ON	OFF	OFF	44	ON	OFF	ON	ON	OFF	OFF
13	OFF	OFF	ON	ON	OFF	ON	45	ON	OFF	ON	ON	OFF	ON
14	OFF	OFF	ON	ON	ON	OFF	46	ON	OFF	ON	ON	ON	OFF
15	OFF	OFF	ON	ON	ON	ON	47	ON	OFF	ON	ON	ON	ON
16	OFF	ON	OFF	OFF	OFF	OFF	48	ON	ON	OFF	OFF	OFF	OFF
17	OFF	ON	OFF	OFF	OFF	ON	49	ON	ON	OFF	OFF	OFF	ON
18	OFF	ON	OFF	OFF	ON	OFF	50	ON	ON	OFF	OFF	ON	OFF
19	OFF	ON	OFF	OFF	ON	ON	51	ON	ON	OFF	OFF	ON	ON
20	OFF	ON	OFF	ON	OFF	OFF	52	ON	ON	OFF	ON	OFF	OFF
21	OFF	ON	OFF	ON	OFF	ON	53	ON	ON	OFF	ON	OFF	ON
22	OFF	ON	OFF	ON	ON	OFF	54	ON	ON	OFF	ON	ON	OFF
23	OFF	ON	OFF	ON	ON	ON	55	ON	ON	OFF	ON	ON	ON
24	OFF	ON	ON	OFF	OFF	OFF	56	ON	ON	ON	OFF	OFF	OFF
25	OFF	ON	ON	OFF	OFF	ON	57	ON	ON	ON	OFF	OFF	ON
26	OFF	ON	ON	OFF	ON	OFF	58	ON	ON	ON	OFF	ON	OFF
27	OFF	ON	ON	OFF	ON	ON	59	ON	ON	ON	OFF	ON	ON
28	OFF	ON	ON	ON	OFF	OFF	60	ON	ON	ON	ON	OFF	OFF
29	OFF	ON	ON	ON	OFF	ON	61	ON	ON	ON	ON	OFF	ON
30	OFF	ON	ON	ON	ON	OFF	62	ON	ON	ON	ON	ON	OFF
31	OFF	ON	ON	ON	ON	ON	63	ON	ON	ON	ON	ON	ON

■ START input

This signal starts the positioning operation.

Select the operation data No. and turn the START input to ON to start positioning operation.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Alarm	Return-to-home incomplete alarm	When the positioning operation is started while the position origin has not been set, selects whether the alarm generates or not. [Setting range] 0: Disable 1: Enable	0

■ SSTART input

This signal starts the sequential positioning operation. (p.169)

Positioning operation based on the next operation data No. will be performed every time the SSTART input turns ON. This function is useful when multiple positioning operations must be performed sequentially, because there is no need to repeatedly select each operation data No.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Alarm	Return-to-home incomplete alarm	When the positioning operation is started while the position origin has not been set, selects whether the alarm generates or not. [Setting range] 0: Disable 1: Enable	0

■ MS0 to MS5 input

This signal starts the direct positioning operation. (p.168)

When any of the MS0 to MS5 inputs is turned ON, the positioning operation corresponding to the input data No. will be performed. Since the positioning operation is enabled by turning any of the MS0 to MS5 inputs ON, you can save the steps of selecting the operation data No.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Alarm	Return-to-home incomplete alarm	When the positioning operation is started while the position origin has not been set, selects whether the alarm generates or not. [Setting range] 0: Disable 1: Enable	0
I/O	MS0 operation No. selection	Sets operation data No. corresponding to MS0 to MS5 input. [Setting range] Operation data No.0 to 63	0
	MS1 operation No. selection		1
	MS2 operation No. selection		2
	MS3 operation No. selection		3
	MS4 operation No. selection		4
	MS5 operation No. selection		5

■ HOME input

This signal starts the return-to-home operation. (p.179)

Turn the HOME input ON to start return-to-home operation. When the return-to-home operation is completed and the motor stops, the HOME-P output turns ON.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Home operation	Home-seeking mode	Sets the mode for return-to-home operation. [Setting range] 0: 2-sensor mode 1: 3-sensor mode 2: Push mode	1
	Operating speed of home-seeking	Sets the operating speed for return-to-home operation. [Setting range] 1 to 1,000,000 Hz	1,000

MEXE02 tree view	Parameter name	Description	Initial value
Home operation	Acceleration/ deceleration of home- seeking	Sets the acceleration/deceleration rate (acceleration/deceleration time) for return-to- home operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s)	1,000
	Starting speed of home- seeking	Sets the starting speed for return-to-home operation. [Setting range] 1 to 1,000,000 Hz	500
	Position offset of home-seeking	Sets the amount of offset from mechanical home. [Setting range] -8,388,608 to 8,388,607 step	0
	Starting direction of home-seeking	Sets the starting direction for home detection. [Setting range] 0: Negative direction 1: Positive direction	1
	SLIT detection with home-seeking	Sets whether or not to concurrently use the SLIT input for return-to-home operation. [Setting range] 0: Disable 1: Enable	0
	TIM signal detection with home-seeking	Sets whether or not to concurrently use the TIM signal for return-to-home operation. [Setting range] 0: Disable 1: Enable	0
	Operating current of home-seeking with push-motion	Sets the operating current, based on the rated current being 100 %, for push-motion return-to- home operation. [Setting range] 0 to 1,000 (1=0.1 %)	1,000

■ FWD input, RVS input

These signals start the continuous operation. (p.188)

Operation is performed based on the FWD or RVS input and the operating speed corresponding to the selected operation data No.

Turn the FWD signal to ON, to perform continuous operation in the positive direction.

Turn the RVS signal to ON, to perform continuous operation in the negative direction.

If the signal of the same direction is turned ON again during deceleration, the motor will accelerate and continue operating.

If the FWD and RVS inputs are turned ON simultaneously, the motor will decelerate to a stop.

When the operation data No. is changed during continuous operation, the speed will change to the one specified for the new operation data No.

■ +JOG input, –JOG input

These signals start the JOG operation. (p.193)

Turn the +JOG signal to ON, to perform JOG operation in the positive direction.

Turn the –JOG signal to ON, to perform JOG operation in the negative direction.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Operation	JOG travel amount	Sets the travel amount for JOG operation. [Setting range] 1 to 8,388,607 step	1
	JOG operating speed	Sets the operating speed for JOG operation. [Setting range] 1 to 1,000,000 Hz	1,000
	Acceleration/ deceleration rate of JOG	Sets the acceleration/deceleration rate (acceleration/deceleration time) for JOG operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s)	1,000
	JOG starting speed	Sets the starting speed for JOG operation. [Setting range] 0 to 1,000,000 Hz	500

■ STOP input

When the STOP input turns ON, the motor will stop.

When the STOP input turns ON while a positioning operation is being performed, the balance of the travel amount will be cleared. Refer to p.196 for stop action.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	STOP input action	Sets how the motor should stop when a STOP input is turned ON. [Setting range] 0: Immediate stop 1: Deceleration stop 2: Immediate stop & Current OFF 3: Deceleration stop & Current OFF	1

■ C-ON input

This signal is used to excite the motor.

The motor will be excited when the C-ON input is ON, while the motor will become non-excitation status when the C-ON input is OFF.

When an electromagnetic brake motor is used, the electromagnetic brake will be released after the motor is excited.

memo When the C-ON input is not assigned to the direct I/O or remote I/O, this input will always be set to ON. When assigning to both direct I/O and remote I/O, the function will be executed when both of them are set to ON.

■ FREE input

When the FREE input is turned ON, the motor current will be cut off. The motor will lose its holding torque, and the output shaft can be turned manually. When an electromagnetic brake motor is used, the electromagnetic brake will also be released.

Note Do not turn the FREE input ON when driving a vertical load. Since the motor loses its holding torque, the load may drop.

Relations among the status of the FREE input, the C-ON input and the output shaft are shown in the tables.

Motor without an electromagnetic brake

C-ON input FREE input	OFF	ON
OFF	Output shaft is in a released state	Output shaft is in a holding state by motor excitation
ON	Output shaft is in a released state	Output shaft is in a released state

Motor with an electromagnetic brake

C-ON input FREE input	OFF	ON
OFF	Output shaft is in a holding state by electromagnetic brake	Output shaft is in a holding state by motor excitation
ON	Output shaft is in a released state	Output shaft is in a released state

■ P-PRESET input

This is a signal for the command position preset.

When the P-PRESET input is turned ON, the command position is set as the value of the "Preset position" parameter.

(This signal will become effective when turning from OFF to ON.)

However, the preset will not execute in the following conditions.

- When an alarm is present.
- When the motor is operating.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Coordinates	Preset position	Sets the preset position. [Setting range] -8,388,608 to 8,388,607 step	0

■ ALM-RST input

When an alarm generates, the motor will stop. When the ALM-RST input is turned from ON to OFF, the alarm will be reset. (The alarm will be reset at the OFF edge of the ALM-RST input.) Always reset an alarm after removing the cause of the alarm and after ensuring safety.

Note that some alarms cannot be reset with the ALM-RST input. Refer to p.143 for alarm descriptions.


■ HMI input

When the HMI input is turned ON, the function limitation of the **MEXE02** or **OPX-2A** will be released.

When the HMI input is turned OFF, the function limitation will be imposed.

The following functions will be limited to execute.

- I/O test
- Test operation
- Teaching
- Parameters setting, writing, downloading, initializing
- Data setting, clearing, initializing


 When the HMI input is not assigned to the input terminal, this input will always be set to ON. When assigning to both direct I/O and remote I/O, the function will be executed when both of them are set to ON.

1-4 Output signals

The output signals of the driver are photocoupler/open-collector output.

- Direct I/O I/O for normally open: "ON: Current-carrying", "OFF: Not current-carrying"
I/O for normally closed: "ON: Not current-carrying", "OFF: Current-carrying"
- Remote I/O..... "ON: 1", "OFF: 0"

Internal output circuit



ALM output

Refer to p.143 for alarm descriptions.

- **Direct I/O**
When an alarm generates, the ALM output will turn OFF. At the same time, the ALM LED (or ALARM LED) of the driver will blink and the motor current will be cut off and stop. The ALM output is normally closed.
- **Remote I/O**
When an alarm generates, the ALM output will turn ON. At the same time, the ALM LED (or ALARM LED) of the driver will blink and the motor current will be cut off and stop. The ALM output is normally open.
- **Related parameter**

MEXE02 tree view	Parameter name	Description	Initial value
Alarm	Overload alarm	Sets the condition that an overload alarm generates. [Setting range] 1 to 300 (1=0.1 s)	50
	Excessive position deviation alarm at current ON	Sets the condition that an excessive position deviation alarm generates when the motor is in a state of current ON. [Setting range] 1 to 30,000 (1=0.01 rev)	300
	Return-to-home incomplete alarm	When the positioning operation is started while the position origin has not been set, selects whether the alarm generates or not. [Setting range] 0: Disable 1: Enable	0

MEXE02 tree view	Parameter name	Description	Initial value
Alarm	Excessive position deviation alarm at current OFF	Sets the condition that an excessive position deviation alarm generates when the motor is in a state of current OFF. If the position deviation exceeds the setting value in the "Excessive position deviation alarm at current ON" parameter, the excessive position deviation warning at current OFF generates. In addition, if the C-ON input is turned ON, the excessive position deviation alarm at current OFF generates. [Setting range] 1 to 30,000 (1=0.01 rev)	10,000
Communication	Communication timeout	Sets the condition in which a communication timeout occurs in RS-485 communication. It is not monitored when the set value is 0. [Setting range] 0: Not monitored 1 to 10,000 ms	0
	Communication error alarm	Sets the condition in which a RS-485 communication error alarm generates. A communication error alarm generates after a RS-485 communication error has occurred by the number of times set here. [Setting range] 1 to 10 times	3

■ WNG output

When a warning generates, the WNG output turns ON. Refer to p.150 for warning descriptions.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Warning	Overheat warning	Sets the condition that a main circuit overheat warning generates. [Setting range] 40 to 85 °C	85
	Overload warning	Sets the condition that an overload warning generates. [Setting range] 1 to 300 (1=0.1 s)	50
	Overspeed warning	Sets the condition that an overspeed warning generates. [Setting range] 1 to 5,000 r/min	4,500
	Overvoltage warning	Sets the condition that an overvoltage warning generates. [Setting range] AC power input: 120 to 450 V DC power input: 150 to 630 V (1=0.1 V)	AC power input: 435 DC power input: 630
	Undervoltage warning	Sets the condition that an undervoltage warning generates. [Setting range] AC power input: 120 to 280 V DC power input: 150 to 630 V (1=0.1 V)	AC power input: 120 DC power input: 180
	Excessive position deviation warning at current ON	Sets the condition that an excessive position deviation warning generates when the motor is in a state of current ON. [Setting range] 1 to 30,000 (1=0.01 rev)	300

■ READY output

When the driver becomes ready, the READY output turns ON. Input operating commands to the driver after the READY output has turned ON.

The READY output turns ON when all of the following conditions are satisfied.

- The driver main power supply is turned ON.
- All inputs which start operation are OFF
- The FREE input is OFF
- The C-ON input is ON (When the C-ON input is assigned)
- The STOP input is OFF
- An alarm is not present.
- The motor is not operating.
- Test function, downloading or teaching function was not performed using the **MEXE02**.
- Test operation, downloading, initializing or teaching function was not performed using the **OPX-2A**.
- Configuration commands, all data initialization commands and batch non-volatile memory read commands are not executed via RS-485 communication.

■ HOME-P output

The HOME-P output turns ON corresponding to the setting of the "HOME-P output function selection" parameter. Refer to p.198 for setting the position origin.

● When "HOME-P output function selection" parameter is set to "Home output"

When the command position of the driver is in the home while the MOVE output is OFF, the HOME-P output will turn ON. However, the HOME-P output remains OFF when the position origin for the driver has not been set.

● When "HOME-P output function selection" parameter is set to "Return-to-home complete output"

Regardless of the command position by the driver, if the position origin for the driver is set, the HOME-P output will turn ON. Therefore, it turns ON after completing the return-to-home operation or preset.

Once the HOME-P output turns ON, it will not turn OFF until the motor has moved from the position origin.

● Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	HOME-P output function selection	Sets the timing to output the HOME-P output. [Setting range] 0: Home output 1: Return-to-home complete output	0

■ MOVE output

The MOVE output turns ON while the motor is operating.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	Minimum ON time for MOVE output	Sets the minimum ON time for MOVE output. [Setting range] 0 to 255 ms	0

■ END output

When the motor has completed its movement, the END output will turn ON. When the motor was converged in a position of the "END signal range" parameter against the command position while the MOVE output is in an OFF status, the END output turns ON.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	END signal range	Sets the output range of the END signal (the motor operation converges within this angular range). [Setting range] 0 to 180 (1=0.1°)	18
	Positioning complete output offset	Sets the offset for the END signal (the offset for converging angular range). [Setting range] -18 to 18 (1=0.1°)	0

■ TLC output

When the load exceeds the motor torque range, the TLC output will turn ON.
When performing push-motion operation, if the load exceeds the torque range calculated from the current ratio of push-motion operation, the TLC output will turn ON.
This output can be used for the completion signal of the push-motion operation.

■ AREA1 to AREA3 outputs


The AREA output turns ON when the motor is inside the area set by the parameters.
It turns ON when the motor is inside the area even when the motor stops.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	AREA1 positive direction position	Sets the AREA1 to AREA3 positive direction position. [Setting range] -8,388,608 to 8,388,607 step	0
	AREA2 positive direction position		
	AREA3 positive direction position		
	AREA1 negative direction position	Sets the AREA1 to AREA3 negative direction position. [Setting range] -8,388,608 to 8,388,607 step	0
	AREA2 negative direction position		
	AREA3 negative direction position		


● When the "AREA positive direction position" parameter < "AREA negative direction position" parameter

To turn the AREA output ON:
Motor position ≤ AREA positive direction position, or
Motor position ≥ AREA negative direction position



● When the "AREA positive direction position" parameter > "AREA negative direction position" parameter

To turn the AREA output ON:
AREA negative direction position ≤ Motor position ≤ AREA positive direction position



4 AC power input type/DC power input type Common

● **When the "AREA positive direction position" parameter = "AREA negative direction position" parameter**

To turn the AREA output ON:


Motor position = AREA negative direction position = AREA positive direction position

memo When using AREA1 to AREA3 output to confirm the motor position, you can use two types - the command position and the actual position.
 AREA1 and AREA2: Command position
 AREA3: Actual position

■ **TIM output**

The TIM output will turn ON every time the motor output shaft rotates by 7.2°.

If the command speed is faster than 30 r/min, TIM output will not be output correctly.



memo The TIM output is a signal that is output for 50 times per revolution of the motor output shaft. When the TIM output is used, set the resolution to be an integral multiple of 50 using the "Electronic gear" parameters.

■ **S-BSY output**

The S-BSY output turns ON while internal processing of the driver is being executed.

In the following condition, the driver will be in an internal processing status.

- Issuing maintenance commands via RS-485 communication

■ **MPS output (AC power input only)**

The MPS output turns ON when the driver main power is ON.

■ **Response output**

The response output is the output signal that shows the ON/OFF status corresponding to the input signals.


The tables show the correspondence between the input signals and output signals.

Input signal	Output signal	Input signal	Output signal	Input signal	Output signal
FWD	FWD_R	MS2	MS2_R	M2	M2_R
RVS	RVS_R	MS3	MS3_R	M3	M3_R
HOME	HOME_R	MS4	MS4_R	M4	M4_R
START	START_R	MS5	MS5_R	M5	M5_R
SSTART	SSTART_R	FREE	FREE_R	+LS	+LS_R
+JOG	+JOG_R	C-ON	C-ON_R	-LS	-LS_R
-JOG	-JOG_R	STOP	STOP_R	HOMES	HOMES_R
MS0	MS0_R	M0	M0_R	SLIT	SLIT_R
MS1	MS1_R	M1	M1_R		

memo The response output is the output signal to return the status of the input signal. Therefore, the output signals corresponding to the input signals for motor operation (START_R output etc.) do not show the movement of the motor itself.

1-5 Sensor inputs

Internal input circuit



+LS input, -LS input

These signals are input from the applicable limit sensors. The +LS input is for the positive direction sensor and the -LS input is for the negative direction sensor.

- Return-to-home operationWhen the +LS or -LS input is detected, perform the return-to-home operation according to the setting of the "Home-seeking mode" parameter.
- Any other operationDetect the hardware overtravel and stop the motor. Refer to p.196 for hardware overtravel.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	Hardware overtravel	Sets whether to enable or disable hardware overtravel detection using \pm LS inputs. [Setting range] 0: Disable 1: Enable	1
	Overtravel action	Sets the motor stop action to take place upon the occurrence of overtravel. [Setting range] 0: Immediate stop 1: Decelerate stop	0
	LS contact configuration	Sets the \pm LS input logics. [Setting range] 0: Make (N.O.) 1: Brake (N.C.)	0

HOMES input

The HOMES input is the input for the mechanical home sensor when setting the "Home-seeking mode" parameter to the "3-sensor mode." Refer to p.179 for return-to-home operation.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	HOMES logic level	Sets the HOMES input logic. [Setting range] 0: Make (N.O.) 1: Brake (N.C.)	0

4 AC power input type/DC power input type Common

■ **SLIT input**

Connect the SLIT input when using motorized linear slides equipped with a slit. When detecting the home, use of the SLIT input in addition to the HOMES will increase the accuracy of home detection. Refer to p.179 for return-to-home operation.


Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	SLIT logic level	Sets the SLIT input logic. [Setting range] 0: Make (N.O.) 1: Brake (N.C.)	0

1-6 General signals (R0 to R15)

R0 to R15 are general signals that enable control via RS-485 communication. Using R0 to R15, I/O signals for the external device can be controlled by the host controller via the driver. The direct I/O of the driver can be used as an I/O unit. Refer to the following example for setting of the general signals.

- **When outputting the signals from the host controller to the external device**
Assign the general signal R0 to the OUT0 output and NET-IN0. When setting the NET-IN0 to 1, the OUT0 output turns ON. When setting the NET-IN0 to 0, the OUT0 output turns OFF.
- **When inputting the output of the external device to the host controller**
Assign the general signal R1 to the IN7 input and NET-OUT15. When turning the IN7 input ON by the external device, the NET-OUT15 becomes 1. When turning the IN7 input OFF, the NET-OUT15 becomes 0. The logic level of the IN7 input can be set using "IN7 input logic level setting" parameter.



* The figure shows the AC power input.

2 Method of control via I/O


2-1 Guidance

If you are new to the **AR Series FLEX** built-in controller type, read this section to understand the operating methods along with the operation flow.


Note Before operating the motor, check the condition of the surrounding area to ensure safety.

■ AC power input

STEP 1 Check the installation and connection




STEP 2 Turn on the power and set the operation data



4 AC power input type/DC power input type Common

STEP 3 Operate the motor

2. Check the motor rotates according to the setting.



STEP 4 Were you able to operate the motor properly?


How did it go? Were you able to operate the motor properly? If the motor does not function, check the following points:

- Are the regeneration resistor thermal input terminals (TH1 and TH2) on the CN1 short-circuited?
- Is any alarm present?
- Are the power supply and motor connected securely?


For more detailed settings and functions, refer to "5 Operation type and setting" on p.153.

■ DC power input

STEP 1 Check the installation and connection




STEP 2 Turn on the power and set the operation data



4 AC power input type/DC power input type Common

STEP 3 Operate the motor



STEP 4 Were you able to operate the motor properly?

How did it go? Were you able to operate the motor properly? If the motor does not function, check the following points:

- Is any alarm present?
- Are the power supply and motor connected securely?

For more detailed settings and functions, refer to "5 Operation type and setting" on p.153.

2-2 Operation data

Up to 64 operation data can be set (data Nos.0 to 63).

If the data is changed, a recalculation and setup will be performed after the operation is stopped.

Data	Description	Initial value
Position No.0 to Position No.63	Sets the position (distance) for positioning operation. [Setting range] –8,388,608 to +8,388,607 step	0
Operating speed No.0 to Operating speed No.63	Sets the operating speed in positioning operation and continuous operation. [Setting range] 0 to 1,000,000 Hz	1,000
Operation mode No.0 to Operation mode No.63	Selects how to specify the position (travel amount) in positioning operation. [Setting range] 0: Incremental (INC) 1: Absolute (ABS)	0
Operation function No.0 to Operation function No.63	Sets the operation mode to execute positioning operation. [Setting range] 0: Single-motion 1: Linked-motion 2: Linked-motion 2 3: Push	0
Acceleration No.0 to Acceleration No.63	Sets the acceleration rate (acceleration time) in positioning operation and continuous operation. *1 [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *2	1,000
Deceleration No.0 to Deceleration No.63	Sets the deceleration rate (deceleration time) in positioning operation and continuous operation. *1 [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *2	1,000
Push current No.0 to Push current No.63	Sets the current rate of push-motion operation. [Setting range] 0 to 1,000 (1=0.1 %)	200
Sequential positioning No.0 to Sequential positioning No.63	Sets whether to enable or disable sequential positioning operation. [Setting range] 0: Disable 1: Enable	0
Dwell time No.0 to Dwell time No.63	Sets the dwell time to be used in linked-motion 2 operation. [Setting range] 0 to 50,000 (1=0.001 s)	0

*1 This item is effective when the "Acceleration/deceleration type" parameter is set to "Separate." If this parameter is set to "Common," the values of the "Common acceleration" and "Common deceleration" parameters will be used (initial value: separate).

*2 Acceleration/deceleration rate (ms/kHz) or acceleration/deceleration time (s) can be selected using "Acceleration/deceleration unit" parameter (initial value: ms/kHz).

2-3 Parameter

■ Timing for parameter to update

The parameters are saved in the RAM or non-volatile memory. The data saved in the RAM will be erased once the DC power supply is turned off. On the other hand, the parameters saved in the non-volatile memory will be retained even after the DC power supply is turned off.

When turning the driver DC power supply on, the parameters saved in the non-volatile memory will be sent to the RAM. Then, the recalculation and setup for the parameters are executed in the RAM.

Parameters having set via RS-485 communication or industrial network are saved in the RAM. To save the parameters stored in the RAM to the non-volatile memory, execute the "Batch non-volatile memory write" of the maintenance command.

The parameters set with the **MEXE02** will be saved in the non-volatile memory if "data writing" is performed.

When a parameter is changed, the timing to update the new value varies depending on the parameter. Refer to the following four types.

- memo**
- Parameters set via RS-485 communication or industrial network are saved in the RAM. If parameters, which are required turning on the power again in order to update, are changed, be sure to save them in the non-volatile memory before turning off the power.
 - The non-volatile memory can be rewritten approximately 100,000 times.

■ Notation rules

In this chapter, each update timing is represented in an alphabet.

Notation	Update timing
A	Recalculation and setup are immediately executed when the parameter is written.
B	Recalculation and setup are executed when the operation is stopped.
C	Recalculation and setup are executed after Configuration is executed or the DC power supply is turned on again.
D	Recalculation and setup are executed after the DC power supply is turned on again.

■ Parameter list

I/O parameter (p.112)	<ul style="list-style-type: none"> STOP input action Hardware overtravel Overtravel action END signal range Positioning complete output offset AREA1 positive direction position AREA1 negative direction position AREA2 positive direction position AREA2 negative direction position AREA3 positive direction position AREA3 negative direction position 	<ul style="list-style-type: none"> Minimum ON time for MOVE output LS contact configuration HOMES logic level SLIT logic level MS0 operation No. selection MS1 operation No. selection MS2 operation No. selection MS3 operation No. selection MS4 operation No. selection MS5 operation No. selection HOME-P output function selection
Motor parameter (p.113)	<ul style="list-style-type: none"> RUN current STOP current Position loop gain Speed loop gain Speed loop integral time constant Speed filter 	<ul style="list-style-type: none"> Moving average time Filter selection Speed difference gain 1 Speed difference gain 2 Control mode Smooth drive

Operation parameter (p.114)	<ul style="list-style-type: none"> • Common acceleration • Common deceleration • Starting speed • JOG operating speed • Acceleration/deceleration rate of JOG • JOG starting speed • Acceleration/deceleration type 	<ul style="list-style-type: none"> • Acceleration/deceleration unit • Automatic return operation • Operation speed of automatic return • Acceleration (deceleration) of automatic return • Starting speed of automatic return • JOG travel amount
Home operation parameter (p.115)	<ul style="list-style-type: none"> • Home-seeking mode • Operating speed of home-seeking • Acceleration/deceleration of home-seeking • Starting speed of home-seeking • Position offset of home-seeking 	<ul style="list-style-type: none"> • Starting direction of home-seeking • SLIT detection with home-seeking • TIM signal detection with home-seeking • Operating current of home-seeking with push-motion
Alarm parameter (p.116)	<ul style="list-style-type: none"> • Overload alarm • Excessive position deviation alarm at current ON 	<ul style="list-style-type: none"> • Return-to-home incomplete alarm • Excessive position deviation alarm at current OFF
Warning parameter (p.116)	<ul style="list-style-type: none"> • Overheat warning • Overload warning • Overspeed warning 	<ul style="list-style-type: none"> • Overvoltage warning • Undervoltage warning • Excessive position deviation warning at current ON
Coordinates parameter (p.117)	<ul style="list-style-type: none"> • Electronic gear A • Electronic gear B • Motor rotation direction • Software overtravel 	<ul style="list-style-type: none"> • Positive software limit • Negative software limit • Preset position • Wrap setting • Wrap setting range
Common parameter (p.117)	<ul style="list-style-type: none"> • Data setter speed display 	<ul style="list-style-type: none"> • Data setter edit
I/O function [input] parameter (p.118)	<ul style="list-style-type: none"> • IN0 to IN7 input function selection • IN0 to IN7 input logic level setting 	
I/O function [output] parameter (p.118)	<ul style="list-style-type: none"> • OUT0 to OUT5 output function selection 	
I/O function [RS-485] parameter (p.119)	<ul style="list-style-type: none"> • NET-IN0 to NET-IN15 input function selection • NET-OUT0 to NET-OUT15 output function selection 	
Communication parameter (p.120)	<ul style="list-style-type: none"> • Communication timeout • Communication error alarm • Communication parity 	<ul style="list-style-type: none"> • Communication stop bit • Transmission waiting time

■ I/O parameter

Parameter name	Description	Initial value	Update
STOP input action	Sets how the motor should stop when a STOP input is turned ON. [Setting range] 0: Immediate stop 1: Decelerate stop 2: Immediate stop & Current OFF 3: Deceleration stop & Current OFF	1	A
Hardware overtravel	Sets whether to enable or disable hardware overtravel detection using \pm LS inputs. [Setting range] 0: Disable 1: Enable	1	A
Overtravel action	Sets the motor stop action to take place upon the occurrence of overtravel. [Setting range] 0: Immediate stop 1: Decelerate stop	0	A
END signal range	Sets the output range of the END signal (the motor operation converges within this angular range). [Setting range] 0 to 180 (1=0.1°)	18	A
Positioning complete output offset	Sets the offset for the END signal (the offset for converging angular range). [Setting range] -18 to 18 (1=0.1°)	0	A
AREA1 positive direction position	Sets the AREA1 to AREA3 positive direction position. [Setting range] -8,388,608 to 8,388,607 step	0	A
AREA2 positive direction position			A
AREA3 positive direction position			A
AREA1 negative direction position	Sets the AREA1 to AREA3 negative direction position. [Setting range] -8,388,608 to 8,388,607 step	0	A
AREA2 negative direction position			A
AREA3 negative direction position			A
Minimum ON time for MOVE output	Sets the minimum ON time for MOVE output. [Setting range] 0 to 255 ms	0	A
LS contact configuration	Sets the \pm LS input logics. [Setting range] 0: Make (N.O.) 1: Brake (N.C.)	0	C
HOMES logic level	Sets the HOMES input logic. [Setting range] 0: Make (N.O.) 1: Brake (N.C.)	0	C
SLIT logic level	Sets the SLIT input logic. [Setting range] 0: Make (N.O.) 1: Brake (N.C.)	0	C

Parameter name	Description	Initial value	Update
MS0 operation No. selection	Sets operation data No. corresponding to MS0 to MS5 input. [Setting range] Operation data No.0 to 63	0	B
MS1 operation No. selection		1	
MS2 operation No. selection		2	
MS3 operation No. selection		3	
MS4 operation No. selection		4	
MS5 operation No. selection		5	
HOME-P output function selection	Sets the timing to output the HOME-P output. [Setting range] 0: Home output 1: Return-to-home complete output	0	A

■ Motor parameter

Parameter name	Description	Initial value	Update
RUN current	Sets the motor operating current based on the rated current being 100 %. [Setting range] 0 to 1,000 (1=0.1 %)	1,000	A
STOP current	Sets the motor standstill current as a percentage of the rated current, based on the rated current being 100 %. [Setting range] 0 to 500 (1=0.1 %)	500	A
Position loop gain	Adjusts the motor response in reaction to the position deviation. [Setting range] 1 to 50	10	A
Speed loop gain	Adjusts the motor response in reaction to the speed deviation. [Setting range] 10 to 200	180	A
Speed loop integral time constant	Adjusts the deviation that cannot be adjusted with the speed loop gain. [Setting range] 100 to 2,000 (1=0.1 ms)	1,000	A
Speed filter	Adjusts the motor response. [Setting range] 0 to 200 ms	1	B
Moving average time	Sets the time constant for the moving average filter. [Setting range] 1 to 200 ms	1	B
Filter selection	Sets the filter function to adjust the motor response. [Setting range] 0: Speed filter 1: Moving average filter	0	C
Speed difference gain 1	Adjusts vibration during operation. [Setting range] 0 to 500	45	A
Speed difference gain 2	Adjusts vibration during acceleration/deceleration. [Setting range] 0 to 500	45	A
Control mode	Sets the control mode of the driver. [Setting range] 0: Normal mode 1: Current control mode	0	C

Parameter name	Description	Initial value	Update
Smooth drive	Sets whether to enable or disable smooth drive function. [Setting range] 0: Disable 1: Enable	1	C

■ Operation parameter

Parameter name	Description	Initial value	Update
Common acceleration	Sets the common acceleration rate (common acceleration time) in positioning operation and continuous operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
Common deceleration	Sets the common deceleration rate (common deceleration time) in positioning operation and continuous operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
Starting speed	Sets the starting speed in positioning operation and continuous operation. The motor will operate at the starting speed if the operating speed is below the starting speed. [Setting range] 0 to 1,000,000 Hz	500	B
JOG operating speed	Sets the operating speed for JOG operation. [Setting range] 1 to 1,000,000 Hz	1,000	B
Acceleration/ deceleration rate of JOG	Sets the acceleration/deceleration rate (acceleration/deceleration time) for JOG operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
JOG starting speed	Sets the starting speed for JOG operation. [Setting range] 0 to 1,000,000 Hz	500	B
Acceleration/ deceleration type	Sets whether to use the common acceleration/deceleration or the acceleration/deceleration specified for the operation data. [Setting range] 0: Common 1: Separate	1	B
Acceleration/ deceleration unit	Sets the acceleration/deceleration unit. [Setting range] 0: ms/kHz 1: s	0	C
Automatic return operation	Sets whether to enable or disable automatic return operation. [Setting range] 0: Disable 1: Enable	0	C
Operation speed of automatic return	Sets the operating speed for automatic return operation. [Setting range] 1 to 1,000,000 Hz	1,000	B
Acceleration (deceleration) of automatic return	Sets the acceleration/deceleration rate (acceleration/deceleration time) for automatic return operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
Starting speed of automatic return	Sets the starting speed for automatic return operation. [Setting range] 0 to 1,000,000 Hz	500	B

Parameter name	Description	Initial value	Update
JOG travel amount	Sets the travel amount for JOG operation. [Setting range] 1 to 8,388,607 step	1	B

* Acceleration/deceleration rate (ms/kHz) or acceleration/deceleration time (s) can be selected using "Acceleration/deceleration unit" parameter (initial value: acceleration/deceleration rate).

■ Home operation parameter

Parameter name	Description	Initial value	Update
Home-seeking mode	Sets the mode for return-to-home operation. [Setting range] 0: 2-sensor mode 1: 3-sensor mode 2: Push mode	1	B
Operating speed of home-seeking	Sets the operating speed for return-to-home operation. [Setting range] 1 to 1,000,000 Hz	1,000	B
Acceleration/deceleration of home-seeking	Sets the acceleration/ deceleration rate (acceleration/ deceleration time) for return-to-home operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
Starting speed of home-seeking	Sets the starting speed for return-to-home operation. [Setting range] 1 to 1,000,000 Hz	500	B
Position offset of home-seeking	Sets the amount of offset from mechanical home. [Setting range] -8,388,608 to 8,388,607 step	0	B
Starting direction of home-seeking	Sets the starting direction for home detection. [Setting range] 0: Negative direction 1: Positive direction	1	B
SLIT detection with home-seeking	Sets whether or not to concurrently use the SLIT input for return-to-home operation. [Setting range] 0: Disable 1: Enable	0	B
TIM signal detection with home-seeking	Sets whether or not to concurrently use the TIM signal for return-to-home operation. [Setting range] 0: Disable 1: Enable	0	B
Operating current of home-seeking with push-motion	Sets the operating current for push-motion return-to-home operation based on the rated current being 100 %. [Setting range] 0 to 1,000 (1=0.1 %)	1,000	B

* Acceleration/deceleration rate (ms/kHz) or acceleration/deceleration time (s) can be selected using "Acceleration/deceleration unit" parameter (initial value: acceleration/deceleration rate).

■ Alarm parameter

Parameter name	Description	Initial value	Update
Overload alarm	Sets the condition that an overload alarm generates. [Setting range] 1 to 300 (1=0.1 s)	50	A
Excessive position deviation alarm at current ON	Sets the condition that an excessive position deviation alarm generates when the motor is in a state of current ON. [Setting range] 1 to 30,000 (1=0.01 rev)	300	A
Return-to-home incomplete alarm	When the positioning operation is started while the position origin has not been set, selects whether the alarm generates or not. [Setting range] 0: Disable 1: Enable	0	C
Excessive position deviation alarm at current OFF	Sets the condition that an excessive position deviation alarm generates when the motor is in a state of current OFF. If the position deviation exceeds the setting value in the "Excessive position deviation alarm at current ON" parameter, the excessive position deviation warning at current OFF generates. In addition, if the C-ON input is turned ON, the excessive position deviation alarm at current OFF generates. [Setting range] 1 to 30,000 (1=0.01 rev)	10,000	A

■ Warning parameter

Parameter name	Description	Initial value	Update
Overheat warning	Sets the condition that a main circuit overheat warning generates. [Setting range] 40 to 85 °C	85	A
Overload warning	Sets the condition that an overload warning generates. [Setting range] 1 to 300 (1=0.1 s)	50	A
Overspeed warning	Sets the condition that an overspeed warning generates. [Setting range] 1 to 5,000 r/min	4,500	A
Overvoltage warning (AC power input)	Sets the condition that an overvoltage warning generates. [Setting range] 120 to 450 V	435	A
Overvoltage warning (DC power input)	Sets the condition that an overvoltage warning generates. [Setting range] 150 to 630 (1=0.1 V)	630	A
Undervoltage warning (AC power input)	Sets the condition that an undervoltage warning generates. [Setting range] 120 to 280 V	120	A
Undervoltage warning (DC power input)	Sets the condition that an undervoltage warning generates. [Setting range] 150 to 630 (1=0.1 V)	180	A
Excessive position deviation warning at current ON	Sets the condition that an excessive position deviation warning generates when the motor is in a state of current ON. [Setting range] 1 to 30,000 (1=0.01 rev)	300	A

■ Coordinates parameter

Parameter name	Description	Initial value	Update
Electronic gear A	Sets the denominator of electronic gear. [Setting range] 1 to 65,535	1	C
Electronic gear B	Sets the numerator of electronic gear. [Setting range] 1 to 65,535	1	C
Motor rotation direction	Sets the rotation direction of motor output shaft. [Setting range] 0: Positive direction=CCW 1: Positive direction=CW	1	C
Software overtravel	Sets whether to enable or disable software overtravel detection using soft limits. [Setting range] 0: Disable 1: Enable	1	A
Positive software limit	Sets the value of soft limit in positive direction. [Setting range] -8,388,608 to 8,388,607 step	8,388,607	A
Negative software limit	Sets the value of soft limit in negative direction. [Setting range] -8,388,608 to 8,388,607 step	-8,388,608	A
Preset position	Sets the preset position. [Setting range] -8,388,608 to 8,388,607 step	0	A
Wrap setting	Sets whether to enable or disable wrap function. [Setting range] 0: Disable 1: Enable	0	C
Wrap setting range	Sets the wrap setting range. [Setting range] 1 to 8,388,607 step	1,000	C

■ Common parameter

Parameter name	Description	Initial value	Update
Data setter speed display	Sets the display method of the speed monitor for the OPX-2A . [Setting range] 0: Signed 1: Absolute value	0	A
Data setter edit	Sets whether it is possible to edit using the OPX-2A . [Setting range] 0: Disable 1: Enable	1	A

■ I/O function [input] parameter

Parameter name	Description	Initial value	Update
IN0 input function selection	Assigns the input signals to IN0 to IN7 of the input terminals. [Setting range] Refer to the following table.	3: HOME	C
IN1 input function selection		4: START	
IN2 input function selection		48: M0	
IN3 input function selection		49: M1	
IN4 input function selection		50: M2	
IN5 input function selection		16: FREE	
IN6 input function selection		18: STOP	
IN7 input function selection		24: ALM-RST	
IN0 input logic level setting	Changes the logic level setting for input terminals IN0 to IN7. [Setting range] 0: Make (N.O.) 1: Brake (N.C.)	0	C
IN1 input logic level setting			
IN2 input logic level setting			
IN3 input logic level setting			
IN4 input logic level setting			
IN5 input logic level setting			
IN6 input logic level setting			
IN7 input logic level setting			

Setting range for IN input function selection

0: No function	8: MS0	18: STOP	35: R3	43: R11	51: M3
1: FWD	9: MS1	24: ALM-RST	36: R4	44: R12	52: M4
2: RVS	10: MS2	25: P-PRESET	37: R5	45: R13	53: M5
3: HOME	11: MS3	26: P-CLR*	38: R6	46: R14	
4: START	12: MS4	27: HMI	39: R7	47: R15	
5: SSTART	13: MS5	32: R0	40: R8	48: M0	
6: +JOG	16: FREE	33: R1	41: R9	49: M1	
7: -JOG	17: C-ON	34: R2	42: R10	50: M2	

* It cannot be used.

■ I/O function [output] parameter

Parameter name	Description	Initial value	Update
OUT0 output function selection	Assigns the output signals to OUT0 to OUT5 of the output terminals. [Setting range] Refer to the following table.	70: HOME-P	C
OUT1 output function selection		69: END	
OUT2 output function selection		73: AREA1	
OUT3 output function selection		67: READY	
OUT4 output function selection		66: WNG	
OUT5 output function selection		65: ALM	

Setting range for OUT output function selection

0: No function	10: MS2_R	35: R3	45: R13	61: -LS_R	72: TIM
1: FWD_R	11: MS3_R	36: R4	46: R14	62: HOMES_R	73: AREA1
2: RVS_R	12: MS4_R	37: R5	47: R15	63: SLIT_R	74: AREA2
3: HOME_R	13: MS5_R	38: R6	48: M0_R	65: ALM	75: AREA3
4: START_R	16: FREE_R	39: R7	49: M1_R	66: WNG	80: S-BSY
5: SSTART_R	17: C-ON_R	40: R8	50: M2_R	67: READY	82: MPS *
6: +JOG_R	18: STOP_R	41: R9	51: M3_R	68: MOVE	
7: -JOG_R	32: R0	42: R10	52: M4_R	69: END	
8: MS0_R	33: R1	43: R11	53: M5_R	70: HOME-P	
9: MS1_R	34: R2	44: R12	60: +LS_R	71: TLC	

* AC power input only.

■ I/O function [RS-485] parameter

Parameter name	Description	Initial value	Update
NET-IN0 input function selection	Assigns the input signals to NET-IN0 to NET-IN15. [Setting range] Refer to "Setting range for NET-IN input function selection".	48: M0	C
NET-IN1 input function selection		49: M1	
NET-IN2 input function selection		50: M2	
NET-IN3 input function selection		4: START	
NET-IN4 input function selection		3: HOME	
NET-IN5 input function selection		18: STOP	
NET-IN6 input function selection		16: FREE	
NET-IN7 input function selection		0: No function	
NET-IN8 input function selection		8: MS0	
NET-IN9 input function selection		9: MS1	
NET-IN10 input function selection		10: MS2	
NET-IN11 input function selection		5: SSTART	
NET-IN12 input function selection		6: +JOG	
NET-IN13 input function selection		7: -JOG	
NET-IN14 input function selection		1: FWD	
NET-IN15 input function selection	2: RVS		
NET-OUT0 output function selection	Assigns the output signals to NET-OUT0 to NET-OUT15. [Setting range] Refer to "Setting range for NET-OUT output function selection" on p.120.	48: M0_R	C
NET-OUT1 output function selection		49: M1_R	
NET-OUT2 output function selection		50: M2_R	
NET-OUT3 output function selection		4: START_R	
NET-OUT4 output function selection		70: HOME-P	
NET-OUT5 output function selection		67: READY	
NET-OUT6 output function selection		66: WNG	
NET-OUT7 output function selection		65: ALM	
NET-OUT8 output function selection		80: S-BSY	
NET-OUT9 output function selection		73: AREA1	
NET-OUT10 output function selection		74: AREA2	
NET-OUT11 output function selection		75: AREA3	
NET-OUT12 output function selection		72: TIM	
NET-OUT13 output function selection		68: MOVE	
NET-OUT14 output function selection		69: END	
NET-OUT15 output function selection	71: TLC		

● Setting range for NET-IN input function selection

0: No function	7: -JOG	16: FREE	32: R0	39: R7	46: R14
1: FWD	8: MS0	17: C-ON	33: R1	40: R8	47: R15
2: RVS	9: MS1	18: STOP	34: R2	41: R9	48: M0
3: HOME	10: MS2	24: ALM-RST	35: R3	42: R10	49: M1
4: START	11: MS3	25: P-PRESET	36: R4	43: R11	50: M2
5: SSTART	12: MS4	26: P-CLR *	37: R5	44: R12	51: M3
6: +JOG	13: MS5	27: HMI	38: R6	45: R13	52: M4
					53: M5

* It cannot be used.

● **Setting range for NET-OUT output function selection**

0: No function	10: MS2_R	35: R3	45: R13	61: -LS_R	72: TIM
1: FWD_R	11: MS3_R	36: R4	46: R14	62: HOMES_R	73: AREA1
2: RVS_R	12: MS4_R	37: R5	47: R15	63: SLIT_R	74: AREA2
3: HOME_R	13: MS5_R	38: R6	48: M0_R	65: ALM	75: AREA3
4: START_R	16: FREE_R	39: R7	49: M1_R	66: WNG	80: S-BSY
5: SSTART_R	17: C-ON_R	40: R8	50: M2_R	67: READY	82: MPS *
6: +JOG_R	18: STOP_R	41: R9	51: M3_R	68: MOVE	
7: -JOG_R	32: R0	42: R10	52: M4_R	69: END	
8: MS0_R	33: R1	43: R11	53: M5_R	70: HOME-P	
9: MS1_R	34: R2	44: R12	60: +LS_R	71: TLC	

* AC power input only.

■ **Communication parameter**


Parameter name	Description	Initial value	Update
Communication timeout	Sets the condition in which a communication timeout occurs in RS-485 communication. It is not monitored when the set value is 0. [Setting range] 0: Not monitored 1 to 10,000 ms	0	A
Communication error alarm	Sets the condition in which a RS-485 communication error alarm generates. A communication error alarm generates after a RS-485 communication error has occurred by the number of times set here. [Setting range] 1 to 10 times	3	A
Communication parity	Sets the parity of RS-485 communication. [Setting range] 0: None 1: Even 2: Odd	1	D
Communication stop bit	Sets the stop bit of RS-485 communication. [Setting range] 0: 1 bit 1: 2 bits	0	D
Transmission waiting time	Sets the transmission waiting time of RS-485 communication. [Setting range] 0 to 10,000 (1=0.1 ms)	100	D

3 Operation using the OPX-2A

This chapter explains the overview and operating method for the **OPX-2A**.
When connect or disconnect the **OPX-2A** cable, turn off the driver power supply.

3-1 Overview of the OPX-2A

The **OPX-2A** is a data setter that can set the operation data and parameters, and execute monitor and others. In addition, the **OPX-2A** can be used to save the data of driver. There are four destinations (data banks) to save data.



The **OPX-2A** can be used for the following purposes:

- Set data for the driver.
- Monitor the communication time or communication status.
- Check and clear the alarm records.
- The data set in the driver can be saved to the **OPX-2A**.
- The data saved in the **OPX-2A** can be copied to another driver connected to the **OPX-2A**.

■ Notation

In this manual, keys are denoted by symbols, such as $\left[\begin{smallmatrix} \text{MODE} \\ \text{ESC} \end{smallmatrix} \right]$ $\left[\text{SET} \right]$ $\left[\uparrow \right]$ $\left[\downarrow \right]$ $\left[\leftarrow \right]$ $\left[\rightarrow \right]$.
In figures, a simplified illustration of the display and LED indicators is used, as shown below.



■ Edit lock function


Enable the edit lock function if you want to prevent data from being edited or cleared. Data cannot be changed or deleted while the edit lock function is enabled.

● Setting the edit lock function

In the top screen of each operation mode, press the $\left[\begin{smallmatrix} \text{MODE} \\ \text{ESC} \end{smallmatrix} \right]$ key for at least 5 seconds.

The display will show "Lock" and the edit lock function will be enabled.

The "LOCK" LED in the LED indicator area will also be lit.



● Canceling the edit lock function


Again in the top screen of each operation mode, press the $\left[\begin{smallmatrix} \text{MODE} \\ \text{ESC} \end{smallmatrix} \right]$ key for at least 5 seconds.

The display will show "UnLock" and the edit lock function will be cancelled.

The "LOCK" LED in the LED indicator area will turn off.




3-2 Names and functions of parts




3-3 How to read the display

The display consists of 7-segment LEDs. (The number "5" and alphabet "S" are the same.)


• Numbers



• Alphabets




• Signes




■ How to read the LED indicators

When the operation mode is changed or an alarm or warning generates, a corresponding LED will be lit. While the motor is operating or the edit lock function is enabled, the condition is also indicated by the illumination of a corresponding LED.



3-4 OPX-2A error display

Errors displayed on the **OPX-2A** are explained.

Error display	Meaning	Action
	A communication error occurred between the OPX-2A and driver.	<ul style="list-style-type: none"> • Check if the OPX-2A is connected securely. • Check if the OPX-2A cable is disconnected or damaged. • The OPX-2A or the communication part of the driver may have damaged. Contact your nearest Oriental Motor sales office.


3-5 Screen transitions

- Broken line indicates that data writing cannot be executed when internal processing is in progress via RS-485 communication. "mEm-bUSy" is displayed even when the [SET] key is pressed.
- In the lower screen level except the top screen, press [^{MODE}/_{ESC}] key to return to the previous level.




- The following limitations are present while the edit lock function is enabled.
 - Data mode, parameter mode: Although they are displayed on the screen, they are unable to operate.
 - Clearing the alarm and warning records, clearing the data, position preset, teaching and copy mode: They are not displayed on the screen.
- When the HMI input is in OFF, functions other than monitor mode, upload, verification or viewing of the parameter mode cannot be executed.

● Monitor mode




4 AC power input type/DC power input type Common

● Data mode




4 AC power input type/DC power input type Common

● Parameter mode, test mode



● Copy mode



3-6 Monitor mode

■ Overview of the monitor mode

● Monitoring the operating status

You can monitor the motor speed, command position, operation data number corresponding to the current operation and operation data number currently selected in real time.

memo A range capable to monitor with the **OPX-2A** is from -19,999,999 to 19,999,999 with up to eight digit numbers. However, only seven digit numbers can be shown on the display of the **OPX-2A**, so only the last seven digit numbers are shown when the monitored value is eight digit numbers, and a dot is marked on the lower right of the display.

- Display example

Actual value	-19,999,999	-10,000,001	-10,000,000	10,000,000	10,000,001	19,999,999
Displayed value	-9999999.	-0000001.	-0000000.	0000000.	0000001.	9999999.

● Checking the alarms/warnings, clearing alarm/warning records, and resetting alarms

- If an alarm or warning generates, a corresponding alarm code or warning code will be displayed. You can check the code to identify the details of the alarm/warning.
- Up to 10 most recent alarms/warnings can be displayed, starting from the latest one.
- You can reset the alarms currently present.
- You can clear alarm/warning records.

● Checking the I/O signals

You can check the ON/OFF status of each I/O signal of the driver.

■ Monitor items

● Speed

You can check the motor speed (unit: r/min).

While the motor is rotating in the CCW direction, “-” is shown in front of the displayed value. If the speed is indicated by an absolute value, no sign is shown to indicate the rotating direction. You can select the value display format using the "Data setter speed display" parameter.

● Command position

You can check the command position of the motor with reference to the home.

If a resolution is set, an appropriate value based on the resolution is shown as steps.

● Operation number

You can check the operation data number corresponding to the data used in the current positioning operation.

● Selected number

You can check the operation data number currently selected.

● Alarm

When an alarm generates, a corresponding alarm code will be displayed. You can also reset alarms or check and clear alarm records. Refer to p.144 for details about alarm codes and the method to reset alarms.

Note Do not turn off the driver power supply while an alarm is being reset or alarm records are being cleared (=while the display is blinking). Doing so may damage the data.

memo Some alarms cannot be reset on the **OPX-2A**. Check by the "Alarm list" on p.144. To reset these alarms, you must turn on the power supply again.

● **Warning**

When a warning generates, a corresponding warning code will be displayed. You can also check or clear warning records. For details about warning code, refer to p.150.


Note Do not turn off the driver power supply while warning records are being cleared (=while the display is blinking). Doing so may damage the data.

memo You can also clear the warning records by turning off the driver power supply.


● **Direct I/O monitor**

You can check the ON/OFF status of each I/O signal of the driver. Each digit on the 7-segment LED display corresponds to a signal. The LED is lit when the signal is ON, and it is unlit when the signal is OFF.

● Input signals



● Output signals



4 AC power input type/DC power input type Common

3-7 Data mode

Up to 64 sets of motor operation data can be set. Once set, the operation data is saved in the non-volatile memory of the driver. The data will not be lost even after the **OPX-2A** is disconnected from the driver.

Note Operation data has significant bearing on motor operation. Before setting any operation data, make sure you fully understand the content of the operation data.

- memo**
- If the operations are limited by the edit lock function or HMI input, operation data cannot be edited.
 - Operation data can also be set by selecting the ID with the parameter mode.
 - If the value you have input is outside the setting range, "Error" will be displayed for 1 second. If this error display appears, input a different value that falls within the setting range.
 - If **[SET]** key is pressed while executing the internal processing via RS-485 communication, "mEm-bUSy" may be displayed. Check the timing when "mEm-bUSy" is displayed on p.124. Be sure to wait until all internal processing is completed, before pressing the **[SET]** key.


■ **Setting item**

Setting item	Description	Initial value
Operation mode	Selects how to specify the position (travel amount) in positioning operation. [Setting range] 0: Incremental 1: Absolute	0
Position	Sets the position (distance) for positioning operation. [Setting range] -8,388,608 to +8,388,607 step	0
Operating speed	Sets the operating speed in positioning operation and continuous operation. [Setting range] 1 to 1,000,000 Hz	1,000
Operation function	Sets the operation mode to execute positioning operation. [Setting range] 0: Single-motion 1: Linked-motion 2: Linked-motion 2 3: Push	0
Sequential positioning	Sets whether to enable or disable sequential positioning operation. [Setting range] 0: Disable 1: Enable	0
Acceleration *	Sets the acceleration rate (acceleration time) in positioning operation and continuous operation. [Setting range] 0.001 to 1,000.000 ms/kHz or 0.001 to 1,000.000 s	1.000
Deceleration *	Sets the deceleration rate (deceleration time) in positioning operation and continuous operation. [Setting range] 0.001 to 1,000.000 ms/kHz or 0.001 to 1,000.000 s	1.000
Push current	Sets the current rate of push-motion operation. [Setting range] 0.0 to 100.0 %	20.0
Dwell time	Sets the dwell time to be used in linked-motion 2 operation. [Setting range] 0.000 to 50.000 s	0.000

* This item is effective when the "Acceleration/deceleration type" parameter is set to "Separate."
If this parameter is set to "Common," the values of the "Common acceleration" and "Common deceleration" parameters will be used.

● **How to set the dwell time**

When displaying the "2: Linked-motion 2" on the "Operation function" and pressing the [SET] key, the screen to set the dwell time is displayed. Input the dwell time using the [↑][↓][←][→] keys and press the [SET] key.



■ Setting example

This section explains how to change the the operation mode and position of the operation data No.0.

- Operation mode: Changes from incremental to absolute.
- Position: Changes from 0 step to 10,000 steps.

1. Use the **[MODE/ESC]** key to select the data mode.
The "DATA" LED is lit.
2. Press the **[SET]** key on the top screen of the data mode.
The display changes to the operation data No.0 screen.
3. Press the **[SET]** key.
The display changes to the operation mode screen.
4. Press the **[SET]** key again.
The present set value of the operation mode is displayed with blinking.
5. Press the **[↓]** key once to select "1."
The display changes to the position screen.
6. Press the **[SET]** key.
The blinking speed of the input value becomes quickly and the value is set. The display returns to the operation mode screen.
7. Press the **[↓]** key.
The display changes to the position screen.
8. Press the **[SET]** key.
The present set value of the position is displayed with blinking.
9. Use the **[↑][↓][←][→]** keys to select "10,000."
The selected digit is displayed with blinking.
10. Press the **[SET]** key.
The blinking speed of the input value becomes quickly and the value is set. The display returns to the position screen.
11. Press the **[MODE/ESC]** key.
The display returns to the operation data No.0 screen.

Top screen of the data mode

d R t R

SET

Operation data No.0

d R t R - 0 0

SET

Operation mode

0 0 - i n c R b S

SET

Present value (blinking)

0 0

↓

Change to absolute mode (blinking)

1

SET

Confirm the changed value (quick blinking)

1

Return to the operation mode

0 0 - i n c R b S

↓

Position

0 0 - P o S

SET

Present value (blinking)

0 0 0 0 0 0 0 0

Use **[↑]** **[↓]** to increase/decrease the value.

Use **[←]** **[→]** to navigate through the digits.

Input 10,000 (blinking)

0 0 1 0 0 0 0 0

SET

Confirm the changed value (quick blinking)

0 0 1 0 0 0 0 0

Return to the position

0 0 - P o S

MODE/ESC

Return to the operation data No.0

d R t R - 0 0

■ Initialization of the selected operation data

All of the set value for the selected operation data number can be reverted to the initial values. Perform "clear data" of the data mode. For the operation, check the screen transitions of the data mode on p.125.

■ Initialization of all operation data

All of the operation data saved in the driver can be reverted to the initial values. Perform "Initialize operation data" of the copy mode. For the operation, check the screen transitions of the copy mode on p.127.

3-8 Parameter mode

You can set parameters relating to motor operation and control. These parameters are saved in the non-volatile memory of the driver.


Note Parameters have significant bearing on motor operation. Before setting any parameter, make sure you fully understand the content of the parameter.

- memo**
- If operations are limited by the edit lock function or HMI input, parameters cannot be edited.
 - If the value you have input is outside the setting range, "Error" will be displayed for 1 second. If this error display appears, input a different value that falls within the setting range.
 - If [SET] key is pressed while executing the internal processing via RS-485 communication, "mEm-bUSy" may be displayed. Check the timing when "mEm-bUSy" is displayed on p.124. Be sure to wait until all internal processing is completed, before pressing the [SET] key.
 - If a nonexistent parameter ID is entered, "id-Err" will be displayed for 1 second. Check the ID and enter the correct one.
 - Refer to p.110 for the timing of updating a parameter.

■ Setting example

This section explains how to assign the TIM output to the OUT1 output.

1. Use the **[MODE/ESC]** key to select the parameter mode.
The "PAR" LED is lit.
2. Press the **[SET]** key on the top screen of the parameter mode.
3. Use the **[↑][↓][←][→]** keys to enter [ID: 2209] in the "OUT1 output function selection" parameter.
4. Press the **[SET]** key.
The present set value of the "OUT1 output function selection" parameter is displayed with blinking.
5. Use the **[↑][↓][←][→]** keys to enter "72."
"72" indicates the TIM output.
6. Press the **[SET]** key.
The blinking speed of the input value becomes quickly and the value is set.
The display returns to the "OUT1 output function selection" parameter screen.



■ Parameter list

There is a unique ID in each parameter. With the **OPX-2A**, set the parameter selecting the ID.

● Operation data

Operation data can also be set by selecting the data mode.

ID	Parameter name	Setting range	Initial value	Update
640 to 703	Operation mode No.0 to Operation mode No.63	0: Incremental 1: Absolute	0	B
512 to 575	Position No.0 to Position No.63	-8,388,608 to +8,388,607 step	0	B
576 to 639	Operating speed No.0 to Operating speed No.63	0 to 1,000,000 Hz	1,000	B
704 to 767	Operation function No.0 to Operation function No.63	0: Single-motion 1: Linked-motion 2: Linked-motion 2 3: Push	0	B
960 to 1023	Sequential positioning No.0 to Sequential positioning No.63	0: Disable 1: Enable	0	B
768 to 831	Acceleration No.0 * to Acceleration No.63 *	0.001 to 1,000.000 ms/kHz or 0.001 to 1,000.000 s	1.000	B
832 to 895	Deceleration No.0 * to Deceleration No.63 *	0.001 to 1,000.000 ms/kHz or 0.001 to 1,000.000 s	1.000	B
896 to 959	Push current No.0 to Push current No.63	0.0 to 100.0 %	20.0	B
1024 to 1087	Dwell time No.0 to Dwell time No.63	0.000 to 50.000 s	0.000	B

* This item is effective when the "Acceleration/deceleration type" parameter is set to "Separate."
If this parameter is set to "Common," the values of the "Common acceleration" and "Common deceleration" parameters will be used.

● Parameter

ID	Parameter name	Setting range	Initial value	Update
256	STOP input action	0: Immediate stop 1: Decelerate stop 2: Immediate stop & Current OFF 3: Deceleration stop & Current OFF	1	A
257	Hardware overtravel	0: Disable 1: Enable	1	A
258	Overtravel action	0: Immediate stop 1: Decelerate stop	0	A
259	END signal range	0.0 to 18.0°	1.8	A
260	Positioning complete output offset	-1.8 to 1.8°	0.0	A
261	AREA1 positive direction position	-8,388,608 to 8,388,607 step	0	A
262	AREA1 negative direction position			
263	AREA2 positive direction position			
264	AREA2 negative direction position			
265	AREA3 positive direction position			
266	AREA3 negative direction position			
267	Minimum ON time for MOVE output	0 to 255 ms	0	A
268	LS contact configuration	0: Make (N.O.) 1: Brake (N.C.)	0	C
269	HOMES logic level			C
270	SLIT logic level			C
288	RUN current	0.0 to 100.0 %	100.0	A
289	STOP current	0.0 to 50.0 %	50.0	A
290	Position loop gain	1 to 50	10	A
291	Speed loop gain	10 to 200	180	A
292	Speed loop integral time constant	10.0 to 200.0 ms	100.0	A
293	Speed filter	0 to 200 ms	1	B
294	Moving average time	1 to 200 ms	1	B
320	Common acceleration	0.001 to 1,000.000 ms/kHz or 0.001 to 1,000.000 s	1.000	B
321	Common deceleration			B
322	Starting speed	0 to 1,000,000 Hz	500	B
323	JOG operating speed	1 to 1,000,000 Hz	1,000	B
324	Acceleration/deceleration rate of JOG	0.001 to 1,000.000 ms/kHz or 0.001 to 1,000.000 s	1.000	B
325	JOG starting speed	0 to 1,000,000 Hz	500	B
326	Acceleration/deceleration type	0: Common 1: Separate	1	B
327	Acceleration/deceleration unit	0: ms/kHz 1: s	0	C
352	Home-seeking mode	0: 2-sensor mode 1: 3-sensor mode 2: Push mode	1	B
353	Operating speed of home-seeking	1 to 1,000,000 Hz	1,000	B
354	Acceleration/deceleration of home-seeking	0.001 to 1,000.000 ms/kHz or 0.001 to 1,000.000 s	1.000	B
355	Starting speed of home-seeking	1 to 1,000,000 Hz	500	B
356	Position offset of home-seeking	-8,388,608 to 8,388,607 step	0	B
357	Starting direction of home-seeking	0: Negative direction 1: Positive direction	1	B

ID	Parameter name	Setting range	Initial value	Update
358	SLIT detection with home-seeking	0: Disable 1: Enable	0	B
359	TIM signal detection with home-seeking			B
360	Operating current of home-seeking with push-motion	0.0 to 100.0 %	100.0	B
384	Overload alarm	0.1 to 30.0 s	5.0	A
385	Excessive position deviation alarm at current ON	0.01 to 300.00 rev	3.00	A
388	Return-to-home incomplete alarm	0: Disable 1: Enable	0	C
416	Overheat warning	40 to 85 °C	85	A
417	Overload warning	0.1 to 30.0 s	5.0	A
418	Overspeed warning	1 to 5,000 r/min	4,500	A
419	Overvoltage warning	AC power input: 120 to 450 V DC power input: 15.0 to 63.0 V	AC power input: 435 DC power input: 63.0	A
420	Undervoltage warning	AC power input: 120 to 280 V DC power input: 15.0 to 63.0 V	AC power input: 120 DC power input: 18.0	A
421	Excessive position deviation warning at current ON	0.01 to 300.00 rev	3.00	A
448	Electronic gear A	1 to 65,535	1	C
449	Electronic gear B			
450	Motor rotation direction	0: Positive direction=CCW 1: Positive direction=CW	1	C
451	Software overtravel	0: Disable 1: Enable	1	A
452	Positive software limit	-8,388,608 to 8,388,607 step	8,388,607	A
453	Negative software limit		-8,388,608	A
454	Preset position		0	A
455	Wrap setting	0: Disable 1: Enable	0	C
456	Wrap setting range	1 to 8,388,607 step	1,000	C
480	Data setter speed display	0: Signed 1: Absolute value	0	A
2048	MS0 operation No. selection	0 to 63	0	B
2049	MS1 operation No. selection		1	
2050	MS2 operation No. selection		2	
2051	MS3 operation No. selection		3	
2052	MS4 operation No. selection		4	
2053	MS5 operation No. selection		5	
2054	HOME-P output function selection	0: Home output 1: Return-to-home complete output	0	A
2064	Filter selection	0: Speed filter 1: Moving average filter	0	C
2065	Speed difference gain 1	0 to 500	45	A
2066	Speed difference gain 2			
2067	Control mode	0: Normal mode 1: Current control mode	0	C
2068	Smooth drive	0: Disable 1: Enable	1	C
2080	Automatic return operation	0: Disable 1: Enable	0	C

ID	Parameter name	Setting range	Initial value	Update
2081	Operation speed of automatic return	1 to 1,000,000 Hz	1,000	B
2082	Acceleration (deceleration) of automatic return	0.001 to 1,000.000 ms/kHz or 0.001 to 1,000.000 s	1.000	B
2083	Starting speed of automatic return	0 to 1,000,000 Hz	500	B
2084	JOG travel amount	1 to 8,388,607 step	1	B
2112	Excessive position deviation alarm at current OFF	0.01 to 300.00 rev	100.00	A
2176	IN0 input function selection	Refer to "IN input function selection" on p.138.	3: HOME	C
2177	IN1 input function selection		4: START	
2178	IN2 input function selection		48: M0	
2179	IN3 input function selection		49: M1	
2180	IN4 input function selection		50: M2	
2181	IN5 input function selection		16: FREE	
2182	IN6 input function selection		18: STOP	
2183	IN7 input function selection		24: ALM-RST	
2192	IN0 input logic level setting	0: Make (N.O.) 1: Brake (N.C.)	0	C
2193	IN1 input logic level setting			
2194	IN2 input logic level setting			
2195	IN3 input logic level setting			
2196	IN4 input logic level setting			
2197	IN5 input logic level setting			
2198	IN6 input logic level setting			
2199	IN7 input logic level setting			
2208	OUT0 output function selection	Refer to "OUT output function selection" on p.138.	70: HOME-P	C
2209	OUT1 output function selection		69: END	
2210	OUT2 output function selection		73: AREA1	
2211	OUT3 output function selection		67: READY	
2212	OUT4 output function selection		66: WNG	
2213	OUT5 output function selection		65: ALM	
2224	NET-IN0 input function selection	Refer to "NET-IN input function selection" on p.138.	48: M0	C
2225	NET-IN1 input function selection		49: M1	
2226	NET-IN2 input function selection		50: M2	
2227	NET-IN3 input function selection		4: START	
2228	NET-IN4 input function selection		3: HOME	
2229	NET-IN5 input function selection		18: STOP	
2230	NET-IN6 input function selection		16: FREE	
2231	NET-IN7 input function selection		0: No function	
2232	NET-IN8 input function selection		8: MS0	
2233	NET-IN9 input function selection		9: MS1	
2234	NET-IN10 input function selection		10: MS2	
2235	NET-IN11 input function selection		5: SSTART	
2236	NET-IN12 input function selection		6: +JOG	
2237	NET-IN13 input function selection		7: -JOG	
2238	NET-IN14 input function selection		1: FWD	
2239	NET-IN15 input function selection		2: RVS	
2240	NET-OUT0 output function selection	Refer to "NET-OUT output function selection" on p.138.	48: M0_R	C

ID	Parameter name	Setting range	Initial value	Update
2241	NET-OUT1 output function selection	Refer to "NET-OUT output function selection" on p.138.	49: M1_R	C
2242	NET-OUT2 output function selection		50: M2_R	
2243	NET-OUT3 output function selection		4: START_R	
2244	NET-OUT4 output function selection		70: HOME-P	
2245	NET-OUT5 output function selection		67: READY	
2246	NET-OUT6 output function selection		66: WNG	
2247	NET-OUT7 output function selection		65: ALM	
2248	NET-OUT8 output function selection		80: S-BSY	
2249	NET-OUT9 output function selection		73: AREA1	
2250	NET-OUT10 output function selection		74: AREA2	
2251	NET-OUT11 output function selection		75: AREA3	
2252	NET-OUT12 output function selection		72: TIM	
2253	NET-OUT13 output function selection		68: MOVE	
2254	NET-OUT14 output function selection		69: END	
2255	NET-OUT15 output function selection		71: TLC	
2304	Communication timeout	0: Not monitored 1 to 10,000 ms	0	A
2305	Communication error alarm	1 to 10 times	3	A
2563	Communication parity	0: None 1: Even 2: Odd	1	C
2564	Communication stop bit	0: 1 bit 1: 2 bits	0	C
2565	Transmission waiting time	0.0 to 1,000.0 ms	10.0	C

● Setting range for function selection parameters

IN input function selection

0: No function	8: MS0	18: STOP	35: R3	43: R11	51: M3
1: FWD	9: MS1	24: ALM-RST	36: R4	44: R12	52: M4
2: RVS	10: MS2	25: P-PRESET	37: R5	45: R13	53: M5
3: HOME	11: MS3	26: P-CLR*	38: R6	46: R14	
4: START	12: MS4	27: HMI	39: R7	47: R15	
5: SSTART	13: MS5	32: R0	40: R8	48: M0	
6: +JOG	16: FREE	33: R1	41: R9	49: M1	
7: -JOG	17: C-ON	34: R2	42: R10	50: M2	

* It cannot be used.

OUT output function selection

0: No function	10: MS2_R	35: R3	45: R13	61: -LS_R	72: TIM
1: FWD_R	11: MS3_R	36: R4	46: R14	62: HOMES_R	73: AREA1
2: RVS_R	12: MS4_R	37: R5	47: R15	63: SLIT_R	74: AREA2
3: HOME_R	13: MS5_R	38: R6	48: M0_R	65: ALM	75: AREA3
4: START_R	16: FREE_R	39: R7	49: M1_R	66: WNG	80: S-BSY
5: SSTART_R	17: C-ON_R	40: R8	50: M2_R	67: READY	82: MPS *
6: +JOG_R	18: STOP_R	41: R9	51: M3_R	68: MOVE	
7: -JOG_R	32: R0	42: R10	52: M4_R	69: END	
8: MS0_R	33: R1	43: R11	53: M5_R	70: HOME-P	
9: MS1_R	34: R2	44: R12	60: +LS_R	71: TLC	

* AC power input only.

NET-IN input function selection

0: No function	8: MS0	18: STOP	35: R3	43: R11	51: M3
1: FWD	9: MS1	24: ALM-RST	36: R4	44: R12	52: M4
2: RVS	10: MS2	25: P-PRESET	37: R5	45: R13	53: M5
3: HOME	11: MS3	26: P-CLR *	38: R6	46: R14	
4: START	12: MS4	27: HMI	39: R7	47: R15	
5: SSTART	13: MS5	32: R0	40: R8	48: M0	
6: +JOG	16: FREE	33: R1	41: R9	49: M1	
7: -JOG	17: C-ON	34: R2	42: R10	50: M2	

* It cannot be used.

NET-OUT output function selection

0: No function	10: MS2_R	35: R3	45: R13	61: -LS_R	72: TIM
1: FWD_R	11: MS3_R	36: R4	46: R14	62: HOMES_R	73: AREA1
2: RVS_R	12: MS4_R	37: R5	47: R15	63: SLIT_R	74: AREA2
3: HOME_R	13: MS5_R	38: R6	48: M0_R	65: ALM	75: AREA3
4: START_R	16: FREE_R	39: R7	49: M1_R	66: WNG	80: S-BSY
5: SSTART_R	17: C-ON_R	40: R8	50: M2_R	67: READY	82: MPS *
6: +JOG_R	18: STOP_R	41: R9	51: M3_R	68: MOVE	
7: -JOG_R	32: R0	42: R10	52: M4_R	69: END	
8: MS0_R	33: R1	43: R11	53: M5_R	70: HOME-P	
9: MS1_R	34: R2	44: R12	60: +LS_R	71: TLC	

* AC power input only.

3-9 Test mode

■ **Overview of the test mode**

● **Direct I/O test**

You can check the ON/OFF status of each input signal of the driver. You can also switch the ON/OFF status of each output signal on the **OPX-2A**. When checking the connection condition of the driver, perform the direct I/O test.

● **JOG operation**

You can operate the motor using the keys on the **OPX-2A**.

● **Data select operation**

You can perform the positioning operation.

● **Return-to-home operation**

You can perform the return-to-home operation.

● **Position preset**

You can set the preset value as the command position.

● **Teaching**


You can operate the motor using the keys on the **OPX-2A** and update the attained position in the operation data.



- Stop the motor operation before changing to the test mode.
- When you move from the top screen of the test mode to a lower level, the following inputs will be disabled.
START, SSTART, HOME, ±JOG, FWD, RVS and MS0 to MS5.
- In the direct I/O test, if the screen moves to the lower level, all of I/O signals and operation will be disabled.
- If the **[SET]** key is pressed while executing the internal processing via RS-485 communication, "mEm-bUSy" may be displayed. Check the timing when "mEm-bUSy" is displayed on p.124. Be sure to wait until all internal processing is completed, before pressing the **[SET]** key.
- If "Error" is displayed when data select operation, return-to-home operation, position preset or teaching function is performed, check whether an alarm generates.
- When the HMI input is OFF, test mode cannot be executed.

● **What happens when the **[SET]** key is pressed while the motor is operating**

While the motor is operating, you cannot move to any lower level from the top screen of the test mode. Pressing the **[SET]** key will generate an error, and "oPE-Err" will be shown. Be sure to stop the motor operation before pressing the **[SET]** key.



■ **Direct I/O test**


When checking the connection condition of the driver, perform the direct I/O test.

Each digit on the 7-segment LED display corresponds to a signal. The LED is lit when the input signal is ON, and it is unlit when the input signal is OFF.


Use the **[↑]****[↓]** keys to switch the ON-OFF state of the output signal. "□" is displayed when the signal is ON, while "-" is displayed when the signal is OFF.

● **Input signals**

Input signals test




Sensor signals test



● **Output signals**

Output signals test



Use **[←]** **[→]** to navigate through the digits.

Use **[↑]** **[↓]** to switch the ON/OFF status.

indicates the ON status.

indicates the OFF status.

■ JOG operation


You can operate the motor using the keys on the **OPX-2A**.

Pressing the [↑] key once causes the motor to rotate one step in the positive direction. Pressing and holding the key causes the motor to rotate continuously in the positive direction.

Pressing the [↓] key once causes the motor to rotate one step in the negative direction. Pressing and holding the key causes the motor to rotate continuously in the negative direction.

The operating speed corresponds to the value set in the "JOG operating speed" parameter.

Take note that when the value set in the "JOG starting speed" parameter is greater than the value set in the "JOG operating speed" parameter, the JOG starting speed will become effective.



Note During operation, the motor rotates at the specified operating speed while each applicable key is pressed. Before commencing the operation, consider the status of the equipment and condition of its surroundings to confirm thoroughly that motor rotation will not cause any dangerous situations.

■ Data select operation

Select a desired operation data number and then press the [SET] key, and positioning operation will be performed.

Note During operation, the motor rotates at the specified operating speed. Before commencing the operation, consider the status of the equipment and condition of its surroundings to confirm thoroughly that motor rotation will not cause any dangerous situations.

■ Return-to-home operation

You can perform a return-to-home operation. The operating speed corresponds to the value set in the "Operating speed of home-seeking" parameter.

Note During operation, the motor rotates at the specified operating speed. Before commencing the operation, consider the status of the equipment and condition of its surroundings to confirm thoroughly that motor rotation will not cause any dangerous situations.

■ Presetting the position

In this operation, the command position is preset by rewriting the value in the "Preset position" parameter.

memo If operations are limited by the edit lock function, the preset cannot be performed.

■ Teaching

You can operate the motor using the keys on the **OPX-2A** and update the attained position in the operation data. The absolute mode will be automatically selected as the operation mode of any position data set by teaching. The operating speed, acceleration/deceleration rate and starting speed of teaching are the same as the corresponding settings applicable to JOG operation.

Note During operation, the motor rotates at the specified operating speed. Before commencing the operation, consider the status of the equipment and condition of its surroundings to confirm thoroughly that motor rotation will not cause any dangerous situations.


memo If operations are limited by the edit lock function, the teaching cannot be performed.

3-10 Copy mode

■ Overview of the copy mode

● Download

Data saved in the **OPX-2A** can be copied to the driver. If a download error occurs, a code indicating the description of the error will blink on the display. Download will not be performed and the display will return to the top screen of download. Refer to the following "Error of the copy mode" to display the error.



● Upload

Data saved in the driver can be copied to the **OPX-2A**.

● Verification

Data in the **OPX-2A** can be verified against the corresponding data in the driver.

If the verification finds that the two sets of data match, "Good" will be shown. If the two do not match, "Error" will be shown.

If a verification error occurs, a code indicating the description of the error will blink on the display. Verification will not be performed and the display will return to the top screen of verification. Refer to the following "Error of the copy mode" to display the error.

● Initializing data

Data saved in the driver can be restored to the initial values.

● What happens when the [SET] key is pressed while the edit lock function is enabled

While the edit lock function is enabled, you cannot move to any lower level from the top screen of the copy mode. Pressing the [SET] key will generate an error, and "Lock-Err" will be shown. Be sure to cancel the edit lock function before pressing the [SET] key. Refer to p.121 for the procedure to cancel the edit lock function.

Lock-Err

■ Error of the copy mode

If an error occurs in download or verification, the error code will blink on the display.

At this time, the processing will not be executed and the display will return to the top screen.

Blinking display	Description	Action
<i>Prod-Err</i>	There is a discrepancy between the selected product series and the data being processed.	<ul style="list-style-type: none"> Check the product series. Check the data bank number on the OPX-2A.
<i>HEAD-Err</i> <i>bcc-Err</i>	An error occurred while processing.	Execute the processing again. If the same error occurs, the data saved in the OPX-2A may have damaged. Upload and set the data of the OPX-2A again.
<i>no-data</i>	The specified data bank number does not contain data.	Check the data bank number.

Note Do not turn off the driver power supply while processing is in progress (=while the display is blinking). Doing so may damage the data.

memo When a parameter that the power supply is required to turn on again for updating was changed by downloading, turn on the DC power supply of the driver again.

4 Inspection and maintenance

4-1 Inspection

It is recommended that periodic inspections be conducted for the items listed below after each operation of the motor. If an abnormal condition is noted, discontinue any use and contact your nearest Oriental Motor sales office.

■ Inspection item

- Check if any of the screws having installed the motor is loose.
- Check if an unusual noise is generated from a bearing part (ball bearings) of the motor.
- Check if a damage or stress is applied on the cable.
- Check if the connection part between the cable and driver is loose.
- Check if the output shaft and the load shaft are out of alignment.
- Check if the openings in the driver clogged.
- Check if the installation place of the driver is loose.
- Check if any attachment of dust, etc., on the driver.
- Check if any strange smells or appearances within the driver.



The driver uses semiconductor components. Handle the driver with care since static electricity may damage semiconductor components.

4-2 Warranty

Check on the Oriental Motor Website for the product warranty.

4-3 Disposal

Dispose the product correctly in accordance with laws and regulations, or instructions of local governments.

5 Alarms and warnings

The driver provides alarms that are designed to protect the driver from overheating, poor connection, error in operation, etc. (protective functions), as well as warnings that are output before the corresponding alarms generate (warning functions).

5-1 Alarms

When an alarm generates, the ALM output will turn OFF and the motor will stop. At the same time, the ALM LED (or ALARM LED) will start blinking.

The present alarm can be checked by counting the number of times the LED blinks, or using the **MEXE02**, **OPX-2A** or via RS-485 communication.

Example: Hardware overtravel alarm [number of times the ALM LED (or ALARM LED) blinks: 7]



■ Alarm reset

Perform one of the reset operations specified below. Before resetting an alarm, always remove the cause of the alarm and ensure safety. Refer to p.323 for the timing chart.

- Turn the ALM-RST input from ON to OFF. (The alarm will be reset at the OFF edge of the input.)
- Perform the alarm reset via RS-485 communication.
- Perform the alarm reset using the **MEXE02** or **OPX-2A**.
- Cycle the power.

■ Alarm records

Up to 10 generated alarms are saved in the non-volatile memory in order of the latest to oldest.

Alarm records saved in the non-volatile memory can be read and cleared when performing any of the following.

- Read the alarm records by the monitor command via RS-485 communication.
- Clear the alarm records by the maintenance command via RS-485 communication.
- Read and clear the alarm records using the **MEXE02** or **OPX-2A**.

■ Alarm list

Code	Number of times the ALARM LED blinks	Alarm type	Cause
10h	4	Excessive position deviation	<ul style="list-style-type: none"> When the motor was in a state of current on, the deviation between the command position and actual position at the motor output shaft exceeded the value set in the "Excessive position deviation alarm at current ON" parameter. The load is large, or the acceleration/deceleration is too short. The motor cable was disconnected.
12h		Excessive position deviation during current OFF	The C-ON input was turned ON while an excessive position deviation warning during current OFF was present.
20h	5	Overcurrent	The motor, cable and driver output circuit were short-circuited.
21h	2	Main circuit overheat	The internal temperature of the driver exceeded 85 °C (185 °F).
22h	3	Overvoltage	The power supply voltage exceeded the permissible value. A large inertia load was stopped abruptly or vertical operation was performed.
23h		Main power off *2	The motor was started when the main power supply had been cut off.
25h		Undervoltage	The main power was cut off momentarily or the voltage became low.
28h	8	Sensor error	A sensor error occurred while the motor was operating.
29h	9	CPU peripheral circuit error	An error occurred in the CPU.
30h	2	Overload	<ul style="list-style-type: none"> A load exceeding the peak torque was applied for the time exceeded the "Overload alarm" parameter. The motor cable was disconnected.
31h		Overspeed	The actual speed of the motor output shaft exceeded 4,500 r/min.
34h	2	Command pulse error	The command pulse frequency exceeded the specified value.
41h	9	EEPROM error	The data stored in the driver was damaged.
42h	8	Initial sensor error	A sensor error occurred when the power was turned on.
43h		Initial rotor rotation error	The output shaft did not stand still when the power was turned on.
45h		Motor combination error	A motor not supported by the driver is connected.
4Ah	7	Return-to-home incomplete	The positioning operation was started when the position origin has not been set.

Remedial action	Alarm reset	Motor excitation *1
<ul style="list-style-type: none"> Reduce the load or increase the acceleration/deceleration. Increase the setting value for the "RUN current" parameter. Turn off the power supply and check the connection between the motor cable and the driver before turning on the power supply again. 	<ul style="list-style-type: none"> Turn the ALM-RST input from ON (1) to OFF (0). Perform alarm reset. 	Non-excitation
<ul style="list-style-type: none"> Do not turn the C-ON input ON while an excessive position deviation warning at current OFF is present. Set the "Automatic return operation" parameter to "disable." 		Non-excitation
Turn off the power supply, and check that the motor, cable and driver output circuit are not short-circuited before turning on the power again.	Cycle the power.	Non-excitation
Review the ventilation condition inside the enclosure.	<ul style="list-style-type: none"> Turn the ALM-RST input from ON (1) to OFF (0). Perform alarm reset. 	Non-excitation
<ul style="list-style-type: none"> Check the input voltage of the power supply. If this alarm generates during operation, reduce the load or increase the acceleration/deceleration. 	<ul style="list-style-type: none"> Cycle the power. Perform alarm reset (DC power input only). 	Non-excitation
Check if the main power supply has been input normally.	<ul style="list-style-type: none"> Turn the ALM-RST input from ON (1) to OFF (0). Perform alarm reset. 	Non-excitation
Check the input voltage of the main power supply.		Non-excitation
Turn off the power, and turn on the power again after checking the connection for the motor cable and driver.	Cycle the power.	Non-excitation
Turn on the power again. Then check that no alarm is generated and be sure to perform return-to-home operation.		Non-excitation
<ul style="list-style-type: none"> Reduce the load or increase the acceleration/deceleration. Increase the setting value for the "RUN current" parameter. Check the connection of the driver and electromagnetic brake. Turn off the power supply and check the connection between the motor cable and the driver before turning on the power supply again. 	<ul style="list-style-type: none"> Turn the ALM-RST input from ON (1) to OFF (0). Perform alarm reset. 	Non-excitation
<ul style="list-style-type: none"> Check the "Electronic gear" parameter and set the speed of the motor output shaft to 4,500 r/min or less. If the motor is overshooting at the time of acceleration, increase the acceleration. 		Non-excitation
Check the "Electronic gear" parameter and reduce the speed of the motor output shaft to 4,500 r/min or less.	<ul style="list-style-type: none"> Turn the ALM-RST input from ON (1) to OFF (0). Perform alarm reset. 	Non-excitation
Initialize the all parameters.	Cycle the power.	Non-excitation
Turn off the power supply, and check the connection of the motor cable and driver before turning on the power again.		Non-excitation
Review the load and make sure the output shaft does not turn by an external force when the power is turned on.		Non-excitation
Check the model name of motor and driver, and use the motor and driver in the correct combination.		Non-excitation
Perform the position preset or return-to-home operation.	<ul style="list-style-type: none"> Turn the ALM-RST input from ON (1) to OFF (0). Perform alarm reset. 	Excitation

Code	Number of times the ALARM LED blinks	Alarm type	Cause
51h	2	Regeneration resistor overheat *2	The regeneration resistor is not connected correctly. The regeneration resistor was overheated abnormally.
60h	7	±LS both sides active	Both the +LS input and –LS input were detected when LS detection was enabled.
61h		Reverse limit sensor connection	The limit sensor opposite to the operating direction has detected during a return-to-home operation in 2-sensor mode or 3-sensor mode.
62h		Home seeking error	Return-to-home operation did not complete normally.
63h		No HOMES	The mechanical home sensor is not detected at a position between positive direction limit sensor and negative direction limit sensor during return-to-home operation in 3-sensor mode.
64h		TIM, Z, SLIT signal error	None of the SLIT input or TIM output could be detected during return-to-home operation.
66h		Hardware overtravel	A +LS input or –LS input signal was detected when the "Hardware overtravel" parameter was enabled.
67h		Software overtravel	A software limit was reached when the "Software overtravel" parameter was enabled.
6Ah		Home seeking offset error	A limit sensor was detected during offset movement as part of return-to-home operation.
70h		Abnormal operation data	<ul style="list-style-type: none"> • Data of different directions may be linked in linked-motion operation. • Five or more data may be linked. • Positioning operation of the operating speed 0 r/min was performed. • The larger value than 500 r/min was set in the operating speed of push-motion operation.
71h		Electronic gear setting error	The resolution set in the "Electronic gear" parameter was outside of the specification.
72h	Wrap setting error	The resolution and "Wrap setting range" parameter was inconsistent.	

Remedial action	Alarm reset	Motor excitation *1	
<p>Turn off the power supply, and check the following items before turning on the power again.</p> <p>When the regeneration resistor is not used, short-circuit the TH1 and TH2 terminals on the CN1.</p> <p>Connect the regeneration resistor correctly.</p> <p>Regenerative power from the motor exceeds the allowable regenerative power of the regeneration resistor. Make sure the load and operating condition.</p>	Cycle the power.	Non-excitation	
After resetting the alarm, check the sensor logic installed and "LS contact configuration" parameter.	<ul style="list-style-type: none"> • Turn the ALM-RST input from ON (1) to OFF (0). • Perform alarm reset. 	Excitation	
After resetting the alarm, check the wiring of the limit sensor.		Excitation	
<p>An unanticipated load may have been applied during the return-to-home operation. Check the load.</p> <p>If the installation positions of limit sensor and mechanical home sensor are close to one another, the return-to-home sequence may not end properly, depending on the starting direction of return-to-home operation. Review the sensor installation positions and the starting direction of return-to-home operation.</p> <p>Return-to-home operation may have been performed in a condition where both +LS input and -LS input were detected. Check the sensor logic and "LS contact configuration" parameter.</p>		Excitation	
Set a mechanical home sensor between positive direction and negative direction limit sensors.		Excitation	
<ul style="list-style-type: none"> • Adjust the connection condition of the output shaft and load as well as the mechanical home sensor position so that at least one of the SLIT input or TIM output will turn ON while HOMES input is ON. • Set the "SLIT detection with home-seeking" parameter to "Disable" if the SLIT input are not used with HOMES, while set the "TIM signal detection with home-seeking" parameter to "Disable" if the TIM output are not used with HOMES. 		Excitation	
After resetting the alarm, escape from the limit sensor by continuous operation or by return-to-home operation.		Excitation	
In single-motion operation, check to see if the position exceeds the softlimit. In linked-motion operation, check to see if the result of linked position exceeds the softlimit.		Excitation	
After resetting the alarm, check the offset value.		Excitation	
After resetting the alarm, check the operation data.		<ul style="list-style-type: none"> • Turn the ALM-RST input from ON (1) to OFF (0). • Perform alarm reset. 	Excitation
Turn off the power supply, and set the "Electronic gear" parameter correctly so that the resolution is in a range of 100 to 10,000 P/R before turning on the power again.		Cycle the power.	Non-excitation
Turn off the power supply, and set the "Wrap setting range" parameter correctly before turning on the power again.		Non-excitation	

Code	Number of times the ALARM LED blinks	Alarm type	Cause
81h	7	Network bus error	When the motor operates, the host controller for the network converter shows a disconnected status.
83h		Communication switch setting error	Transmission rate setting switch (SW2) was out-of-specification.
84h		RS-485 communication error	The number of consecutive RS-485 communication errors reached the "Communication error alarm" parameter.
85h		RS-485 communication timeout	The time set in the "Communication timeout" parameter has elapsed, and yet the communication could not be established with the host controller.
8Eh		Network converter error	The network converter generated an alarm.
F0h	Lit	CPU error	CPU malfunctioned.

*1 An excitation state of the motor when an alarm is generated is as follows.

Non-excitation: When an alarm generates, the motor current will be cut off and the motor will lose its holding torque.

The electromagnetic brake will automatically actuate and hold the position when using the electromagnetic brake motor.

Excitation: Even when an alarm generates, the motor current will not be cut off and the motor position will be held.

*2 AC power input only.

If the alarm is not cleared even when these remedial actions have been performed, the driver may have been damaged. Contact your nearest Oriental Motor sales office.

Remedial action	Alarm reset	Motor excitation *1
Check the host controller connector or cable.	<ul style="list-style-type: none"> • Turn the ALM-RST input from ON (1) to OFF (0). • Perform alarm reset. 	Excitation
Check the transmission rate setting switch (SW2).	Cycle the power.	Non-excitation
<ul style="list-style-type: none"> • Check the connection between the host controller and driver. • Check the setting of RS-485 communication. 	<ul style="list-style-type: none"> • Turn the ALM-RST input from ON (1) to OFF (0). • Perform alarm reset. 	Excitation
Check the connection between the host controller and driver.		Excitation
Check the alarm code of the network converter.		Excitation
Cycle the power.	Cycle the power.	Non-excitation

5-2 Warning

When a warning generates, the WNG output will turn ON. The motor will continue to operate. Once the cause of the warning is removed, the WNG output will turn OFF automatically.

Warning records

Up to 10 generated warnings are saved in the RAM in order of the latest to oldest.

Warning records saved in the RAM can be read and cleared when performing any of the following.

- Read the warning records by the monitor command via RS-485 communication.
- Clear the warning records by the maintenance command via RS-485 communication.
- Read and clear the warning records using the **MEXE02** or **OPX-2A**.



You can also clear the warning records by turning off the driver power supply.

Warning list

Code	Warning type	Cause	Remedial action
10h	Excessive position deviation	<ul style="list-style-type: none"> • When the motor was in a state of current ON, the deviation between the command position and actual position at the motor output shaft exceeded the value set in the "Excessive position deviation warning at current ON" parameter. • The load is large or acceleration/deceleration is too short. 	<ul style="list-style-type: none"> • Reduce the load or increase the acceleration/deceleration. • Increase the setting value for the "RUN current" parameter.
12h	Excessive position deviation during current OFF	When the motor was in a state of current OFF, the deviation between the command position and actual position at the motor output shaft exceeded the value set in the "Excessive position deviation alarm at current OFF" parameter. (This warning is output when the "Auto return operation" parameter is set to "Enable.")	Reduce the amount of rotation at current OFF to the specified setting value or less. Or, change the setting value.
21h	Main circuit overheat	The internal temperature of the driver exceeded the value set in the "Overheat warning" parameter.	Review the ventilation condition inside the enclosure.
22h	Overvoltage	<ul style="list-style-type: none"> • The voltage of the power supply exceeded the value set in the "Overvoltage warning" parameter. • A large inertia load was stopped abruptly or vertical operation was performed. 	<ul style="list-style-type: none"> • Check the input voltage of the power supply. • If this alarm generates during operation, reduce the load or increase the acceleration/deceleration.
25h	Undervoltage	<ul style="list-style-type: none"> • The voltage of the power supply fell below the value set in the "Undervoltage warning" parameter. • The main power was cut off momentarily or the voltage became low. 	Check the input voltage of the power supply.
30h	Overload	<ul style="list-style-type: none"> • A load exceeding the peak torque was applied for the time set in the "Overload warning" parameter or longer. • The load is large or acceleration/deceleration is too short. 	<ul style="list-style-type: none"> • Reduce the load or increase the acceleration/deceleration. • Increase the setting value for the "RUN current" parameter. • Check if the electromagnetic brake is released during operation.
31h	Overspeed	The actual speed of the motor output shaft exceeded the value set in the "Overspeed warning" parameter.	<ul style="list-style-type: none"> • Check the "Electronic gear" parameter and reduce the speed of the motor output shaft to the value set in the parameter or less. • If an overshoot is occurred at the time of accelerating, increase the acceleration/deceleration.

Code	Warning type	Cause	Remedial action
71h	Electronic gear setting error	The resolution set in the "Electronic gear" parameter is outside the specified range.	Turn off the power supply, and set the "Electronic gear" parameter correctly so that the resolution is in a range of 100 to 10,000 P/R before turning on the power again.
72h	Wrap setting error	The resolution and "Wrap setting range" parameter was inconsistent.	Turn off the power supply, and set the "Wrap setting range" parameter correctly before turning on the power again.
84h	RS-485 communication error	A RS-485 communication error was detected.	<ul style="list-style-type: none"> • Check the connection between the host controller and driver. • Check the setting of RS-485 communication.

5-3 Communication errors

Up to 10 communication errors are saved in the RAM in order of the latest to the oldest and you can check using the **MEXE02** or via RS-485 communication.

■ Communication error records

Up to 10 communication errors are saved in the RAM in order of the latest to oldest.

Communication error records saved in the RAM can be read and cleared when performing any of the following.

- Read the communication error records by the monitor command via RS-485 communication.
- Clear the communication error records by the maintenance command via RS-485 communication.
- Read and clear the communication error records by the status monitor of the **MEXE02**.



You can also clear the communication records by turning off the driver power supply.

■ Communication error list

Code	Communication error type	Cause	Remedial action
84h	RS-485 communication error	One of the following errors was detected. <ul style="list-style-type: none"> • Framing error • BCC error 	<ul style="list-style-type: none"> • Check the connection between the host controller and driver. • Check the setting of RS-485 communication.
88h	Command not yet defined	The command requested by the host controller could not be executed because of being undefined.	<ul style="list-style-type: none"> • Check the setting value for the command. • Check the flame configuration.
89h	Execution disable due to user I/F communication in progress	The command requested by the host controller could not be executed since the MEXE02 or OPX-2A was communicating with the driver.	Wait until the processing for the MEXE02 or OPX-2A will be completed.
8Ah	Not possible to execute because of non-volatile memory processing	The command could not be executed because the driver was processing the non-volatile memory. <ul style="list-style-type: none"> • Internal processing was in progress. (S-BSY is ON.) • An EEPROM error alarm was present. 	<ul style="list-style-type: none"> • Wait until the internal processing will complete. • When the EEPROM error alarm was generated, initialize the parameter using the MEXE02, OPX-2A or via RS-485 communication.
8Ch	Outside setting range	The setting data requested by the host controller could not be executed due to outside the range.	Check the setting data.
8Dh	Command execute disable	When the command could not be executed, it tried to do it.	Check the driver status.

6 Troubleshooting and remedial actions

During motor operation, the motor or driver may fail to function properly due to an improper setting or wiring. When the motor cannot be operated correctly, refer to the contents provided in this chapter and take appropriate action. If the problem persists, contact your nearest Oriental Motor sales office.

Phenomenon	Possible cause	Remedial action
<ul style="list-style-type: none"> The motor is not excited. The output shaft can be moved by hand. 	The C-ON input is turned OFF.	Turn the C-ON input ON and confirm that the motor will be excited.
	The FREE input is turned ON.	Turn the FREE input OFF.
The motor has a holding torque even if it is put into a non-excitation state. *	Effect of dynamic brake.	If the motor is put into a non-excitation state using the C-ON input or the STOP input, the motor windings is in a state of being short-circuited in the driver, and the holding torque larger than when the power is shut off is generated (dynamic brake). To release the dynamic brake, shut off the power or turn the FREE input ON.
The motor does not operate.	An electromagnetic brake motor is used and the electromagnetic brake is in the holding state.	Check the connections between electromagnetic brake and driver.
	The STOP input is turned ON.	Turn the STOP input OFF.
	The position (distance) is not set in the operation data while positioning operation.	Check the operation data.
	The FWD input and RVS input are turned ON simultaneously in the continuous operation.	Turn either FWD input or RVS input ON.
The output shaft rotates in the direction opposite to the specified direction.	The "Motor rotation direction" parameter is set wrong.	Check the setting of the "Motor rotation direction" parameter.
The gear output shaft rotates in the direction opposite to the motor output shaft.	A gear that rotates in the direction opposite to the motor output shaft is used.	<ul style="list-style-type: none"> The rotation direction of the TH geared type may differ from that of the motor output shaft depending on the frame size or the gear ratio. Refer to p.15 for details. With Harmonic geared type, the gear output shaft always rotates in the direction opposite to the motor output shaft.
Motor operation is unstable.	Connection error in the motor or power supply.	Check the connections between the driver, motor and power supply.
	The "RUN current" or "STOP current" parameter is too low.	Return the "RUN current" or "STOP current" parameter to its initial setting and check the motor operation. If the motor output torque is too large relative to the load, vibration will increase.
Motor vibration is too large.	Load is too small.	Lower the operating current using the "RUN current" parameter. If the motor output torque is too large relative to the load, vibration will increase.
The electromagnetic brake does not release.	The power is not supplied to the electromagnetic brake.	Check the connections between electromagnetic brake and driver.

* DC power input only.



- Check the alarm when the alarm generates.
- I/O signals can be monitored using the **MEXE02**, **OPX-2A** or via RS-485 communication. Use to check the wiring condition of the I/O signals.

5 Operation type and setting

This part explains the details of operation and how to set the driver function.


◆ Table of contents

1	Guidance	154	5	Return-to-home operation	179
2	Adjustment and setting	158	5-1	Operation sequence	182
2-1	Resolution	158	5-2	Position preset	187
2-2	Operating current.....	159	6	Continuous operation	188
2-3	Standstill current.....	159	6-1	Starting method of continuous operation	189
2-4	Acceleration/deceleration rate and acceleration/deceleration time	160	6-2	Variable speed operation.....	191
2-5	Smooth drive.....	160	7	Other operation	193
2-6	Speed filter	161	7-1	JOG operation.....	193
2-7	Moving average filter	162	7-2	Test operation	194
2-8	Speed error gain.....	162	7-3	Automatic return operation.....	195
2-9	Control mode.....	163	7-4	Stop operation.....	196
2-10	Position loop gain, speed loop gain, speed loop integral time constant	163	8	Coordination management.....	198
3	Operation type and function list	164	8-1	Position coordinate management.....	198
4	Positioning operation.....	165	8-2	Wrap function	198
4-1	Operation data	165			
4-2	Starting method of positioning operation	167			
4-3	Operation function	172			
4-4	Push-motion operation	176			

1 Guidance

If you are new to the **AR** Series built-in controller type, read this section to understand the operating methods along with the operation flow.

This section explains an example to perform positioning operation using the **MEXE02**.



■ Checking the factory setting

Setting item	Factory setting
Resolution	1,000 P/R (0.36°/step)
Operating current	1,000 (Base current rate 100 %)
Speed filter	1 ms
Home	Motor position at power on


Note Before operating the motor, check the condition of the surrounding area to ensure safety.

STEP 1 Make preparations for operation

1. Wire the driver by reference to the figure.


● AC power input

Be sure to connect a 24 VDC power supply.



* These cables are provided as our products. Purchase them separately.

● DC power input




*1 This cable is provided as our product. When the length of the motor cable is not enough, purchase it separately.

*2 This cable is provided as our product. Purchase it separately.

2. Start the **MEXE02**, and turn on the driver main power supply.
Refer to the Support software **MEXE02 OPERATING MANUAL** for how to start or use the **MEXE02**.


STEP 2 Set the operation data using the MEXE02

1. Using the **MEXE02**, set the operation data of No.1 as follows.




	Operation mode	Position [step]	Operating speed [Hz]	Operation function	Push current [%]	Dwell time [s]	Sequential positioning	Acceleration [ms/kHz] or [s]	Deceleration [ms/kHz] or [s]
#0	Incremental (INC)	0	1000	Single-motion	20.0	0.000	Disable	1.000	1.000
#1	Incremental (INC)	8500	2000	Single-motion	20.0	0.000	Disable	1.500	1.500


- Click the [Teaching, remote operation] short-cut button in the left side of the screen. The teaching, remote operation window appears.




- Click "Start the teaching remote operation," and click [Yes] on the pop-up window (Warning).



- Write the edited data to the driver. Click "Writing all data. (PC -> Product)," and click [OK]. The contents of the data No.1 will be written to the driver.




- Select the operation data No.1.




STEP 3 Operate the motor

1. Click [Start positioning operation].
Since the pop-up window (Warning) is displayed, click [Yes].
The motor performs positioning operation.



2. Check that the command position and actual position have changed to 8,500.
If they are 8,500, positioning operation is performed properly.



3. To end the teaching, remote operation, unselect "Start the teaching remote operation."

Positioning operation has been completed.

2 Adjustment and setting

This chapter explains how to adjust/set the motor and driver functions. When a parameter is changed, the timing to update the new value varies depending on the parameter. Refer p.110 for details.

2-1 Resolution

Set a resolution when using in combination with a mechanism product such as a geared motor or an actuator. When the "Electronic gear A" and "Electronic gear B" parameters are set, the resolution per one rotation of the motor output shaft can be set. Note that the calculated value must fall within the setting range specified next:

Resolution setting range: 100 to 10,000 P/R

$$\text{Resolution} = 1,000 \times \frac{\text{Electronic gear B}}{\text{Electronic gear A}}$$

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Coordinates	Electronic gear A	Sets the denominator of electric gear. [Setting range] 1 to 65,535	1
	Electronic gear B	Sets the numerator of electric gear. [Setting range] 1 to 65,535	1



- If the value outside of the setting range is set, the "electronic gear setting error warning" will generate. If the power is cycled or the configuration is executed while the "electronic gear setting error warning" is present, an "electronic gear setting error alarm" will generate.
- When the TIM output is used, set the "Electronic gear" parameters to be an integral multiple of 50.

■ Calculation of electronic gear A and B

Calculation of electronic gear A and B is explained with examples of a ball screw and rotary table.

● Example: Ball screw

Ball screw lead : 12 mm
 Minimum travel amount : 0.01 mm
 Gear ratio : 1 (No speed reduction mechanism between the motor and ball screw)

$$\text{Resolution} = 1,000 \times \frac{\text{Electronic gear B}}{\text{Electronic gear A}} = \frac{\text{Ball screw lead}}{\text{Minimum travel amount}} \times \text{Gear ratio}$$

$$\text{In this example: } 1,000 \times \frac{\text{Electronic gear B}}{\text{Electronic gear A}} = \frac{12 \text{ mm}}{0.01 \text{ mm}} \times 1$$

$$\text{Result: } \frac{\text{Electronic gear B}}{\text{Electronic gear A}} = \frac{12}{10}$$

Therefore, the electronic gear A and B are 10 and 12 respectively, and the resolution will be 1,200 P/R.

- **Example: Rotary table**

Step angle per one rotation : 360°
 Minimum step angle : 0.01°
 Gear ratio : 10 [Using the geared motor (gear ratio 10:1)]

$$\text{Resolution} = 1,000 \times \frac{\text{Electronic gear B}}{\text{Electronic gear A}} = \frac{\text{Minimum step angle}}{\text{Step angle per one rotation}} \times \text{Gear ratio}$$

$$\text{In this example: } 1,000 \times \frac{\text{Electronic gear B}}{\text{Electronic gear A}} = \frac{360^\circ}{0.01^\circ} \times \frac{1}{10}$$

$$\text{Result: } \frac{\text{Electronic gear B}}{\text{Electronic gear A}} = \frac{36}{10}$$

Therefore, the electronic gear A and B are 10 and 36 respectively, and the resolution will be 3,600 P/R.

2-2 Operating current

The maximum driver operating current can be changed using the "RUN current" parameter. If the load is small and there is an ample allowance for torque, the motor temperature rise can be suppressed by setting a lower operating current.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Motor	RUN current	Sets the motor operating current based on the rated current being 100 %. [Setting range] 0 to 1,000 (1=0.1 %)	1,000



Excessively low operating current may cause a problem in starting the motor or holding the load in position. Do not lower the operating current more than necessary.

2-3 Standstill current

When the motor stops, the current cutback function will be actuated to lower the motor current to the standstill current. The standstill current is a value in which the set value of the "STOP current" parameter is multiplied by the rated current (100 %). The standstill current does not change even when the "RUN current" parameter has been changed.

Related parameter



MEXE02 tree view	Parameter name	Description	Initial value
Motor	STOP current	Sets the motor standstill current as a percentage of the rated current, based on the rated current being 100 %. [Setting range] 0 to 500 (1=0.1 %)	500

2-4 Acceleration/deceleration rate and acceleration/deceleration time

Acceleration/deceleration unit

Set the acceleration/deceleration unit using the "Acceleration/deceleration unit" parameter. Acceleration/deceleration rate (ms/kHz) or acceleration/deceleration time (s) can be set.

- Acceleration/deceleration unit: ms/kHz
- Acceleration/deceleration unit: s



VS: Starting speed
VR: Operating speed
TA: Acceleration
TD: Deceleration

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Operation	Acceleration/ deceleration unit	Sets the acceleration/deceleration unit. [Setting range] 0: ms/kHz 1: s	0

Common setting and separate setting of the acceleration/deceleration

The acceleration/deceleration for positioning operation or continuous operation can be set as follows using the "Acceleration/deceleration type" parameter:

Separate: The acceleration/deceleration set under the applicable operation data No. will be followed.

Common: The setting of the "Common acceleration" and "Common deceleration" parameters will be followed.



- When performing linked operation, the acceleration/deceleration for the starting linked operation data No. is applied even when the "Acceleration/deceleration type" parameter is set to "Separate."
- Refer to p.191 for the acceleration/deceleration when performing variable speed operation.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Operation	Acceleration/ deceleration type	Sets whether to use the common acceleration/ deceleration or the acceleration/deceleration specified for the operationdata. [Setting range] 0: Common 1: Separate	1

2-5 Smooth drive

You can achieve lower vibration and smoother movement using the smooth drive function.

You may feel vibration in the low speed range when this function is set to "disable." Set the function to "enable" under normal conditions of use.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Motor	Smooth drive	Sets whether to enable or disable smooth drive function. [Setting range] 0: Disable 1: Enable	1


2-6 Speed filter

If the "Filter selection" parameter is set to "Speed filter," the motor response can be adjusted with the "Speed filter" parameter.

When the speed filter level is raised, vibration can be suppressed during low-speed operation, and starting/stopping of the motor will become smooth. Note, however, that an excessively high filter level will result in lower synchronicity with commands. Set an appropriate value according to the specific load and purpose.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Motor	Filter selection	Sets the filter function to adjust the motor response. [Setting range] 0: Speed filter 1: Moving average filter	0
	Speed filter	Adjusts the motor response. [Setting range] 0 to 200 ms	1



When setting the value of the "Speed filter" parameter to "0," this function will be invalid.

2-7 Moving average filter


The motor response can be adjusted when setting the "Filter selection" parameter to "Moving average filter" and setting the value for the "Moving average time" parameter.

The positioning time can be shortened by suppressing the residual vibration for the positioning operation.

Optimum value for the "Moving average time" parameter varies depending on the load or operation condition. Set a suitable value based on the load or application.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Motor	Filter selection	Sets the filter function to adjust the motor response. [Setting range] 0: Speed filter 1: Moving average filter	0
	Moving average time	Sets the time constant for the moving average filter. [Setting range] 1 to 200 ms	1



2-8 Speed error gain

The speed error gain is used to suppress vibration while the motor is operating or accelerating/decelerating.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Motor	Speed difference gain 1	Adjusts vibration during operation. [Setting range] 0 to 500	45
	Speed difference gain 2	Adjusts vibration during acceleration/deceleration. [Setting range] 0 to 500	45

2-9 Control mode

The driver operates in one of two control modes: the normal mode, and the current control mode. If noise is heard during high-speed operation or there is notable vibration, it may be effective to switch to the current control mode. Note, however, that a slight delay may occur in the current control mode, compared to the normal mode, depending on the condition of the load. Keep the driver in the normal mode during normal conditions of use.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Motor	Control mode	Sets the control mode of the driver. [Setting range] 0: Normal mode 1: Current control mode	0

2-10 Position loop gain, speed loop gain, speed loop integral time constant

These items are effective in the current control mode. Vibration that occurs while the motor is accelerating/decelerating or at standstill can be adjusted to an optimal value. (The optimal value varies depending on the equipment and operating conditions.)

Related parameter


MEXE02 tree view	Parameter name	Description	Initial value
Motor	Position loop gain	Adjusts the motor response in reaction to the position deviation. When this value is increased, the deviation between the command position and actual position will be small. An excessively high value may increase the motor overshooting or cause motor hunting. [Setting range] 1 to 50	10
	Speed loop gain	Adjusts the motor response in reaction to the speed deviation. When this value is increased, the deviation between the command speed and actual speed will be small. An excessively high value may increase the motor overshooting or cause motor hunting. [Setting range] 10 to 200	180
	Speed loop integral time constant	Adjusts the deviation that cannot be adjusted with the speed loop gain. An excessively high value may slow the motor response. On the other hand, an excessively low value may cause motor hunting. [Setting range] 100 to 2,000 (1=0.1 ms)	1,000

3 Operation type and function list

Operation

[Setting by operation data and parameters]


Positioning operation




Starting method

- Data number selecting operation
- Direct positioning operation
- Sequential positioning operation

Return-to-home operation



Continuous operation



Other operations

- JOG operation
- Automatic return operation

Function

[Setting by parameters]

<ul style="list-style-type: none"> • I/O Input logic level STOP input action Overtravel 	<ul style="list-style-type: none"> • Motor function Operating current Standstill current Speed filter Moving average filter 	<ul style="list-style-type: none"> • Operation function Acceleration/deceleration type Acceleration/deceleration unit JOG operation Automatic return operation 	<ul style="list-style-type: none"> • Return-to-home function Home offset External sensor signal detection Return-to-home speed Return-to-home starting direction
<ul style="list-style-type: none"> • I/O function Input function Input logic Output function 	<ul style="list-style-type: none"> • I/O function (RS-485) Input function Output function 	<ul style="list-style-type: none"> • Alarm/warning Alarm detection Warning detection 	<ul style="list-style-type: none"> • Coordination setting Resolution (electronic gear) Wrap function Motor rotation direction

4 Positioning operation

Positioning operation is one in which motor operating speed, position (travel amount) and other items are set as operation data and then executed. When the positioning operation is executed, the motor begins at the starting speed and accelerates until the operating speed is reached. Then, once the operating speed is reached, that speed is maintained. The motor decelerates when the stopping position approaches, and finally comes to a stop.

The operation function can also be set in operation data. The operation function is how to operate consecutive operation data (example: operation data No.0, No.1, No.2).

4-1 Operation data

The following data are the operation data for positioning operation. Up to 64 operation data can be set (data Nos.0 to 63).

MEXE02 tree view	Setting item	Description	Initial value
Operation data	Position	Sets the position (distance) for positioning operation. [Setting range] –8,388,608 to +8,388,607 step	0
	Operating speed	Sets the operating speed in positioning operation. [Setting range] 0 to 1,000,000 Hz	1,000
	Acceleration	Sets the acceleration rate (acceleration time) in positioning operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s)	1,000
	Deceleration	Sets the deceleration rate (deceleration time) in positioning operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s)	1,000
	Operation mode	Selects how to specify the position (travel amount) in positioning operation. [Setting range] 0: Incremental (INC) 1: Absolute (ABS)	0
	Operation function	Sets the operation mode to execute positioning operation. [Setting range] 0: Single-motion 1: Linked-motion 2: Linked-motion 2 3: Push	0
	Dwell time	Sets the dwell time to be used in linked-motion 2 operation. [Setting range] 0 to 50,000 (1=0.001 s)	0
	Push current	Sets the current rate of push-motion operation. [Setting range] 0 to 1,000 (1=0.1 %)	200
	Sequential positioning	Sets whether to enable or disable sequential positioning operation. [Setting range] 0: Disable 1: Enable	0


● **Position, operating speed, acceleration, deceleration**

The acceleration/deceleration for positioning operation can be set as follows using the "Acceleration/deceleration type" parameter:


Separate : The acceleration/deceleration set under the applicable operation data No. will be followed (Each 64 data for acceleration and deceleration).

Common : The setting of the "Common acceleration" and "Common deceleration" parameter will be followed (Each one data for acceleration and deceleration).

When the starting speed < operating speed



When the starting speed ≥ operating speed




● **Operation mode**

The following two operation modes are available:

Absolute (ABS) mode

The position (distance) from home is set [Absolute positioning].


Example: When positioning operation is performed with setting the starting point to 1,000 and setting the destination to +3,000 and -3,000



Incremental (INC) mode

Each motor destination becomes the starting point for the next movement. This mode is suitable when the same position (distance) is repeatedly used [Incremental positioning].

Example: When positioning operation is performed with setting the starting point to 1,000 and setting the destination to +3,000 and -3,000



● **Operation function, dwell time**

The following four operation function are available:

Operation function	Description	Ref.
Single-motion	A single operation data set is executed.	p.172
Linked-motion	Multiple sets of operation data are linked to execute multi-speed positioning operation.	p.173
Linked-motion 2	Dwell time (stop waiting time) can be set between operation data. Operation data whose rotation direction is different can also be linked.	p.174
Push-motion	This is an operation of continuously applying pressure on the load when pressing against the load during positioning operation.	p.176

4-2 Starting method of positioning operation

The following three types are available in the starting method.

Starting method	Description
Data number selecting operation	When the START input is turned ON with selecting the operation data No. by a combination of the M0 to M5 inputs, the positioning operation will perform.
Direct positioning operation	When any of the MS0 to MS5 inputs is turned ON, the positioning operation corresponding to the input data No. will perform.
Sequential positioning operation	Positioning operation is performed to the next operation data No. every time a SSTART input signal is input.


■ Data number selecting operation

Select an operation data based on a combination of ON/OFF status of the M0 to M5 inputs. Refer p.93 for details.

Operation data No.	M5	M4	M3	M2	M1	M0
0	OFF	OFF	OFF	OFF	OFF	OFF
1	OFF	OFF	OFF	OFF	OFF	ON
2	OFF	OFF	OFF	OFF	ON	OFF
·	·	·	·	·	·	·
·	·	·	·	·	·	·
·	·	·	·	·	·	·
61	ON	ON	ON	ON	OFF	ON
62	ON	ON	ON	ON	ON	OFF
63	ON	ON	ON	ON	ON	ON

Operating method

- 1) Check the READY output is ON.
- 2) Select the operation data No. by a combination of the M0 to M5 inputs and turn the START input ON.
- 3) The motor starts positioning operation.
- 4) Check that the READY output has been turned OFF and turn the START input OFF.
- 5) When the positioning operation is completed, the READY output will be turned ON.



* In direct I/O, turn the START input ON after setting the M0 to M5 inputs. In remote I/O, the operation will be performed even when turning the M0 to M5 inputs and the START input ON simultaneously.

■ Direct positioning operation

When any of the MS0 to MS5 inputs is turned ON, the positioning operation corresponding to the input data No. will perform. Since the positioning operation is enabled by turning any of the MS0 to MS5 inputs ON, you can save the step of selecting the operation data No.


The operation data assigning to the MS0 to MS5 inputs will be set by parameters.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	MS0 operation No. selection	Sets the operation data No. corresponding to MS0 to MS5 input. [Setting range] 0 to 63	0
	MS1 operation No. selection		1
	MS2 operation No. selection		2
	MS3 operation No. selection		3
	MS4 operation No. selection		4
	MS5 operation No. selection		5

Operating method

- 1) Check the READY output is ON.
- 2) Turn the MS0 input ON.
- 3) The motor starts positioning operation.
- 4) Check that the READY output has been turned OFF and turn the MS0 input OFF.
- 5) When the positioning operation is completed, the READY output will be turned ON.



■ Sequential positioning operation

In sequential positioning operation, whenever turning the SSTART input ON, the positioning operation for the following operation data No. will be performed. This function is useful when multiple positioning operations must be performed sequentially, because there is no need to select each data number.

When the "sequential positioning" of operation data is executed up to the data No. set to "disable", the operation returns to the original data No. that was selected before starting the sequential positioning operation. And the sequential positioning operation will start again.


If the starting point for the sequential positioning operation is changed using the M0 to M5 inputs or the MS0 to MS5 inputs, multiple sequential positioning operations can be set. It is convenient for setting a different operating pattern for each component or each process of works.

● When the operating pattern is one type

- 1) The positioning operation for the operation data No.0 is performed by turning the SSTART input ON.
- 2) After the operation 1) is completed, when turning the SSTART input ON again, the positioning operation for the operation data No.1 will be performed.
- 3) After the operation 2) is completed, when turning the SSTART input ON again, the positioning operation for the operation data No.2 will be performed.
- 4) After the operation 3) is completed, when turning the SSTART input ON again, the positioning operation will be performed by returning to the operation data No.0 because the sequential positioning for the operation data No.3 has been set to "disable."

Setting example

Operation data	Sequential positioning
No.0	Enable
No.1	
No.2	
No.3	Disable




- When the operating patterns are multiple

- 1) After selecting the operation data No.3 that is the starting point for the sequential positioning operation, the positioning operation will be performed by turning the START input ON.
- 2) After the operation 1) is completed, when turning the SSTART input ON again, the positioning operation for the operation data No.4 will be performed.
- 3) After the operation 2) is completed, when turning the SSTART input ON again, the positioning operation for the operation data No.5 will be performed.
- 4) After the operation 3) is completed, when turning the SSTART input ON again, the positioning operation will be performed by returning to the operation data No.3 because the sequential positioning for the operation data No.6 has been set to "disable."
- 5) After the operation 4) is completed, the positioning operation is performed by selecting the operation No.7 and turning the START input ON.
- 6) The operation data No.7 becomes a starting point for a new sequential positioning operation.
- 7) After the operation 5) is completed, when turning the SSTART input ON again, the positioning operation for the operation data No.8 will be performed.
- 8) When turning the SSTART input ON again after the operation 6) is completed, the positioning operation will be performed by returning to the operation data No.7 because the sequential positioning for the operation data No.9 has been set to "disable."


Setting example

Operation data	Sequential positioning
No.3	Enable
No.4	
No.5	
No.6	Disable
No.7	Enable
No.8	
No.9	Disable



● Operating method

- 1) Check the READY output is ON.
- 2) Turn the SSTART input ON.
- 3) The motor starts positioning operation.
- 4) Check that the READY output has been turned OFF and turn the SSTART input OFF.
- 5) When the positioning operation is completed, the READY output will be turned ON.



● Key points about sequential positioning operation

When performing any of the following operations while sequential positioning operation is performed, the starting point for sequential positioning will be changed to the operation data No.0. And the current operation data No. is set to "-1."

- When the DC power supply is turned ON.
- When operations other than the positioning operation are performed (return-to home operation, continuous operation, etc.).
- When an alarm is generated and reset.
- When the STOP input is turned ON.
- When a signal to put the motor into a non-excitation state, such as the FREE input or C-ON input, was input.
- When the P-PRESET is executed.
- When a configuration is executed.



Set "enable" the "sequential positioning" even when sequential positioning is performed by the operation data being set to "Linked-motion" or "Linked-motion 2" in the "operation function."

4-3 Operation function


■ Single-motion operation

The positioning operation is performed only once using a single operation data set.

● Example of single-motion operation


#	Operation mode	Position [step]	Operating speed [Hz]	Operation function	Push current [%]	Dwell time [s]	Sequential positioning	Acceleration [ms/kHz] or [s]	Deceleration [ms/kHz] or [s]
#0	Incremental (INC)	0	1000	Single-motion	20.0	0.000	Disable	1.000	1.000
#1	Incremental (INC)	5000	5000	Single-motion	20.0	0.000	Disable	1000.000	1000.000

Operation example



Operating method

- 1) Check the READY output is ON.
- 2) Select the operation data No.1 by turning the M0 input ON and turn the START input ON.
- 3) The motor starts the positioning operation for the operation data No.1.
- 4) Check that the READY output has been turned OFF and turn the START input OFF.
- 5) When the positioning operation is completed, the READY output will be turned ON.



* In direct I/O, turn the START input ON after setting the M0 to M5 inputs. In remote I/O, the operation will be performed even when turning the M0 to M5 inputs and the START input ON simultaneously.

■ Linked-motion operation

When the "operation function" is set to "linked-motion" using operation data, positioning operation based on the next data number will be performed without stopping the motor.

If operation data includes data for which "single-motion" or "push" is set, the motor will stop after the positioning with respect to the "single" or "push" operation data is completed.

A maximum of four operation data can be linked. Note that only operation data of the same direction can be linked.




- Multiple operation data of different directions cannot be linked. An operation data error alarm will generate during operation.
- Up to four sets of operation data can be linked. When combining the linked-motion operation and the linked-motion 2 operation, make sure the total number of linked operation data sets does not exceed four. When linked-motion operation is performed with five or more sets of operation data linked together, an operation data error alarm will generate upon start of operation.
- No.0 will not be linked even when "linked-motion" is set for data No.63, because the operation pertaining to No.63 will be processed independently.
- The acceleration/deceleration in linked-motion operation corresponds to the acceleration/deceleration specified for the operation data No. with which the linked-motion operation is started.
- When the operation data linked last is being set to "push," the push speed is applied as the starting speed.

● Example of linked-motion operation


#	Operation mode	Position [step]	Operating speed [Hz]	Operation function	Push current [%]	Dwell time [s]	Sequential positioning	Acceleration [ms/kHz] or [s]	Deceleration [ms/kHz] or [s]
#0	Incremental (INC)	0	1000	Single-motion	20.0	0.000	Disable	1.000	1.000
#1	Incremental (INC)	5000	5000	Linked-motion	20.0	0.000	Disable	1000.000	1000.000
#2	Incremental (INC)	20000	10000	Single-motion	20.0	0.000	Disable	1.000	1.000

Operation example



Operating method

- 1) Check the READY output is ON.
- 2) Select the operation data No.1 by turning the M0 input ON and turn the START input ON.
- 3) The motor starts the positioning operation in which the operation data No.1 and No.2 are linked.
- 4) Check that the READY output has been turned OFF and turn the START input OFF.
- 5) When the positioning operation is completed, the READY output will be turned ON.



* In direct I/O, turn the START input ON after setting the M0 to M5 inputs. In remote I/O, the operation will be performed even when turning the M0 to M5 inputs and the START input ON simultaneously.

■ Linked-motion 2 operation

By setting the “operation function” of operation data to “Linked-motion2,” an operation data whose rotation direction is different can be linked. In this case, the system stops for the dwell time after each positioning operation, and then performs operation according to the next operation data. If operation data includes data for which “single-motion” or “push” is set, the motor will stop after the positioning with respect to the “single” or “push” operation data is completed.




- Up to four sets of operation data can be linked. When combining the linked-motion operation and the linked-motion 2 operation, make sure the total number of linked operation data sets does not exceed four. When linked-motion operation is performed with five or more sets of operation data linked together, an operation data error alarm will generate upon start of operation.
- No.0 will not be linked even when “linked-motion2” is set for data No.63, because the operation pertaining to No.63 will be processed independently.

● Example of linked-motion 2 operation


	Operation mode	Position [step]	Operating speed [Hz]	Operation function	Push current [%]	Dwell time [s]	Sequential positioning	Acceleration [ms/kHz] or [s]	Deceleration [ms/kHz] or [s]
#0	Incremental (INC)	0	1000	Single-motion	20.0	0.000	Disable	1.000	1.000
#1	Incremental (INC)	5000	5000	Linked-motion 2	20.0	1.000	Disable	1000.000	1000.000
#2	Incremental (INC)	-3000	3000	Single-motion	20.0	0.000	Disable	1000.000	1000.000

Operation example



Operating method

- 1) Check the READY output is ON.
- 2) Select the operation data No.1 by turning the M0 input ON and turn the START input ON.
- 3) The motor starts the positioning operation for the operation data No.1.
- 4) Check that the READY output has been turned OFF and turn the START input OFF.
- 5) When the positioning operation 3) is completed, the MOVE output will be turned OFF.
- 6) When the dwell time has passed, the positioning operation for the operation data No.2 will automatically start. At the same time, the MOVE output will be turned ON.
- 7) When the positioning operation for the operation data No.2 is completed, the READY output will be turned ON.




* In direct I/O, turn the START input ON after setting the M0 to M5 inputs. In remote I/O, the operation will be performed even when turning the M0 to M5 inputs and the START input ON simultaneously.

● **Example of linked-motion 2 operation;
When combining the linked-motion operation and the linked-motion 2 operation**


#	Operation mode	Position [step]	Operating speed [Hz]	Operation function	Push current [%]	Dwell time [s]	Sequential positioning	Acceleration [ms/kHz] or [s]	Deceleration [ms/kHz] or [s]
#0	Incremental (INC)	0	1000	Single-motion	20.0	0.000	Disable	1.000	1.000
#1	Incremental (INC)	5000	3000	Linked-motion	20.0	0.000	Disable	1000.000	1000.000
#2	Incremental (INC)	10000	5000	Linked-motion	20.0	0.000	Disable	1.000	1.000
#3	Incremental (INC)	25000	7000	Linked-motion 2	20.0	1.000	Disable	1.000	1.000
#4	Absolute (ABS)	0	7000	Single-motion	20.0	0.000	Disable	1000.000	1000.000

Operation example



Operating method

- 1) Check the READY output is ON.
- 2) Select the operation data No.1 by turning the M0 input ON and turn the START input ON.
- 3) The motor starts the positioning operation in which the operation data from No.1 to No.3 are linked.
- 4) Check that the READY output has been turned OFF and turn the START input OFF.
- 5) When the positioning operation 3) is completed, the MOVE output will be turned OFF.
- 6) When the dwell time has passed, the positioning operation for the operation data No.4 will automatically start. At the same time, the MOVE output will be turned ON.
- 7) When the positioning operation for the operation data No.4 is completed, the READY output will be turned ON.



* In direct I/O, turn the START input ON after setting the M0 to M5 inputs. In remote I/O, the operation will be performed even when turning the M0 to M5 inputs and the START input ON simultaneously.

4-4 Push-motion operation

When the "operation function" is set to "push," the motor performs an operation of continuously applying pressure on the load when pressing against the load. In push-motion operation, the motor performs constant speed operation at the operating speed of the selected operation data No. but the acceleration/deceleration will not be applied. The motor becomes push-motion status when pressing against the load, and the TLC output and READY output are turned ON. The set current value of push-motion operation is applied to the motor current. When the operation was completed with non-push-motion status, the motor stops, and the END output and READY output are turned ON. The set current of push-motion operation is applied to the motor current at standstill. When the STOP input is turned ON, the motor stops, and the END output and READY output are turned ON. The STOP current is applied to the motor current at standstill.


Note Do not perform push-motion operation with geared motors. Doing so may cause damage to the motor or gear part.

- memo**
- Regardless of resolution, the maximum speed of push-motion operation is 500 r/min. If the push-motion operation is started by setting higher speed than 500 r/min, an operation data error alarm will generate.
 - If push-motion operation is performed for a long time while a large push-motion current is set, the driver may increase heat generation and generate the main circuit overheat alarm.

• Example of push-motion operation; When it had pressed against the load


	Operation mode	Position [step]	Operating speed [Hz]	Operation function	Push current [%]	Dwell time [s]	Sequential positioning	Acceleration [ms/kHz] or [s]	Deceleration [ms/kHz] or [s]
#0	Incremental (INC)	0	1000	Single-motion	20.0	0.000	Disable	1.000	1.000
#1	Incremental (INC)	5000	500	Push	50.0	0.000	Disable	1.000	1.000

Operation example



Operating method


- 1) Check the READY output is ON.
- 2) Select the operation data No.1 by turning the M0 input ON and turn the START input ON.
- 3) The motor starts the positioning operation for the operation data No.1.
- 4) Check that the READY output has been turned OFF and turn the START input OFF.
- 5) When the motor becomes push-motion status, the TLC output will be turned ON and then the READY output will be turned ON.



* In direct I/O, turn the START input ON after setting the M0 to M5 inputs. In remote I/O, the operation will be performed even when turning the M0 to M5 inputs and the START input ON simultaneously.


● Example of push-motion operation; When it had not pressed against the load

Operation example



Operating method

- 1) Check the READY output is ON.
- 2) Select the operation data No.1 by turning the M0 input ON and turn the START input ON.
- 3) The motor starts the positioning operation for the operation data No.1.
- 4) Check that the READY output has been turned OFF and turn the START input OFF.
- 5) When the motor reaches to the target position, the operation will be stopped and the READY output will be turned ON. Since the motor did not become push-motion status, the TLC output remains OFF.




* In direct I/O, turn the START input ON after setting the M0 to M5 inputs. In remote I/O, the operation will be performed even when turning the M0 to M5 inputs and the START input ON simultaneously.

● Example of push-motion operation; When combining the linked-motion operation and the push-motion operation


#	Operation mode	Position [step]	Operating speed [Hz]	Operation function	Push current [%]	Dwell time [s]	Sequential positioning	Acceleration [ms/kHz] or [s]	Deceleration [ms/kHz] or [s]
#0	Incremental (INC)	0	1000	Single-motion	20.0	0.000	Disable	1.000	1.000
#1	Incremental (INC)	5000	5000	Linked-motion	20.0	0.000	Disable	1000.000	1000.000
#2	Incremental (INC)	5000	500	Push	50.0	0.000	Disable	1.000	1.000

Operation example



Operating method

- 1) Check the READY output is ON.
- 2) Select the operation data No.1 by turning the M0 input ON and turn the START input ON.
- 3) The motor starts the positioning operation in which the operation data No.1 and No.2 are linked.
- 4) Check that the READY output has been turned OFF and turn the START input OFF.
- 5) When the motor becomes push-motion status, the TLC output will be turned ON and then the READY output will be turned ON.



* In direct I/O, turn the START input ON after setting the M0 to M5 inputs. In remote I/O, the operation will be performed even when turning the M0 to M5 inputs and the START input ON simultaneously.

5 Return-to-home operation

Return-to-home is an operation in which the reference point of positioning (mechanical home) is detected automatically. Return-to-home operation is performed to return to the home from the current position when the power supply is turned on or the positioning operation is completed.

Return-to-home operation can be performed in the following four modes:

Operation type	Description	Feature
3-sensor mode	The motor operates at the "operating speed of home-seeking." When the HOME sensor is detected, the motor will stop and the stop position will be the home.	<ul style="list-style-type: none"> • 3 external sensors are needed. *3 • Operating speed is high (Operating speed of home-seeking).
2-sensor mode	The motor operates at the "starting speed of home-seeking." When the limit sensor is detected, the motor will rotate in the reverse direction and escape from the limit sensor. After escaping from the limit sensor, the motor will move 200 steps and stop, and then the stop position will be the home. *2	<ul style="list-style-type: none"> • 2 external sensors are needed. • Operating speed is low (Starting speed of home-seeking).
Push mode *1	The motor operates at the "starting speed of home-seeking." When the moving part for the motor is pressed against a mechanical stopper etc., the motor will rotate in the reverse direction. After reversing, the motor will move 200 steps and stop, and then the stop position will be the home. *2	<ul style="list-style-type: none"> • No external sensor is needed. • Operating speed is low (Starting speed of home-seeking).
Position preset	When executing the P-PRESET at the position that the motor stops, the command position will be the value of the "Preset position" parameter. The home can be set to any position.	<ul style="list-style-type: none"> • No external sensor is needed. • The home can be set to any position.

*1 Do not perform push-mode return-to-home operation for geared motors.

*2 It moves 200 steps regardless of resolution. Therefore, the actual travel distance may vary according to resolution.

*3 The home can be detected even one piece of the external sensor. In that case, connect only the HOME sensor.


■ Additional function

Additional function	2-sensor mode 3-sensor mode Push mode	Position preset	Related parameter
Home offset	Possible	Not possible	Position offset of home-seeking
External sensor (signal) detection	Possible	Not possible	SLIT detection with home-seeking TIM signal detection with home-seeking
Command position after returning to home	The position becomes "0"	Any position	Preset position

● Home offset

This is a function to perform positioning operation of the offset amount set by the parameter after return-to-home operation and to set the stop position to the home. The position set by the home offset is called "electrical home" in distinction from the usual home.

If the amount of offset from mechanical home is "0," the mechanical home and electrical home will become the same.



- **Detecting the external sensor (signal)**

When detecting the home, use of the SLIT input and/or TIM signal will increase the accuracy of home detection.



When the TIM output is used, set the resolution to be an integral multiple of 50.

- **Command position after returning to home**

When executing the P-PRESET at the position that the motor stops, the command position will be the value of the "Preset position" parameter.

- **Parameters related to return-to-home operation**

MEXE02 tree view	Parameter name	Description	Initial value
Home operation	Home-seeking mode	Sets the mode for return-to-home operation. [Setting range] 0: 2-sensor mode 1: 3-sensor mode 2: Push mode	1
	Operating speed of home-seeking	Sets the operating speed for return-to-home operation. [Setting range] 1 to 1,000,000 Hz	1,000
	Acceleration/ deceleration of home-seeking	Sets the acceleration/deceleration rate (acceleration/deceleration time) for return-to-home operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s)	1,000
	Starting speed of home-seeking	Sets the starting speed for return-to-home operation. [Setting range] 1 to 1,000,000 Hz	500
	Position offset of home-seeking	Sets the amount of offset from mechanical home. [Setting range] -8,388,608 to 8,388,607 step	0
	Starting direction of home-seeking	Sets the starting direction for home detection. [Setting range] 0: Negative side 1: Positive side	1
	SLIT detection with home-seeking	Sets whether or not to concurrently use the SLIT input for return-to-home operation. [Setting range] 0: Disable 1: Enable	0
	TIM signal detection with home-seeking	Sets whether or not to concurrently use the TIM signal for return-to-home operation. [Setting range] 0: Disable 1: Enable	0
	Operating current of home-seeking with push-motion	Sets the operating current for push-motion return-to-home operation based on the rated current being 100 %. [Setting range] 0 to 1,000 (1=0.1 %)	1,000

5-1 Operation sequence

3-sensor mode

VS: Starting speed of home-seeking

VR: Operating speed of home-seeking

VL: Last speed of return-to-home (When VS < 500 Hz: VS, When VS ≥ 500 Hz: 500 Hz)

--- Broken line indicates a home offset move.

Starting position of return-to-home operation	Starting direction of return-to-home operation: Positive direction	Starting direction of return-to-home operation: Negative direction
-LS		
+LS		
HOMES		
Between HOMES and -LS		
Between HOMES and +LS		

When using the HOME sensor only

If the limit sensor is not used such as a rotating mechanism, operation sequences are as follows.

Starting position of return-to-home operation	Starting direction of return-to-home operation: Positive direction	Starting direction of return-to-home operation: Negative direction
HOMES		
Not HOMES		



Depending on the setting value of the "Acceleration/deceleration of home-seeking" parameter, the motor may decelerate to a stop in excess of the HOME sensor after the HOME sensor was detected. Since there is a risk of contact if the distance between the mechanical end and the HOME sensor is close, provide enough distance between them.

● When concurrently using the SLIT input and/or TIM signal

After the ON edge of the HOME sensor is detected, the return-to-home operation will continue until the external sensor (signal) will be detected. If the external sensor (signal) is detected while the HOME sensor is ON, the return-to-home operation will complete.

Operation sequence after detecting the ON edge of the HOME sensor

Home detection signal	Starting direction of return-to-home operation: Positive direction	Starting direction of return-to-home operation: Negative direction
SLIT input		
TIM signal		
SLIT input and TIM signal		

■ 2-sensor mode

VS: Starting speed of home-seeking

VR: Operating speed of home-seeking

VL: Last speed of return-to-home (When VS < 500 Hz: VS, When VS ≥ 500 Hz: 500 Hz)

- - - Broken line indicates a home offset move.

Starting position of return-to-home operation	Starting direction of return-to-home operation: Positive direction	Starting direction of return-to-home operation: Negative direction
-LS		
+LS		
Between -LS and +LS		

* After pulling out of the limit sensor, the motor will move 200 steps.

● **When concurrently using the SLIT input and/or TIM signal**

When the limit sensor is detected, the motor will rotate in the reverse direction and escape from the limit sensor. After escaping from the limit sensor, the motor will move 200 steps and stop once. Then, the motor operation will continue until the external sensor (signal) will be detected. When the external sensor (signal) is detected, return-to-home operation will complete.

Operation sequence after detecting the ON edge of the limit sensor

Home detection signal	Starting direction of return-to-home operation: Positive direction	Starting direction of return-to-home operation: Negative direction
SLIT input		
TIM signal		
SLIT input and TIM signal		

* After pulling out of the limit sensor, the motor will move 200 steps.

■ **Push mode**

VS: Starting speed of home-seeking

VR: Operating speed of home-seeking

VL: Last speed of return-to-home (When VS < 500 Hz: VS, When VS ≥ 500 Hz: 500 Hz)

- - - Broken line indicates a home offset move.

Starting position of return-to-home operation	Starting direction of return-to-home operation: Positive direction		Starting direction of return-to-home operation: Negative direction	
Negative direction mechanical end	Negative direction mechanical end Positive direction Negative direction	Positive direction mechanical end VR VS VS VR	Negative direction mechanical end Positive direction Negative direction	Positive direction mechanical end VR VS VS VR
Positive direction mechanical end	Negative direction mechanical end Positive direction Negative direction	Positive direction mechanical end VR VS VS VR	Negative direction mechanical end Positive direction Negative direction	Positive direction mechanical end VR VS VS VR
Between mechanical ends	Negative direction mechanical end Positive direction Negative direction	Positive direction mechanical end VR VS VS VR	Negative direction mechanical end Positive direction Negative direction	Positive direction mechanical end VR VS VS VR

* The motor will move 200 steps from the mechanical end.

● **When concurrently using the SLIT input and/or TIM signal**

When the moving part for the motor is pressed against a mechanical stopper etc., the motor will rotate in the reverse direction. After reversing, the motor will move 200 steps and stop once. Then, the motor operation will continue until the external sensor (signal) will be detected. When the external sensor (signal) is detected, return-to-home operation will complete.

Home detection signal	Starting direction of return-to-home operation: Positive direction		Starting direction of return-to-home operation: Negative direction	
SLIT input	<p>Negative direction mechanical end Positive direction mechanical end</p> <p>Positive direction Negative direction</p> <p>SLIT ON OFF</p>	<p>Negative direction mechanical end Positive direction mechanical end</p> <p>Positive direction Negative direction</p> <p>SLIT ON OFF</p>		
TIM signal	<p>Negative direction mechanical end Positive direction mechanical end</p> <p>Positive direction Negative direction</p> <p>TIM ON OFF</p>	<p>Negative direction mechanical end Positive direction mechanical end</p> <p>Positive direction Negative direction</p> <p>TIM ON OFF</p>		
SLIT input and TIM signal	<p>Negative direction mechanical end Positive direction mechanical end</p> <p>Positive direction Negative direction</p> <p>SLIT ON OFF TIM ON OFF</p>	<p>Negative direction mechanical end Positive direction mechanical end</p> <p>Positive direction Negative direction</p> <p>SLIT ON OFF TIM ON OFF</p>		

* The motor will move 200 steps from the mechanical end.

Note

- Do not perform push-mode return-to-home operation for geared motors. Doing so may cause damage to the motor.
- The maximum speed for the push-mode is 500 r/min on the motor output shaft regardless of resolution. Starting return-to-home operation with setting faster speed than 500 r/min may cause damage to the motor.

5-2 Position preset

When the P-PRESET is executed, the command position is set as the value of the "Preset position" parameter. However, the preset will not execute in the following conditions.


- When the motor is operating
- When an alarm is present

● Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Coordinates	Preset position	Sets the preset position. [Setting range] -8,388,608 to 8,388,607 step	0

● Operating method

- 1) Check the READY output is ON.
- 2) Turn the P-PRESET input ON
- 3) When the driver internal processing is completed, the HOME-P output will be turned ON.
- 4) Check the HOME-P output has been turned ON, and then turn the P-PRESET input OFF.



6 Continuous operation

The motor operates continuously while the FWD or RVS input is ON.

Operation is performed based on the FWD or RVS input and the operating speed corresponding to the selected operation data No. When the operation data No. is changed during continuous operation, the speed will change to the speed specified by the new operation data No.

When the FWD or RVS input is turned OFF, the motor will decelerate to a stop. If the signal of the same direction is turned ON again during deceleration, the motor will accelerate and continue operating.

If the FWD and RVS inputs are turned ON simultaneously, the motor will decelerate to a stop.

■ Operation data


Operation data for continuous operation are as follows.

MEXE02 tree view	Setting item	Description	Initial value
Operation data	Operating speed	Sets the operating speed in continuous operation. [Setting range] 1 to 1,000,000 Hz	1,000
	Acceleration	Sets the acceleration rate (acceleration time) in continuous operation. * [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s)	1,000
	Deceleration	Sets the deceleration rate (deceleration time) in continuous operation. * [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s)	1,000

* The acceleration/deceleration for continuous operation can be set as follows using the "Acceleration/deceleration type" parameter:

Separate : The acceleration/deceleration set under the applicable operation data No. will be followed (Each 64 data for acceleration and deceleration).

Common: The setting of the "Common acceleration" and "Common deceleration" parameter will be followed (Each one data for acceleration and deceleration).




6-1 Starting method of continuous operation

When selecting the operation data No. and turning the FWD input or RVS input ON, continuous operation will be started. Select an operation data based on a combination of ON/OFF status of the M0 to M5 inputs. Refer to p.93 for details.

Operation data No.	M5	M4	M3	M2	M1	M0
0	OFF	OFF	OFF	OFF	OFF	OFF
1	OFF	OFF	OFF	OFF	OFF	ON
2	OFF	OFF	OFF	OFF	ON	OFF
.
.
.
61	ON	ON	ON	ON	OFF	ON
62	ON	ON	ON	ON	ON	OFF
63	ON	ON	ON	ON	ON	ON

● Operating method


- 1) Check the READY output is ON.
- 2) Select the operation data No. by a combination of the M0 to M5 inputs and turn the FWD input ON.
- 3) The motor starts continuous operation. The READY output will be turned OFF.
- 4) Select the operation data No.1 by turning the M0 input ON. The motor accelerates to the operating speed of the operation data No.1.
- 5) Select the operation data No.0 by turning the M0 input OFF. The motor decelerates to the operating speed of the operation data No.0.
- 6) Turn the FWD input OFF.
- 7) The motor will decelerate to a stop and the READY output will be turned ON.



* In direct I/O, turn the FWD input or RVS input ON after setting the M0 to M5 inputs. In remote I/O, the operation will be performed even when turning the M0 to M5 inputs and the FWD (RVS) input ON simultaneously.

● **Operating method; When combining the FWD input and RVS input**

- 1) Check the READY output is ON.
- 2) Select the operation data No. by a combination of the M0 to M5 inputs and turn the FWD input ON.
- 3) The motor starts continuous operation. The READY output will be turned OFF.
- 4) Turn the FWD input OFF. The motor will decelerate.
- 5) Turn the FWD input ON while the motor is decelerating. The motor accelerates again.
- 6) Turn the FWD input OFF. The motor will decelerate.
- 7) Turn the RVS input ON while the motor is decelerating. The motor will stop once, and start rotating in the reverse direction.
- 8) When turning the FWD input ON while the RVS input is ON, the motor will decelerate.
- 9) The motor will decelerate to a stop and the MOVE output will be turned OFF.
- 10) When turning both the FWD input and RVS input OFF, the READY output will be turned ON.





* In direct I/O, turn the FWD input or RVS input ON after setting the M0 to M5 inputs.
 In remote I/O, the operation will be performed even when turning the M0 to M5 inputs and the FWD (RVS) input ON simultaneously.

6-2 Variable speed operation

■ When acceleration/deceleration is "separate"



● Acceleration/deceleration unit: ms/kHz



- Explanation of labels
 - VS: Starting speed (Hz)
 - VR1: Operating speed of operation data No.1 (Hz)
 - VR2: Operating speed of operation data No.2 (Hz)

- TA1: Acceleration rate of operation data No.1 (ms/kHz)
- TA2: Acceleration rate of operation data No.2 (ms/kHz)
- TD2: Deceleration rate of operation data No.2 (ms/kHz)

● Acceleration/deceleration unit: s



- Explanation of labels
 - VS: Starting speed (Hz)
 - VR1: Operating speed of operation data No.1 (Hz)
 - VR2: Operating speed of operation data No.2 (Hz)
 - TA1: Acceleration time of operation data No.1 (s)
 - TA2: Acceleration time of operation data No.2 (s)
 - TD2: Deceleration time of operation data No.2 (s)


- TAR1: Acceleration rate of operation data No.1 (Hz/s)
- TAR2: Acceleration rate of operation data No.2 (Hz/s)
- TDR2: Deceleration rate of operation data No.2 (Hz/s)

- Calculation method for acceleration/deceleration rate
 - $TAR1 = (VR1 - VS) / TA1$
 - $TAR2 = (VR2 - VS) / TA2$
 - $TDR2 = (VR2 - VS) / TD2$


■ When acceleration/deceleration is "common"

● Acceleration/deceleration unit: ms/kHz

When accelerating



When decelerating




- Explanation of labels
 VS: Starting speed (Hz)
 VR1: Operating speed of operation data No.1 (Hz)
 VR2: Operating speed of operation data No.2 (Hz)


TAC: Common acceleration rate (ms/kHz)
 TDC: Common deceleration rate (ms/kHz)

● Acceleration/deceleration unit: s

When accelerating



When decelerating



- Explanation of labels
 VS: Starting speed (Hz)
 VR1: Operating speed of operation data No.1 (Hz)
 VR2: Operating speed of operation data No.2 (Hz)
 TAC: Common acceleration time (s)
 TDC: Common deceleration time (s)

TAR1: Acceleration rate of operation data No.1 (Hz/s)
 TAR2: Acceleration rate of operation data No.2 (Hz/s)
 TDR2: Deceleration rate of operation data No.2 (Hz/s)

- Calculation method for acceleration/deceleration rate
 $TAR1 = (VR1 - VS) / TAC$
 $TAR2 = (VR2 - VS) / TAC$
 $TDR2 = (VR2 - VS) / TDC$

7 Other operation

7-1 JOG operation

JOG operation is a function to perform positioning operation of the travel amount set in the "JOG travel amount" parameter.

When the +JOG signal to ON, JOG operation is in the positive direction.


When the -JOG signal to ON, JOG operation is in the negative direction.

This function is convenient for fine adjustment of the position.

- Related parameter


MEXE02 tree view	Parameter name	Description	Initial value
Operation	JOG operating speed	Sets the operating speed for JOG operation. [Setting range] 1 to 1,000,000 Hz	1,000
	Acceleration/ deceleration rate of JOG	Sets the acceleration/deceleration rate (acceleration/ deceleration time) for JOG operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s)	1,000
	JOG starting speed	Sets the starting speed for JOG operation. [Setting range] 0 to 1,000,000 Hz	500
	JOG travel amount	Sets the travel amount for JOG operation. [Setting range] 1 to 8,388,607 step	1

- Operation example



● **Operating method**

- 1) Check the READY output is ON.
- 2) Turn the +JOG input ON.
- 3) The motor starts positioning operation.
- 4) Check the READY output has been turned OFF and turn the +JOG input OFF.
- 5) When the positioning operation is completed, the READY output will be turned ON.




7-2 Test operation

Test operation is performed using the **MEXE02** or **OPX-2A**. JOG operation and teaching function can be performed. Refer to the Support software **MEXE02 OPERATING MANUAL** when setting with the **MEXE02**, and p.121 when setting with the **OPX-2A**.

■ **JOG operation**

Connection condition or operation status for the motor and driver can be checked using JOG operation.

Example: When performing test operation with the OPX-2A



■ **Teaching**

This is a function to move the motor using the **MEXE02** or **OPX-2A** and set the current position as the position (travel amount) of the operation data. When the position (travel amount) is set using teaching function, the "operation mode" will always be the absolute mode.

The operating speed, acceleration/deceleration and starting speed of teaching function are same as those of JOG operation.

memo Perform teaching function when the position origin is set. Refer to p.198 for setting the position origin.

7-3 Automatic return operation

When a position deviation occurs by an external force while the motor is in a non-excitation state, the motor can automatically return to the position where the motor last stopped.


When the power is turned on and motor is reexcited by turning the C-ON input ON or turning the FREE input OFF, automatic return operation will be executed under the following conditions;

- When the main power is turned on
- When the C-ON input is turned from OFF to ON
- When the FREE input is turned from ON to OFF

● Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Operation	Automatic return operation	Sets whether to enable or disable automatic return operation. [Setting range] 0: Disable 1: Enable	0
	Operation speed of automatic return	Sets the operating speed for automatic return operation. [Setting range] 1 to 1,000,000 Hz	1,000
	Acceleration (deceleration) of automatic return	Sets the acceleration/deceleration rate (acceleration/deceleration time) for automatic return operation. [Setting range] 1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s)	1,000
	Starting speed of automatic return	Sets the starting speed for automatic return operation. [Setting range] 0 to 1,000,000 Hz	500

● Example of automatic return operation



- Automatic return operation will not be executed immediately after turning on the DC power supply or executing the configuration command.
- If an alarm generates while the motor is in a non-excitation state, the automatic return operation will not be executed normally.


7-4 Stop operation

■ STOP action

When the STOP input is turned ON or STOP is commanded via RS-485 communication while the motor is operating, the motor will stop.

The stopping mode is determined by the setting of the "STOP input action" parameter.

For example, the operation when setting "STOP input action" parameter to "Deceleration stop" is shown in the figure.



* The deceleration time is determined by the setting of "Deceleration" in the operation data.

■ Hardware overtravel


Hardware overtravel is the function that limits the operation range by installing the limit sensor (\pm LS) at the upper and lower limit of the operation range.

If the "Hardware overtravel" parameter is set to "Enable," the motor can be stopped when detecting the limit sensor.


The stopping mode is determined by the setting of "Overtravel action" parameter.

The operation example is shown in the figure.

- Immediate stop



- Decelerate stop



Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	Hardware overtravel	Sets whether to enable or disable hardware overtravel detection using \pm LS inputs. [Setting range] 0: Disable 1: Enable	1
	Overtravel action	Sets the motor stop action to take place upon the occurrence of overtravel. [Setting range] 0: Immediate stop 1: Decelerate stop	0



When the "Overtravel action" parameter is set to "Decelerate stop," consider the distance from the start of deceleration to the stop, and do not allow a load to contact with the edge of the mechanism.


■ Software overtravel

The software overtravel is a function that limits the range of movement using the parameter.


If the "Software overtravel" parameter is set to "Enable," the motor can be stopped when exceeding the software limit. The stopping mode is determined by the setting of "Overtravel action" parameter. For example, setting the "Overtravel action" parameter to "Decelerate stop" can decelerate the motor according to the deceleration rate and stop it at the software limit.

The figures below show the motor movement when an operation exceeding the software limit is started during operation.

- Immediate stop



- Decelerate stop



Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
I/O	Overtravel action	Sets the motor stop action to take place upon the occurrence of overtravel. [Setting range] 0: Immediate stop 1: Decelerate stop	0
Coordinates	Software overtravel	Sets whether to enable or disable software overtravel detection using soft limits. [Setting range] 0: Disable 1: Enable	1
	Positive software limit	Sets the value of soft limit in positive direction. [Setting range] -8,388,608 to 8,388,607 step	8,388,607
	Negative software limit	Sets the value of soft limit in negative direction. [Setting range] -8,388,608 to 8,388,607 step	-8,388,608



- Software overtravel will become effective after the position origin is set. Refer to p.198 for setting the position origin.
- When the value of the software limit is changed while the motor is operating, the motor will stop according to the setting of the "Overtravel action" parameter.

■ Escape from the limit sensor

It is possible to escape in the negative direction when detecting the positive direction limit, and possible to escape in the positive direction when detecting the negative direction limit.

The table shows the types of operation that can be used when escaping from the limit.

Types of operation	Limit sensors (\pm LS)	Software limit
Positioning operation	Will not operate (unable to escape)	Allowed to operate (able to escape)
Continuous operation	Allowed to operate (able to escape)	
Test operation Return-to-home operation		

8 Coordination management

8-1 Position coordinate management

The driver manages the motor position information.

■ Position origin for the driver

The position origin will be set whenever one of the following operations is executed:

- Return-to-home operation
- P-PRESET input is turned ON

■ When the position origin has not been set

If the "Return-to-home incomplete alarm" parameter is set to "Enable," positioning operations can be prohibited while the position origin has not been set.

The return-to-home incomplete alarm will generate if the START input, SSTART input or the MS0 to MS5 inputs are turned ON while the position origin has not been set. Refer to p.144 for alarm.

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Alarm	Return-to-home incomplete alarm	When the positioning operation is started while the position origin has not been set, selects whether the alarm generates or not. [Setting range] 0: Disable 1: Enable	0


8-2 Wrap function

The wrap function is a function that resets the command position or multi-rotation data to 0 whenever the command position exceeds the set value by the "Wrap setting range" parameter.

The command position varies in a range of "0 to (wrap setting value-1)."

Related parameter

MEXE02 tree view	Parameter name	Description	Initial value
Coordinates	Wrap setting	Sets whether to enable or disable wrap function. [Setting range] 0: Disable 1: Enable	0
	Wrap setting range	Sets the wrap setting range. [Setting range] 1 to 8,388,607 step	1,000

 When setting the "Wrap setting" parameter to "Enable," the software overtravel will be disabled. (It is disabled even when setting the "Software overtravel" parameter to "Enable.")

■ Setting condition of wrap function

Condition 1: $\frac{\text{Electronic gear B} \times 1,000}{\text{Electronic gear A} \times 50} = \text{An integer}$

Condition 2: $\text{Wrap setting value} \times \frac{\text{Electronic gear A} \times 50}{\text{Electronic gear B} \times 1,000} = \text{An integer}$

The wrap setting error warning will generate when not meeting these formulas.



When not meeting these formulas while the "Wrap setting" parameter is "Enable," the wrap setting error warning will generate. If the power is turned on again or the configuration is executed while the wrap setting error warning is present, the wrap setting error alarm will generate.

■ Example for wrap function

Example of operation when the positioning operation is performed in the following conditions.

- Wrap setting range : 3,600
- Resolution : 1,000 P/R (electronic gear A=1, electronic gear B=1)
- Command position : 900

$$\text{Condition 1: } \frac{\text{Electronic gear B} \times 1,000}{\text{Electronic gear A} \times 50} = \frac{1 \times 1,000}{1 \times 50} = 20$$

$$\text{Condition 2: } \text{Wrap setting value} \times \frac{\text{Electronic gear A} \times 50}{\text{Electronic gear B} \times 1,000} = 3,600 \times \frac{1 \times 50}{1 \times 1,000} = 180$$

The calculation result of these two formulas is an integer and this meets the setting condition.

Following tables are examples when the positioning operation is performed from 900 steps of the command position.

Position	Operation mode: Incremental	Operation mode: Absolute
+1,000		
-1,000		
+5,000		
-5,000		

6 Method of control via Modbus RTU (RS-485 communication)


This part explains how to control from the host controller via RS-485 communication. The protocol for the RS-485 communication is the Modbus protocol.

◆ Table of contents

1	Guidance	202	8	Register address list	227
2	Communication specifications	208	8-1	Operation commands	227
3	Setting the switches.....	211	8-2	Maintenance commands	229
3-1	Setting the AC power input	211	8-3	Monitor commands	230
3-2	Setting the DC power input.....	213	8-4	Parameter R/W commands	233
4	Setting of RS-485 communication ...	215	9	Group send	244
5	Communication mode and communication timing	216	10	Setting example of the operation	246
5-1	Communication mode.....	216	10-1	Positioning operation	246
5-2	Communication timing	216	10-2	Continuous operation.....	249
6	Message.....	218	10-3	Return-to-home operation	251
6-1	Query	218	11	Detection of communication errors.....	253
6-2	Response.....	220	11-1	Communication errors.....	253
7	Function code.....	222	11-2	Alarms and warnings.....	253
7-1	Reading from a holding register(s) (03h).....	222	12	Timing charts.....	254
7-2	Writing to a holding register (06h)	223			
7-3	Diagnosis (08h)	224			
7-4	Writing to multiple holding registers (10h).....	225			

1 Guidance

If you are new to the **AR** Series FLEX built-in controller type, read this section to understand the operating methods along with the operation flow. This is an example how to set operation data and parameters to the driver and operate the motor using a host controller.



● **Operation condition**


Here, the motor is assumed to be operated under the following conditions.

- Number of drivers connected: 1 unit
- Address number: 1
- Transmission rate: 115,200 bps
- Termination resistor: Enable

Note Before operating the motor, check the condition of the surrounding area to ensure safety.


STEP 1 Check the installation and connection

■ **AC power input**



* These cables are provided as our products. Purchase them separately.

■ DC power input



- *1 This cable is provided as our product. When the length of the motor cable is not enough, purchase it separately.
- *2 These cables are provided as our products. Purchase them separately.


STEP 2 Setting the switches

Set as shown in the table with the switches. The status becomes as shown in the following figures after setting.


■ AC power input

Setting item	Switch	Factory setting
Protocol: Modbus protocol	Turn No.2 of SW4 ON	OFF
Address number: 1	Turn No.1 of SW4 OFF, set ID to 1	No.1 of SW4: OFF, ID: 0
Transmission rate: 115,200 bps	Set SW2 to 4	7
Termination resistor: ON	Set Nos.1 and 2 of TERM. ON	OFF

● Driver front side




● Driver bottom side




■ DC power input

Setting item	Switch	Factory setting
Protocol: Modbus protocol	Turn No.2 of SW3 ON	OFF
Address number: 1	Turn No.1 of SW3 OFF, set SW1 to 1	No.1 of SW3: OFF, SW1: 0
Transmission rate: 115,200 bps	Set SW2 to 4	7
Termination resistor: ON	Set No.4 of SW3 ON	OFF

● Driver front side



● Driver bottom side



STEP 3 Turn on the power and check the communication parameters

Check the following communication parameters with the **MEXE02**.
 If communication cannot be established, review the communication parameters of the driver.

MEXE02 tree view	Parameter name
Communication	Communication parity [Initial value: 1 (even number)]
	Communication stop bit [Initial value: 0 (1 bit)]
	Transmission waiting time [Initial value: 100 (10.0 ms)]


memo Set the transmission interval of frames sent from the client to be longer than the silent interval of the driver. When the transmission rate is 115,200 bps, the silent interval of the driver is 2.5 ms.

STEP 4 Cycle the power

The switches of the driver and the communication parameters are enabled after the power is cycled.

STEP 5 Send a message and operate the motor

As an example, here is a description how to execute the following positioning operation.



1. Send the following five queries and set the operation data.

• Operation mode of operation data No.0

Field name		Data	Description
Server address		01h	Server address 1
Function code		06h	Writing to a holding register
Data	Register address (upper)	05h	Operation mode No.0 (0501h)
	Register address (lower)	01h	
	Value written (upper)	00h	Incremental (0000h)
	Value written (lower)	00h	
Error check (lower)		D8h	Calculation result of CRC-16
Error check (upper)		C6h	

• Position of operation data No.0

Field name		Data	Description
Server address		01h	Server address 1
Function code		06h	Writing to a holding register
Data	Register address (upper)	04h	Position No.0 (0401h)
	Register address (lower)	01h	
	Value written (upper)	21h	8,500 steps (2134h)
	Value written (lower)	34h	
Error check (lower)		C0h	Calculation result of CRC-16
Error check (upper)		BDh	

• Operating speed of operation data No.0

Field name		Data	Description
Server address		01h	Server address 1
Function code		06h	Writing to a holding register
Data	Register address (upper)	04h	Operating speed No.0 (0481h)
	Register address (lower)	81h	
	Value written (upper)	07h	2,000 Hz (07D0h)
	Value written (lower)	D0h	
Error check (lower)		DBh	Calculation result of CRC-16
Error check (upper)		7Eh	

• Acceleration of operation data No.0

Field name		Data	Description
Server address		01h	Server address 1
Function code		06h	Writing to a holding register
Data	Register address (upper)	06h	Acceleration No.0 (0601h)
	Register address (lower)	01h	
	Value written (upper)	05h	1.5 ms/kHz (05DCh)
	Value written (lower)	DCh	
Error check (lower)		DAh	Calculation result of CRC-16
Error check (upper)		4Bh	

• Deceleration of operation data No.0

Field name		Data	Description
Server address		01h	Server address 1
Function code		06h	Writing to a holding register
Data	Register address (upper)	06h	Deceleration No.0 (0681h)
	Register address (lower)	81h	
	Value written (upper)	05h	1.5 ms/kHz (05DCh)
	Value written (lower)	DCh	
Error check (lower)		DBh	Calculation result of CRC-16
Error check (upper)		A3h	

2. Send the following two queries and perform operation.

• START input ON (To start operation for operation data No.0)

Field name		Data	Description
Server address		01h	Server address 1
Function code		06h	Writing to a holding register
Data	Register address (upper)	00h	Driver input command (007Dh)
	Register address (lower)	7Dh	
	Value written (upper)	00h	START ON (0008h)
	Value written (lower)	08h	
Error check (lower)		18h	Calculation result of CRC-16
Error check (upper)		14h	

• START input OFF

Field name		Data	Description
Server address		01h	Server address1
Function code		06h	Writing to a holding register
Data	Register address (upper)	00h	Driver input command (007Dh)
	Register address (lower)	7Dh	
	Value written (upper)	00h	START OFF (0000h)
	Value written (lower)	00h	
Error check (lower)		19h	Calculation result of CRC-16
Error check (upper)		D2h	

3. Check the motor rotates according to the setting.

STEP 6 Were you able to operate the motor properly?

How did it go? Were you able to operate the motor properly? If the motor does not function, check the following points:

- Is any alarm present?
- Are the power supply, the motor, and the RS-485 cable connected securely?
- Are the server address, transmission rate and termination resistor set correctly?
- Is the C-DAT/C-ERR LED turned off? Or is it lit in red? (A communication error has occurred.)


2 Communication specifications

Electrical characteristics	In conformance with EIA-485, straight cable Use a twisted pair cable (TIA/EIA-568B CAT5e or higher is recommended) and keep the total wiring distance including extension to 50 m (164 ft.) or less. *
Communication mode	Half duplex Asynchronous mode (data: 8 bits, stop bit: 1 bit/2 bits, parity: none/even number/odd number)
Transmission rate	Selectable from 9,600 bps, 19,200 bps, 38,400 bps, 57,600 bps and 115,200 bps.
Protocol	Modbus RTU mode
Connection figure	Up to 31 drivers can be connected to a single host controller.

* If the motor cable or power supply cable generates an undesirable amount of noise depending on the wiring or configuration, shield the cable or install a ferrite core.


■ Connection example

The figure shows the model for AC power input.



■ Internal circuit diagram


● AC power input



*1 Termination resistor 120 Ω

*2 Turn the termination resistor ON (TERM.-Nos.1 and 2).

● DC power input



- *1 Termination resistor 120 Ω
- *2 Turn the termination resistor ON (SW3-No.4).
- *3 Common with GND of CN1 (Non-isolated)


3 Setting the switches

Switches differ in the AC power input driver and the DC power input driver. Set properly.


3-1 Setting the AC power input

The figures show the status of factory setting.

● Driver front side



● Driver bottom side



Note When setting any switch, turn off the main power supply and the 24 VDC power supply of the driver and wait for the CHARGE LED to turn off before doing so. The residual voltage may cause electric shock.

memo The set switches are enabled after the 24 VDC power supply is turned on again.

■ Protocol

Using the SW4-No.2 of the function setting switch to ON. The Modbus protocol is selected.

Factory setting OFF

SW4-No.2	Protocol
ON	Modbus RTU mode
OFF	Connecting with network converter

■ Transmission rate

Using the transmission rate setting switch (SW2), set the transmission rate. The transmission rate to be set should be the same as the transmission rate of the host controller.

Factory setting 7

SW2	Transmission rate (bps)	SW2	Transmission rate (bps)
0	9,600	4	115,200
1	19,200	5, 6	Not used
2	38,400	7	Network converter
3	57,600	8 to F	Not used

memo Do not set SW2 to positions 5, 6, and 8 to F.

■ Address number (Server address)

Using the address number setting switch (ID) and SW4-No.1 of the function setting switch, set the address number (server address). Make sure each address number (server address) you set for each driver is unique. Address number (server address) 0 is reserved for broadcasting, so do not use this address.

Factory setting ID: 0, SW4-No.1: OFF

ID	SW4-No.1	Address number (Server address)	ID	SW4-No.1	Address number (Server address)
0	OFF	Not used	0	ON	16
1		1	1		17
2		2	2		18
3		3	3		19
4		4	4		20
5		5	5		21
6		6	6		22
7		7	7		23
8		8	8		24
9		9	9		25
A		A	10		26
B		B	11		27
C		C	12		28
D		D	13		29
E		E	14		30
F		F	15		31

■ Termination resistor


Set the termination resistor (120 Ω) of RS-485 communication on the driver that is farthest away (at the end) from the host controller.

Turn the termination resistor setting switch (TERM.-Nos.1 and 2) ON to set the termination resistor for RS-485 communication (120 Ω).

Factory setting Nos.1 and 2: Both OFF (termination resistor disabled)

TERM.-Nos.1 and 2	Termination resistor (120 Ω)
Both are OFF	Disabled
Both are ON	Enabled


memo If only one of No.1 or No.2 is turned ON, a communication error may occur.




3-2 Setting the DC power input

The figures show the status of factory setting.

● Driver front side



● Driver bottom side



memo Be sure to turn off the driver power supply before setting the switches. If the switches are set while the power is still on, the new switch settings will not become effective until the driver power supply is cycled.

■ Protocol

Using the SW3-No.2 of the function setting switch to ON. The Modbus protocol is selected.

Factory setting OFF

SW3-No.2	Protocol
ON	Modbus RTU mode
OFF	Connecting with network converter

■ Transmission rate

Using the transmission rate setting switch (SW2), set the transmission rate.

The transmission rate to be set should be the same as the transmission rate of the host controller.

Factory setting 7

SW2	Transmission rate (bps)
0	9,600
1	19,200
2	38,400
3	57,600
4	115,200
5, 6	Not used
7	Network converter
8 to F	Not used

memo Do not set SW2 to positions 5, 6, and 8 to F.

■ Address number (Server address)

Using the address number setting switch (SW1) and SW3-No.1 of the function setting switch, set the address number (server address). Make sure each address number (server address) you set for each driver is unique. Address number (server address) 0 is reserved for broadcasting, so do not use this address.

Factory setting SW1: 0, SW3-No.1: OFF

SW1	SW3-No.1	Address number (Server address)	SW1	SW3-No.1	Address number (Server address)
0	OFF	Not used	0	ON	16
1		1	1		17
2		2	2		18
3		3	3		19
4		4	4		20
5		5	5		21
6		6	6		22
7		7	7		23
8		8	8		24
9		9	9		25
A		10	A		26
B		11	B		27
C		12	C		28
D		13	D		29
E		14	E		30
F		15	F		31


■ Termination resistor

Set the termination resistor (120 Ω) of RS-485 communication on the driver that is farthest away (at the end) from the host controller.

Turn the termination resistor setting switch (SW3-No.4) ON to set the termination resistor for RS-485 communication (120 Ω).

Factory setting OFF (termination resistor disabled)

SW3-No.4	Termination resistor (120 Ω)
OFF	Disabled
ON	Enabled



* Common with GND of CN1 (Non-isolated)

4 Setting of RS-485 communication

Set parameters required RS-485 communication first.

When a parameter is changed, the timing to update the new value varies depending on the parameter. Refer to "Communication parameter" on p.120 for the timing to update each parameter.

■ Parameters set with the MEXE02 or OPX-2A

Set the following parameters using the **MEXE02** or **OPX-2A** since they cannot be set via RS-485 communication.

MEXE02 tree view	Parameter name	Description	Initial value
Communication	Communication parity	Sets the parity of RS-485 communication. [Setting range] 0: None 1: Even 2: Odd	1
	Communication stop bit	Sets the stop bit of RS-485 communication. [Setting range] 0: 1 bit 1: 2 bits	0
	Transmission waiting time	Sets the transmission waiting time of RS-485 communication. [Setting range] 0 to 10,000 (1=0.1 ms)	100

■ Parameters set with the MEXE02, OPX-2A or via RS-485 communication

Set the following parameters using the **MEXE02**, **OPX-2A** or via RS-485 communication.

MEXE02 tree view	Parameter name	Description	Initial value
Communication	Communication timeout	Sets the condition in which a communication timeout occurs in RS-485 communication. It is not monitored when the set value is 0. [Setting range] 0: Not monitored 1 to 10,000 ms	0
	Communication error alarm	Sets the condition in which a RS-485 communication error alarm generates. A communication error alarm generates after a RS-485 communication error has occurred by the number of times set here. [Setting range] 1 to 10 times	3


5 Communication mode and communication timing

5-1 Communication mode

Modbus protocol communication is based on the single-client/multiple-server method. Only the client can issue a query (command). Each server executes the process requested by query and returns a response message. The **AR** Series supports only the RTU mode as a transmission mode. It does not support the ASCII mode. Under this protocol, messages are sent in one of two methods.


- **Unicast mode**

The client sends a command to only one server. The server executes the process and returns a response.




- **Broadcast mode**

If the server address 0 is specified on the client, the client can send a command to all servers. Each server executes the process, but does not return a response.



5-2 Communication timing

The communication time monitored by the driver and the communication timing of the client are as follows.




Character	Name	Description
Tb1	Communication timeout (Driver)	The driver monitors an interval between received queries. If no query could be received after the time set with the "Communication timeout" parameter, an alarm of Communication timeout is generated. When normal messages including messages to other servers were received, an alarm of Communication timeout is not generated.
Tb2	Transmission waiting time (Driver)	This is the amount of time from when the driver receives a query from the client to when it starts sending a response. Set using the "Transmission waiting time" parameter.
Tb3	Broadcasting interval (Client)	This is the amount of time until the client sends the next query in broadcasting. A time equivalent to or longer than the silent interval (C3.5) plus 5 ms is required.
Tb4	Transmission waiting time (Client)	This is the amount of time from when the client receives the response to when it sends the next query (setting on the client side). Set so that it is equal to or longer than the time of the silent interval (C3.5).
C3.5	Silent interval	This is the amount of time to determine the end of a query or response message. An interval equal to or longer than the time of the silent interval (C3.5) is required when the message ends. Refer to the following table for the transmission waiting time.

Transmission waiting time of the "silent interval (C3.5)"

Transmission rate (bps)	Silent interval	Frame interval of client (reference)
9,600	4 ms or more	5.0 ms or more
19,200 38,400 57,600 115,200	2.5 ms or more	3.0 ms or more

6 Message

The message format is shown below.



6-1 Query

The query message structure is shown below.

Server address	Function code	Data	Error check
8 bits	8 bits	N×8 bits	16 bits

■ Server address

Specify the server address (unicast mode).
 If the server address is set to 0, the client can send a query to all servers (broadcast mode).

■ Function code

The function codes and message lengths supported by the driver are as follows.

Function code	Function	Message length		Broadcast
		Query	Response	
03h	Reading from a holding register(s)	8	7 to 37	Impossible
06h	Writing to a holding register	8	8	Possible
08h	Diagnosis	8	8	Impossible
10h	Writing to multiple holding registers	11 to 41	8	Possible

■ Data

Set data associated with the selected function code. The specific data length varies depending on the function code.

■ Error check

In the Modbus RTU mode, error checks are based on the CRC-16 method. The server calculates a CRC-16 of each received message and compares the result against the error check value included in the message. If the calculated CRC-16 value matches the error check value, the server determines that the message is normal.

● CRC-16 calculation method

1. Calculate an exclusive-OR (XOR) value of the default value of FFFFh and server address (8 bits).
2. Shift the result of step 1 to the right by 1 bit. Repeat this shift until the overflow bit becomes "1."
3. Upon obtaining "1" as the overflow bit, calculate an XOR of the result of step 2 and A001h.
4. Repeat steps 2 and 3 until a shift is performed eight times.
5. Calculate an XOR of the result of step 4 and function code (8 bits).
 Repeat steps 2 to 4 for all bytes.
 The final result gives the result of CRC-16 calculation.

- **Example of CRC-16 calculation**

The table is a calculation example when setting the server address of the first byte to 02h and setting the function code of the second byte to 07h.

The result of actual CRC-16 calculation is calculated including the data on and after the third byte.

Description	Result	Overflow digit
Default value in CRC register FFFFh	1111 1111 1111 1111	–
First byte 02h	0000 0000 0000 0010	–
XOR with default value FFFFh	1111 1111 1111 1101	–
First shift to right	0111 1111 1111 1110	1
XOR with A001h	1010 0000 0000 0001 1101 1111 1111 1111	–
Second shift to right	0110 1111 1111 1111	1
XOR with A001h	1010 0000 0000 0001 1100 1111 1111 1110	–
Third shift to right	0110 0111 1111 1111	0
Fourth shift to right	0011 0011 1111 1111	1
XOR with A001h	1010 0000 0000 0001 1001 0011 1111 1110	–
Fifth shift to right	0100 1001 1111 1111	0
Sixth shift to right	0010 0100 1111 1111	1
XOR with A001h	1010 0000 0000 0001 1000 0100 1111 1110	–
Seventh shift to right	0100 0010 0111 1111	0
Eighth shift to right	0010 0001 0011 1111	1
XOR with A001h	1010 0000 0000 0001 1000 0001 0011 1110	–
XOR with next byte 07h	0000 0000 0000 0111 1000 0001 0011 1001	–
First shift to right	0100 0000 1001 1100	1
XOR with A001h	1010 0000 0000 0001 1110 0000 1001 1101	–
Second shift to right	0111 0000 0100 1110	1
XOR with A001h	1010 0000 0000 0001 1101 0000 0100 1111	–
Third shift to right	0110 1000 0010 0111	1
XOR with A001h	1010 0000 0000 0001 1100 1000 0010 0110	–
Fourth shift to right	0110 0100 0001 0011	0
Fifth shift to right	0011 0010 0000 1001	1
XOR with A001h	1010 0000 0000 0001 1001 0010 0000 1000	–
Sixth shift to right	0100 1001 0000 0100	0
Seventh shift to right	0010 0100 1000 0010	0
Eighth shift to right	0001 0010 0100 0001	0
Result of CRC-16	0001 0010 0100 0001	–

6-2 Response

Server-returned responses are classified into three types: normal response, no response, and exception response. The response message structure is the same as the query message structure.

Server address	Function code	Data	Error check
8 bits	8 bits	N×8 bits	16 bits

■ Normal response

Upon receiving a query from the client, the server executes the requested process and returns a response corresponding to the function code.

■ No response

The server may not return a response to a query sent by the client. This condition is referred to as "No response." The causes of no response are explained below.

● Transmission error

The server discards the query and does not return a response if any of the following transmission errors is detected.

Cause of transmission error	Description
Framing error	Stop bit 0 was detected.
Parity error	A mismatch with the specified parity was detected.
Mismatched CRC	The calculated value of CRC-16 was found not matching the error check value.
Invalid message length	The message length exceeded 256 bytes.

● Other than transmission error

A response may not be returned without any transmission error being detected.

Cause	Description
Broadcast	If the query was broadcast, the server executes the requested process but does not return a response.
Mismatched server address	The server address in the query was found not matching the server address of the driver.

■ Exception response

An exception response is returned if the server cannot execute the process requested by the query. Appended to this response is an exception code indicating why the process cannot be executed. The message structure of exception response is as follows.


Server address	Function code	Exception code	Error check
8 bits	8 bits	8 bits	16 bits

● Function code

The function code in the exception response is a sum of the function code in the query and 80h.

Function code of query	Exception response
03h	83h
06h	86h
08h	88h
10h	90h

● Example of exception response



● Exception code

This code indicates why the process cannot be executed.

Exception code	Communication error code	Cause	Description
01h	88h	Invalid function	The process could not be executed because the function code was invalid. <ul style="list-style-type: none"> • The function code is not supported. • The sub-function code for diagnosis (08h) is other than 00h.
02h		Invalid data address	The process could not be executed because the data address was invalid. <ul style="list-style-type: none"> • The address is not supported (other than 0000h to 1FFFh). • Register address and number of registers are 2000h or more in total.
03h	8Ch	Invalid data	The process could not be executed because the data was invalid. <ul style="list-style-type: none"> • The number of registers is 0 or more than 17. • The number of bytes is other than twice the number of registers. • The data length is outside the specified range.
04h	89h 8Ah 8Ch 8Dh	Server error	The process could not be executed because an error occurred at the server. <ul style="list-style-type: none"> • User I/F communication in progress (89h) <ul style="list-style-type: none"> · Downloading or initialization is in progress using the MEXE02 · Downloading, initializing or teaching function is in progress using the OPX-2A • Non-volatile memory processing in progress (8Ah) <ul style="list-style-type: none"> · Internal processing is in progress. (S-BSY is ON.) · An EEPROM error alarm is present. • Outside the parameter setting range (8Ch) <ul style="list-style-type: none"> The value write is outside the setting range. • Command execute disable (8Dh)

7 Function code

This chapter explains the function codes supported by the **AR** Series drivers.

Note that the function code cannot be executed if function codes other than those introduced here are sent.

7-1 Reading from a holding register(s) (03h)

This function code is used to read a register (16 bits). Up to 16 successive registers (16×16 bits) can be read. Read the upper and lower data at the same time. If they are not read at the same time, the value may be invalid. If multiple holding registers are read, they are read in order of register addresses.

■ Example of read

Read operation data for positions Nos.1 and 2 of server address 1.

Description	Register address	Value read	Corresponding decimal
Operation data position No.1 (upper)	0402h	0000h	10,000
Operation data position No.1 (lower)	0403h	2710h	
Operation data position No.2 (upper)	0404h	FFFFh	-10,000
Operation data position No.2 (lower)	0405h	D8F0h	

● Query

Field name	Data	Description
Server address	01h	Server address1
Function code	03h	Reading from holding registers
Data	Register address (upper)	Register address to start reading from
	Register address (lower)	
	Number of registers (upper)	Number of registers to be read from the starting register address (4 registers=0004h)
	Number of registers (lower)	
Error check (lower)	E4h	Calculation result of CRC-16
Error check (upper)	F9h	

● Response

Field name	Data	Description	
Server address	01h	Same as query	
Function code	03h	Same as query	
Data	Number of data bytes	08h	Twice the number of registers in the query
	Value read from register address (upper)	00h	Value read from register address 0402h
	Value read from register address (lower)	00h	
	Value read from register address+1 (upper)	27h	Value read from register address 0403h
	Value read from register address+1 (lower)	10h	
	Value read from register address+2 (upper)	FFh	Value read from register address 0404h
	Value read from register address+2 (lower)	FFh	
	Value read from register address+3 (upper)	D8h	Value read from register address 0405h
Value read from register address+3 (lower)	F0h		
Error check (lower)	08h	Calculation result of CRC-16	
Error check (upper)	A3h		

7-2 Writing to a holding register (06h)

This function code is used to write data to a specified register address. However, since the result combining the upper and lower may be outside the data range, write the upper and lower at the same time using the "Writing to multiple holding registers (10h)."

■ Example of write

Write 80 (50h) as speed filter to server address 2.

Description	Register address	Value written	Corresponding decimal
Speed filter	024Bh	50h	80

● Query

Field name		Data	Description
Server address		02h	Server address 2
Function code		06h	Writing to a holding register
Data	Register address (upper)	02h	Register address to be written
	Register address (lower)	4Bh	
	Value written (upper)	00h	Value written to the register address
	Value written (lower)	50h	
Error check (lower)		F8h	Calculation result of CRC-16
Error check (upper)		6Bh	

● Response

Field name		Data	Description
Server address		02h	Same as query
Function code		06h	Same as query
Data	Register address (upper)	02h	Same as query
	Register address (lower)	4Bh	
	Value written (upper)	00h	Same as query
	Value written (lower)	50h	
Error check (lower)		F8h	Calculation result of CRC-16
Error check (upper)		6Bh	

7-3 Diagnosis (08h)

This function code is used to diagnose the communication between the client and server. Arbitrary data is sent and the returned data is used to determine whether the communication is normal. 00h (reply to query) is the only sub-function supported by this function code.

■ Example of diagnosis

Send arbitrary data (1234h) to the server.

● Query

Field name		Data	Description
Server address		03h	Server address 3
Function code		08h	Diagnosis
Data	Sub-function code (upper)	00h	Return the query data
	Sub-function code (lower)	00h	
	Data value (upper)	12h	Arbitrary data (1234h)
	Data value (lower)	34h	
Error check (lower)		ECh	Calculation result of CRC-16
Error check (upper)		9Eh	

● Response

Field name		Data	Description
Server address		03h	Same as query
Function code		08h	Same as query
Data	Sub-function code (upper)	00h	Same as query
	Sub-function code (lower)	00h	
	Data value (upper)	12h	Same as query
	Data value (lower)	34h	
Error check (lower)		ECh	Same as query
Error check (upper)		9Eh	

7-4 Writing to multiple holding registers (10h)

This function code is used to write data to multiple successive registers. Up to 16 registers can be written. Write the data to the upper and lower at the same time. If not, an invalid value may be written. Registers are written in order of register addresses. Note that even when an exception response is returned because some data is invalid as being outside the specified range, etc., other data may have been written properly.

■ Example of write

Set the following data as acceleration Nos.2 to 4 as part of operation data at server address 4.

Description	Register address	Value written	Corresponding decimal
Operation data acceleration No.2 (upper)	0604h	0000h	10,000
Operation data acceleration No.2 (lower)	0605h	2710h	
Operation data acceleration No.3 (upper)	0606h	0000h	20,000
Operation data acceleration No.3 (lower)	0607h	4E20h	
Operation data acceleration No.4 (upper)	0608h	0007h	500,000
Operation data acceleration No.4 (lower)	0609h	A120h	

● Query

Field name		Data	Description	
Server address		04h	Server address 4	
Function code		10h	Writing to multiple holding registers	
Data	Register address (upper)	06h	Register address to start writing from	
	Register address (lower)	04h		
	Number of registers (upper)	00h	Number of registers to be written from the starting register address (6 registers=0006h)	
	Number of registers (lower)	06h		
	Number of data bytes		0Ch	Twice the number of registers in the command
	Value written to register address (upper)		00h	Value written to register address 0604h
	Value written to register address (lower)		00h	
	Value written to register address+1 (upper)		27h	Value written to register address 0605h
	Value written to register address+1 (lower)		10h	
	Value written to register address+2 (upper)		00h	Value written to register address 0606h
	Value written to register address+2 (lower)		00h	
	Value written to register address+3 (upper)		4Eh	Value written to register address 0607h
	Value written to register address+3 (lower)		20h	
	Value written to register address+4 (upper)		00h	Value written to register address 0608h
	Value written to register address+4 (lower)		07h	
	Value written to register address+5 (upper)		A1h	Value written to register address 0609h
Value written to register address+5 (lower)		20h		
Error check (lower)		1Dh	Calculation result of CRC-16	
Error check (upper)		A9h		

- **Response**

Field name		Data	Description
Server address		04h	Same as query
Function code		10h	Same as query
Data	Register address (upper)	06h	Same as query
	Register address (lower)	04h	
	Number of registers (upper)	00h	Same as query
	Number of registers (lower)	06h	
Error check (lower)		01h	Calculation result of CRC-16
Error check (upper)		17h	

8 Register address list

All data used by the driver is 32-bit wide. Since the register for the Modbus protocol is 16-bit wide, one data is described by two registers.

Since the address assignment is big endian, the even number addresses become the upper and the odd number addresses become the lower.

8-1 Operation commands

Commands related to motor operation. Operation commands are not saved in the non-volatile memory.

Register address		Name	Description	READ/ WRITE	Setting range
Dec	Hex				
48	0030h	Group (upper)	Sets the address number for the group send.	R/W	-1 : Individual (No group setting) 1 to 31: Group address (Address number of parent server)
49	0031h	Group (lower)			
124	007Ch	Driver input command (upper)	Sets the input command to the driver.	R/W	Refer to p.228.
125	007Dh	Driver input command (lower)			
126	007Eh	Driver output command (upper)	Reads the output status of the driver.	R	Refer to p.228.
127	007Fh	Driver output command (lower)			

■ Group (0030h/0031h)

Multiple servers are made into a group and a query is sent to all servers in the group at once. Refer to p.244 for group details. The initial value is -1. When setting a group, read/write to the upper and lower at the same time.

Address (Hex)	Description of address *							
0030h	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
	[FFFFh]							
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	[FFFFh]							

* []: Initial value

Address (Hex)	Description of address *							
0031h	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
	1 to 31: Sets a group address. [FFFFh]							
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	1 to 31: Sets a group address. [FFFFh]							

* []: Initial value

■ **Driver input command (007Ch/007Dh)**

These are the driver input signals that can be accessed via RS-485 communication. Refer to p.92 for each input signal.

Address (Hex)	Description of address							
007Ch	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
	–	–	–	–	–	–	–	–
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	–	–	–	–	–	–	–	–

Address (Hex)	Description of address *							
007Dh	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
	NET-IN15 [RVS]	NET-IN14 [FWD]	NET-IN13 [-JOG]	NET-IN12 [+JOG]	NET-IN11 [SSTART]	NET-IN10 [MS2]	NET-IN9 [MS1]	NET-IN8 [MS0]
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	NET-IN7 [not used]	NET-IN6 [FREE]	NET-IN5 [STOP]	NET-IN4 [HOME]	NET-IN3 [START]	NET-IN2 [M2]	NET-IN1 [M1]	NET-IN0 [M0]

* []: Initial value

■ **Driver output command (007Eh/007Fh)**

These are the driver output signals that can be received via RS-485 communication. Refer to p.98 for each output signal.

Address (Hex)	Description of address							
007Eh	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
	–	–	–	–	–	–	–	–
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	–	–	–	–	–	–	–	–

Address (Hex)	Description of address *							
007Fh	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
	NET-OUT15 [TLC]	NET-OUT14 [END]	NET-OUT13 [MOVE]	NET-OUT12 [TIM]	NET-OUT11 [AREA3]	NET-OUT10 [AREA2]	NET-OUT9 [AREA1]	NET-OUT8 [S-BSY]
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	NET-OUT7 [ALM]	NET-OUT6 [WNG]	NET-OUT5 [READY]	NET-OUT4 [HOME-P]	NET-OUT3 [START_R]	NET-OUT2 [M2_R]	NET-OUT1 [M1_R]	NET-OUT0 [M0_R]

* []: Initial value

8-2 Maintenance commands

These commands are used to reset alarms and warnings. They are also used to execute the batch processing for the non-volatile memory. All commands can be written (WRITE). Executes when writing from 0 to 1.

Register address		Name	Description	Setting range
Dec	Hex			
384	0180h	Reset alarm (upper)	Resets the alarms that are present. Some alarms cannot be reset with the "reset alarm."	0, 1
385	0181h	Reset alarm (lower)		
388	0184h	Clear alarm records (upper)	Clears alarm records.	
389	0185h	Clear alarm records (lower)		
390	0186h	Clear warning records (upper)	Clears warning records.	
391	0187h	Clear warning records (lower)		
392	0188h	Clear communication error records (upper)	Clears the communication error records.	
393	0189h	Clear communication error records (lower)		
394	018Ah	P-PRESET execute (upper)	Presets the command position.	
395	018Bh	P-PRESET execute (lower)		
396	018Ch	Configuration (upper)	Executes the parameter recalculation and the setup.	
397	018Dh	Configuration (lower)		
398	018Eh	All data initialization (upper) *	Resets the operation data and parameters saved in the non-volatile memory, to their defaults.	
399	018Fh	All data initialization (lower) *		
400	0190h	Batch non-volatile memory read (upper)	Reads the parameters saved in the non-volatile memory, to the RAM. All operation data and parameters previously saved in the RAM are overwritten.	
401	0191h	Batch non-volatile memory read (lower)		
402	0192h	Batch non-volatile memory write (upper)	Writes the parameters saved in the RAM to the non-volatile memory. The non-volatile memory can be rewritten approximately 100,000 times.	
403	0193h	Batch non-volatile memory write (lower)		

* Communication parity, communication stop bit and transmission waiting time are not initialized. Initialize them using the **MEXE02** or **OPX-2A**.

■ Configuration (018Ch/018Dh)

Configuration will be executed when all of the following conditions are satisfied:

- An alarm is not present.
- The motor is not operated.
- The **MEXE02** is in other status than downloading, I/O test, test operation or teaching function.
- The **OPX-2A** is in other modes than the test mode or copy mode.

Shows the driver status before and after executing the configuration.

Item	Configuration is ready to execute	Configuration is executing	Configuration is completed
AC power input: PWR LED DC power input: POWER LED	Lit	Lit	Based on the driver condition.
AC power input: ALM LED DC power input: ALARM LED	OFF	OFF	
Electromagnetic brake	Hold/Release	Hold	
Motor excitation	Excitation/Non-excitation	Non-excitation	
Output signals	Allowed	Indeterminate	Allowed
Input signals		Not allowed	
Sensor inputs			



- The correct monitor value may not return even when the monitor is executed while executing the configuration.
- If the "Automatic return action" parameter is "Enable" while meeting the conditions performing the automatic return operation, the automatic return operation will not perform immediately after executing the configuration.

8-3 Monitor commands

These commands are used to monitor the command position, command speed, alarm and warning records, etc. All commands can be read (READ).

Register address		Name	Description	Setting range
Dec	Hex			
128	0080h	Present alarm (upper)	Monitors the present alarm code.	00h to FFh
129	0081h	Present alarm (lower)		
130	0082h	Alarm record 1 (upper)	Monitors the alarm records.	
131	0083h	Alarm record 1 (lower)		
132	0084h	Alarm record 2 (upper)		
133	0085h	Alarm record 2 (lower)		
134	0086h	Alarm record 3 (upper)		
135	0087h	Alarm record 3 (lower)		
136	0088h	Alarm record 4 (upper)		
137	0089h	Alarm record 4 (lower)		
138	008Ah	Alarm record 5 (upper)		
139	008Bh	Alarm record 5 (lower)		
140	008Ch	Alarm record 6 (upper)		
141	008Dh	Alarm record 6 (lower)		
142	008Eh	Alarm record 7 (upper)		
143	008Fh	Alarm record 7 (lower)		
144	0090h	Alarm record 8 (upper)		
145	0091h	Alarm record 8 (lower)		
146	0092h	Alarm record 9 (upper)		
147	0093h	Alarm record 9 (lower)		

Register address		Name	Description	Setting range
Dec	Hex			
148	0094h	Alarm record 10 (upper)	Monitors the alarm records.	00h to FFh
149	0095h	Alarm record 10 (lower)		
150	0096h	Present warning (upper)	Monitors the present warning code.	
151	0097h	Present warning (lower)		
152	0098h	Warning record 1 (upper)	Monitors the warning records.	
153	0099h	Warning record 1 (lower)		
154	009Ah	Warning record 2 (upper)		
155	009Bh	Warning record 2 (lower)		
156	009Ch	Warning record 3 (upper)		
157	009Dh	Warning record 3 (lower)		
158	009Eh	Warning record 4 (upper)		
159	009Fh	Warning record 4 (lower)		
160	00A0h	Warning record 5 (upper)		
161	00A1h	Warning record 5 (lower)		
162	00A2h	Warning record 6 (upper)		
163	00A3h	Warning record 6 (lower)		
164	00A4h	Warning record 7 (upper)		
165	00A5h	Warning record 7 (lower)		
166	00A6h	Warning record 8 (upper)		
167	00A7h	Warning record 8 (lower)		
168	00A8h	Warning record 9 (upper)		
169	00A9h	Warning record 9 (lower)		
170	00AAh	Warning record 10 (upper)		
171	00ABh	Warning record 10 (lower)		
172	00ACh	Communication error code (upper)	Monitors the last received communication error code.	
173	00ADh	Communication error code (lower)		
174	00AEh	Communication error code record 1 (upper)	Monitors the communication error records that have occurred in the past.	
175	00AFh	Communication error code record 1 (lower)		
176	00B0h	Communication error code record 2 (upper)		
177	00B1h	Communication error code record 2 (lower)		
178	00B2h	Communication error code record 3 (upper)		
179	00B3h	Communication error code record 3 (lower)		
180	00B4h	Communication error code record 4 (upper)		
181	00B5h	Communication error code record 4 (lower)		
182	00B6h	Communication error code record 5 (upper)		
183	00B7h	Communication error code record 5 (lower)		
184	00B8h	Communication error code record 6 (upper)		

Register address		Name	Description	Setting range
Dec	Hex			
185	00B9h	Communication error code record 6 (lower)	Monitors the communication error records that have occurred in the past.	00h to FFh
186	00BAh	Communication error code record 7 (upper)		
187	00BBh	Communication error code record 7 (lower)		
188	00BCh	Communication error code record 8 (upper)		
189	00BDh	Communication error code record 8 (lower)		
190	00BEh	Communication error code record 9 (upper)		
191	00BFh	Communication error code record 9 (lower)		
192	00C0h	Communication error code record 10 (upper)		
193	00C1h	Communication error code record 10 (lower)		
194	00C2h	Present selected data No. (upper)		
195	00C3h	Present selected data No. (lower)		
196	00C4h	Present operation data No. (upper)	Monitors the operation data No. corresponding to the data used in the current positioning operation. This address is used in linked-motion operation and sequential positioning operation. While the motor is stopped, the last used operation data number is indicated. "-1" is indicated until the positioning operation is performed after turning the power on.	-1 to 63
197	00C5h	Present operation data No. (lower)		
198	00C6h	Command position (upper)	Monitors the command position.	-2,147,483,648 to 2,147,483,647 step
199	00C7h	Command position (lower)		
200	00C8h	Command speed (upper)	Monitors the current command speed.	-4,500 to +4,500 r/min +: Forward -: Reverse 0: Stop
201	00C9h	Command speed (lower)		
204	00CCh	Actual position (upper)	Monitors the actual position. Shows the value that updated the data having set with the electronic gear.	-2,147,483,648 to 2,147,483,647 step
205	00CDh	Actual position (lower)		
206	00CEh	Actual speed (upper)	Monitors the actual speed.	-4,500 to +4,500 r/min
207	00CFh	Actual speed (lower)		
210	00D2h	Remaining dwell time (upper)	Monitors how much of the dwell time used in the linked-motion 2 operation remains.	0 to 50,000 ms
211	00D3h	Remaining dwell time (lower)		
212	00D4h	Direct I/O and electromagnetic brake status (upper)	Monitors the each direct I/O signal and electromagnetic brake status.	Refer to the following table.
213	00D5h	Direct I/O and electromagnetic brake status (lower)		

■ Direct I/O and electromagnetic brake status (00D4h/00D5h)

Address (Hex)		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
00D4h	Upper	–	–	–	–	–	–	–	MB
	Lower	–	–	OUT5	OUT4	OUT3	OUT2	OUT1	OUT0
00D5h	Upper	–	–	IN7	IN6	IN5	IN4	IN3	IN2
	Lower	IN1	IN0	–	–	SLIT	HOMES	–LS	+LS

8-4 Parameter R/W commands

Write or read parameters. All commands can be read and written (READ/WRITE). For details on parameters, refer to p.110.

■ Operation data

If the data is changed, a recalculation and setup will be performed after the operation is stopped.

Register address		Name	Setting range	Initial value
Dec	Hex			
1024	0400h	Position No.0 (upper) Position No.0 (lower) to Position No.63 (upper) Position No.63 (lower)	–8,388,608 to 8,388,607 step	0
1025	0401h			
to	to			
1150	047Eh			
1151	047Fh			
1152	0480h	Operating speed No.0 (upper) Operating speed No.0 (lower) to Operating speed No.63 (upper) Operating speed No.63 (lower)	0 to 1,000,000 Hz	1,000
1153	0481h			
to	to			
1278	04FEh			
1279	04FFh			
1280	0500h	Operation mode No.0 (upper) Operation mode No.0 (lower) to Operation mode No.63 (upper) Operation mode No.63 (lower)	0: Incremental 1: Absolute	0
1281	0501h			
to	to			
1406	057Eh			
1407	057Fh			
1408	0580h	Operation function No.0 (upper) Operation function No.0 (lower) to Operation function No.63 (upper) Operation function No.63 (lower)	0: Single-motion 1: Linked-motion 2: Linked-motion 2 3: Push	0
1409	0581h			
to	to			
1534	05FEh			
1535	05FFh			
1536	0600h	Acceleration No.0 (upper) Acceleration No.0 (lower) to Acceleration No.63 (upper) Acceleration No.63 (lower)	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *1 *2	1,000
1537	0601h			
to	to			
1662	067Eh			
1663	067Fh			
1664	0680h	Deceleration No.0 (upper) Deceleration No.0 (lower) to Deceleration No.63 (upper) Deceleration No.63 (lower)	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *1 *2	1,000
1665	0681h			
to	to			
1790	06FEh			
1791	06FFh			
1792	0700h	Push current No.0 (upper) Push current No.0 (lower) to Push current No.63 (upper) Push current No.63 (lower)	0 to 1,000 (1=0.1 %)	200
1793	0701h			
to	to			
1918	077Eh			
1919	077Fh			
1920	0780h	Sequential positioning No.0 (upper) Sequential positioning No.0 (lower) to Sequential positioning No.63 (upper) Sequential positioning No.63 (lower)	0: Disable 1: Enable	0
1921	0781h			
to	to			
2046	07FEh			
2047	07FFh			

Register address		Name	Setting range	Initial value
Dec	Hex			
2048	0800h	Dwell time No.0 (upper)	0 to 50,000 (1=0.001 s)	0
2049	0801h	Dwell time No.0 (lower)		
to	to	to		
2174	087Eh	Dwell time No.63 (upper)		
2175	087Fh	Dwell time No.63 (lower)		

*1 This item is effective when the "Acceleration/deceleration type" parameter is set to "Separate." If this parameter is set to "Common," the values of the "Common acceleration" and "Common deceleration" parameters will be used (initial value: separate).

*2 Acceleration/deceleration rate (ms/kHz) or acceleration/deceleration time (s) can be selected using "Acceleration/deceleration unit" parameter. (initial value: acceleration/deceleration rate).

■ User parameters

When a parameter is changed, the timing for updating the new value varies depending on the parameter. Refer to "Notation rules" on p.110 for details on update timing.

Register address		Name	Setting range	Initial value	Update
Dec	Hex				
512	0200h	STOP input action (upper)	0: Immediate stop 1: Deceleration stop 2: Immediate stop & Current OFF 3: Deceleration stop & Current OFF	1	A
513	0201h	STOP input action (lower)			
514	0202h	Hardware overtravel (upper)	0: Disable 1: Enable	1	A
515	0203h	Hardware overtravel (lower)			
516	0204h	Overtravel action (upper)	0: Immediate stop 1: Deceleration stop	0	A
517	0205h	Overtravel action (lower)			
518	0206h	END signal range (upper)	0 to 180 (1=0.1°)	18	A
519	0207h	END signal range (lower)			
520	0208h	Positioning complete output offset (upper)	-18 to 18 (1=0.1°)	0	A
521	0209h	Positioning complete output offset (lower)			
522	020Ah	AREA1 positive direction position (upper)	-8,388,608 to 8,388,607 step	0	A
523	020Bh	AREA1 positive direction position (lower)			
524	020Ch	AREA1 negative direction position (upper)			
525	020Dh	AREA1 negative direction position (lower)			
526	020Eh	AREA2 positive direction position (upper)			
527	020Fh	AREA2 positive direction position (lower)			
528	0210h	AREA2 negative direction position (upper)			
529	0211h	AREA2 negative direction position (lower)			
530	0212h	AREA3 positive direction position (upper)			
531	0213h	AREA3 positive direction position (lower)			
532	0214h	AREA3 negative direction position (upper)			

Register address		Name	Setting range	Initial value	Update
Dec	Hex				
533	0215h	AREA3 negative direction position (lower)	-8,388,608 to 8,388,607 step	0	A
534	0216h	Minimum ON time for MOVE output (upper)	0 to 255 ms	0	A
535	0217h	Minimum ON time for MOVE output (lower)			
536	0218h	LS contact configuration (upper)	0: Make (N.O.) 1: Brake (N.C.)	0	C
537	0219h	LS contact configuration (lower)			C
538	021Ah	HOMES logic level (upper)			C
539	021Bh	HOMES logic level (lower)			C
540	021Ch	SLIT logic level (upper)			C
541	021Dh	SLIT logic level (lower)			
576	0240h	RUN current (upper)	0 to 1,000 (1=0.1 %)	1,000	A
577	0241h	RUN current (lower)			
578	0242h	STOP current (upper)	0 to 500 (1=0.1 %)	500	A
579	0243h	STOP current (lower)			
580	0244h	Position loop gain (upper)	1 to 50	10	A
581	0245h	Position loop gain (lower)			
582	0246h	Speed loop gain (upper)	10 to 200	180	A
583	0247h	Speed loop gain (lower)			
584	0248h	Speed loop integral time constant (upper)	100 to 2,000 (1=0.1 ms)	1,000	A
585	0249h	Speed loop integral time constant (lower)			
586	024Ah	Speed filter (upper)	0 to 200 ms	1	B
587	024Bh	Speed filter (lower)			
588	024Ch	Moving average time (upper)	1 to 200 ms	1	B
589	024Dh	Moving average time (lower)			
640	0280h	Common acceleration (upper)	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
641	0281h	Common acceleration (lower)			
642	0282h	Common deceleration (upper)	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
643	0283h	Common deceleration (lower)			
644	0284h	Starting speed (upper)	0 to 1,000,000 Hz	500	B
645	0285h	Starting speed (lower)			
646	0286h	JOG operating speed (upper)	1 to 1,000,000 Hz	1,000	B
647	0287h	JOG operating speed (lower)			
648	0288h	Acceleration/deceleration rate of JOG (upper)	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
649	0289h	Acceleration/deceleration rate of JOG (lower)			
650	028Ah	JOG starting speed (upper)	0 to 1,000,000 Hz	500	B
651	028Bh	JOG starting speed (lower)			
652	028Ch	Acceleration/deceleration type (upper)	0: Common 1: Separate	1	B
653	028Dh	Acceleration/deceleration type (lower)			
654	028Eh	Acceleration/deceleration unit (upper)	0: ms/kHz 1: s	0	C
655	028Fh	Acceleration/deceleration unit (lower)			

Register address		Name	Setting range	Initial value	Update
Dec	Hex				
704	02C0h	Home-seeking mode (upper)	0: 2-sensor mode 1: 3-sensor mode 2: Push mode	1	B
705	02C1h	Home-seeking mode (lower)			
706	02C2h	Operating speed of home-seeking (upper)	1 to 1,000,000 Hz	1,000	B
707	02C3h	Operating speed of home-seeking (lower)			
708	02C4h	Acceleration/deceleration of home-seeking (upper)	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s)*	1,000	B
709	02C5h	Acceleration/deceleration of home-seeking (lower)			
710	02C6h	Starting speed of home-seeking (upper)	1 to 1,000,000 Hz	500	B
711	02C7h	Starting speed of home-seeking (lower)			
712	02C8h	Position offset of home-seeking (upper)	-8,388,608 to 8,388,607 step	0	B
713	02C9h	Position offset of home-seeking (lower)			
714	02CAh	Starting direction of home-seeking (upper)	0: Negative direction 1: Positive direction	1	B
715	02CBh	Starting direction of home-seeking (lower)			
716	02CCh	SLIT detection with home-seeking (upper)	0: Disable 1: Enable	0	B
717	02CDh	SLIT detection with home-seeking (lower)			
718	02CEh	TIM signal detection with home-seeking (upper)	0: Disable 1: Enable	0	B
719	02CFh	TIM signal detection with home-seeking (lower)			
720	02D0h	Operating current of home-seeking with push-motion (upper)	0 to 1,000 (1=0.1 %)	1,000	B
721	02D1h	Operating current of home-seeking with push-motion (lower)			
768	0300h	Overload alarm (upper)	1 to 300 (1=0.1 s)	50	A
769	0301h	Overload alarm (lower)			
770	0302h	Excessive position deviation alarm at current ON (upper)	1 to 30,000 (1=0.01 rev)	300	A
771	0303h	Excessive position deviation alarm at current ON (lower)			
776	0308h	Return-to-home incomplete alarm (upper)	0: Disable 1: Enable	0	C
777	0309h	Return-to-home incomplete alarm (lower)			
832	0340h	Overheat warning (upper)	40 to 85 °C	85	A
833	0341h	Overheat warning (lower)			
834	0342h	Overload warning (upper)	1 to 300 (1=0.1 s)	50	A
835	0343h	Overload warning (lower)			
836	0344h	Overspeed warning (upper)	1 to 5,000 r/min	4,500	A
837	0345h	Overspeed warning (lower)			

Register address		Name	Setting range	Initial value	Update
Dec	Hex				
838	0346h	Overvoltage warning (upper)	AC power input: 120 to 450 V DC power input: 150 to 630 (1=0.1 V)	AC power input: 435 DC power input: 630	A
839	0347h	Overvoltage warning (lower)			
840	0348h	Undervoltage warning (upper)	AC power input: 120 to 280 V DC power input: 150 to 630 (1=0.1 V)	AC power input: 120 DC power input: 180	A
841	0349h	Undervoltage warning (lower)			
842	034Ah	Excessive position deviation warning at current ON (upper)	1 to 30,000 (1=0.01 rev)	300	A
843	034Bh	Excessive position deviation warning at current ON (lower)			
896	0380h	Electronic gear A (upper)	1 to 65,535	1	C
897	0381h	Electronic gear A (lower)			
898	0382h	Electronic gear B (upper)	1 to 65,535	1	C
899	0383h	Electronic gear B (lower)			
900	0384h	Motor rotation direction (upper)	0: Positive direction=CCW 1: Positive direction=CW	1	C
901	0385h	Motor rotation direction (lower)			
902	0386h	Software overtravel (upper)	0: Disable 1: Enable	1	A
903	0387h	Software overtravel (lower)			
904	0388h	Positive software limit (upper)	-8,388,608 to 8,388,607 step	8,388,607	A
905	0389h	Positive software limit (lower)			
906	038Ah	Negative software limit (upper)	-8,388,608 to 8,388,607 step	-8,388,608	A
907	038Bh	Negative software limit (lower)			
908	038Ch	Preset position (upper)	-8,388,608 to 8,388,607 step	0	A
909	038Dh	Preset position (lower)			
910	038Eh	Wrap setting (upper)	0: Disable 1: Enable	0	C
911	038Fh	Wrap setting (lower)			
912	0390h	Wrap setting range (upper)	1 to 8,388,607 step	1,000	C
913	0391h	Wrap setting range (lower)			
960	03C0h	Data setter speed display (upper)	0: Signed 1: Absolute value	0	A
961	03C1h	Data setter speed display (lower)			
962	03C2h	Data setter edit (upper)	0: Disable 1: Enable	1	A
963	03C3h	Data setter edit (lower)			
4096	1000h	MS0 operation No. selection (upper)	0 to 63	0	B
4097	1001h	MS0 operation No. selection (lower)			
4098	1002h	MS1 operation No. selection (upper)			
4099	1003h	MS1 operation No. selection (lower)			
4100	1004h	MS2 operation No. selection (upper)			
4101	1005h	MS2 operation No. selection (lower)	0 to 63	2	B
4102	1006h	MS3 operation No. selection (upper)			
4103	1007h	MS3 operation No. selection (lower)			
4104	1008h	MS4 operation No. selection (upper)		4	B

Register address		Name	Setting range	Initial value	Update
Dec	Hex				
4105	1009h	MS4 operation No. selection (lower)	0 to 63	4	B
4106	100Ah	MS5 operation No. selection (upper)		5	B
4107	100Bh	MS5 operation No. selection (lower)			
4108	100Ch	HOME-P output function selection (upper)	0: Home output 1: Return-to-home complete output	0	A
4109	100Dh	HOME-P output function selection (lower)			
4128	1020h	Filter selection (upper)	0: Speed filter 1: Moving average filter	0	C
4129	1021h	Filter selection (lower)			
4130	1022h	Speed difference gain 1 (upper)	0 to 500	45	A
4131	1023h	Speed difference gain 1 (lower)			
4132	1024h	Speed difference gain 2 (upper)	0 to 500	45	A
4133	1025h	Speed difference gain 2 (lower)			
4134	1026h	Control mode (upper)	0: Normal mode 1: Current control mode	0	C
4135	1027h	Control mode (lower)			
4136	1028h	Smooth drive (upper)	0: Disable 1: Enable	1	C
4137	1029h	Smooth drive (lower)			
4160	1040h	Automatic return operation (upper)	0: Disable 1: Enable	0	C
4161	1041h	Automatic return operation (lower)			
4162	1042h	Operation speed of automatic return (upper)	1 to 1,000,000 Hz	1,000	B
4163	1043h	Operation speed of automatic return (lower)			
4164	1044h	Acceleration (deceleration) of automatic return (upper)	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
4165	1045h	Acceleration (deceleration) of automatic return (lower)			
4166	1046h	Starting speed of automatic return (upper)	0 to 1,000,000 Hz	500	B
4167	1047h	Starting speed of automatic return (lower)			
4168	1048h	JOG travel amount (upper)	1 to 8,388,607 step	1	B
4169	1049h	JOG travel amount (lower)			
4224	1080h	Excessive position deviation alarm at current OFF (upper)	1 to 30,000 (1=0.01 rev)	10,000	A
4225	1081h	Excessive position deviation alarm at current OFF (lower)			
4352	1100h	IN0 input function selection (upper)	Refer to "Setting range for IN input function selection" on p.243 .	3: HOME	C
4353	1101h	IN0 input function selection (lower)			
4354	1102h	IN1 input function selection (upper)		4: START	C
4355	1103h	IN1 input function selection (lower)			

Register address		Name	Setting range	Initial value	Update	
Dec	Hex					
4356	1104h	IN2 input function selection (upper)	Refer to "Setting range for IN input function selection" on p.243.	48: M0	C	
4357	1105h	IN2 input function selection (lower)				
4358	1106h	IN3 input function selection (upper)		49: M1	C	
4359	1107h	IN3 input function selection (lower)				
4360	1108h	IN4 input function selection (upper)		50: M2	C	
4361	1109h	IN4 input function selection (lower)				
4362	110Ah	IN5 input function selection (upper)		16: FREE	C	
4363	110Bh	IN5 input function selection (lower)				
4364	110Ch	IN6 input function selection (upper)		18: STOP	C	
4365	110Dh	IN6 input function selection (lower)				
4366	110Eh	IN7 input function selection (upper)		24: ALM-RST	C	
4367	110Fh	IN7 input function selection (lower)				
4384	1120h	IN0 input logic level setting (upper)		0: Make (N.O.) 1: Brake (N.C.)	0	C
4385	1121h	IN0 input logic level setting (lower)				C
4386	1122h	IN1 input logic level setting (upper)	C			
4387	1123h	IN1 input logic level setting (lower)	C			
4388	1124h	IN2 input logic level setting (upper)	C			
4389	1125h	IN2 input logic level setting (lower)	C			
4390	1126h	IN3 input logic level setting (upper)	C			
4391	1127h	IN3 input logic level setting (lower)	C			
4392	1128h	IN4 input logic level setting (upper)	C			
4393	1129h	IN4 input logic level setting (lower)	C			
4394	112Ah	IN5 input logic level setting (upper)	C			
4395	112Bh	IN5 input logic level setting (lower)	C			
4396	112Ch	IN6 input logic level setting (upper)	C			
4397	112Dh	IN6 input logic level setting (lower)	C			
4398	112Eh	IN7 input logic level setting (upper)	C			

Register address		Name	Setting range	Initial value	Update
Dec	Hex				
4399	112Fh	IN7 input logic level setting (lower)	0: Make (N.O.) 1: Brake (N.C.)	0	C
4416	1140h	OUT0 output function selection (upper)	Refer to "Setting range for OUT output function selection" on p.243.	70: HOME-P	C
4417	1141h	OUT0 output function selection (lower)			
4418	1142h	OUT1 output function selection (upper)		69: END	C
4419	1143h	OUT1 output function selection (lower)			
4420	1144h	OUT2 output function selection (upper)		73: AREA1	C
4421	1145h	OUT2 output function selection (lower)			
4422	1146h	OUT3 output function selection (upper)		67: READY	C
4423	1147h	OUT3 output function selection (lower)			
4424	1148h	OUT4 output function selection (upper)		66: WNG	C
4425	1149h	OUT4 output function selection (lower)			
4426	114Ah	OUT5 output function selection (upper)		65: ALM	C
4427	114Bh	OUT5 output function selection (lower)			
4448	1160h	NET-IN0 input function selection (upper)		Refer to "Setting range for NET-IN input function selection" on p.243.	48: M0
4449	1161h	NET-IN0 input function selection (lower)			
4450	1162h	NET-IN1 input function selection (upper)	49: M1		C
4451	1163h	NET-IN1 input function selection (lower)			
4452	1164h	NET-IN2 input function selection (upper)	50: M2		C
4453	1165h	NET-IN2 input function selection (lower)			
4454	1166h	NET-IN3 input function selection (upper)	4: START		C
4455	1167h	NET-IN3 input function selection (lower)			
4456	1168h	NET-IN4 input function selection (upper)	3: HOME		C
4457	1169h	NET-IN4 input function selection (lower)			
4458	116Ah	NET-IN5 input function selection (upper)	18: STOP		C
4459	116Bh	NET-IN5 input function selection (lower)			
4460	116Ch	NET-IN6 input function selection (upper)	16: FREE		C
4461	116Dh	NET-IN6 input function selection (lower)			

Register address		Name	Setting range	Initial value	Update
Dec	Hex				
4462	116Eh	NET-IN7 input function selection (upper)	"Setting range for NET-IN input function selection" on p.243	0: No function	C
4463	116Fh	NET-IN7 input function selection (lower)			
4464	1170h	NET-IN8 input function selection (upper)		8: MS0	C
4465	1171h	NET-IN8 input function selection (lower)			
4466	1172h	NET-IN9 input function selection (upper)		9: MS1	C
4467	1173h	NET-IN9 input function selection (lower)			
4468	1174h	NET-IN10 input function selection (upper)		10: MS2	C
4469	1175h	NET-IN10 input function selection (lower)			
4470	1176h	NET-IN11 input function selection (upper)		5: SSTART	C
4471	1177h	NET-IN11 input function selection (lower)			
4472	1178h	NET-IN12 input function selection (upper)		6: +JOG	C
4473	1179h	NET-IN12 input function selection (lower)			
4474	117Ah	NET-IN13 input function selection (upper)		7: -JOG	C
4475	117Bh	NET-IN13 input function selection (lower)			
4476	117Ch	NET-IN14 input function selection (upper)		1: FWD	C
4477	117Dh	NET-IN14 input function selection (lower)			
4478	117Eh	NET-IN15 input function selection (upper)	2: RVS	C	
4479	117Fh	NET-IN15 input function selection (lower)			
4480	1180h	NET-OUT0 output function selection (upper)	"Setting range for NET-OUT output function selection" on p.243	48: M0_R	C
4481	1181h	NET-OUT0 output function selection (lower)			
4482	1182h	NET-OUT1 output function selection (upper)		49: M1_R	C
4483	1183h	NET-OUT1 output function selection (lower)			
4484	1184h	NET-OUT2 output function selection (upper)		50: M2_R	C
4485	1185h	NET-OUT2 output function selection (lower)			
4486	1186h	NET-OUT3 output function selection (upper)		4: START_R	C
4487	1187h	NET-OUT3 output function selection (lower)			
4488	1188h	NET-OUT4 output function selection (upper)		70: HOME-P	C

Register address		Name	Setting range	Initial value	Update
Dec	Hex				
4489	1189h	NET-OUT4 output function selection (lower)	"Setting range for NET-OUT output function selection" on p.243	70: HOME-P	C
4490	118Ah	NET-OUT5 output function selection (upper)		67: READY	C
4491	118Bh	NET-OUT5 output function selection (lower)		66: WNG	C
4492	118Ch	NET-OUT6 output function selection (upper)			
4493	118Dh	NET-OUT6 output function selection (lower)		65: ALM	C
4494	118Eh	NET-OUT7 output function selection (upper)			
4495	118Fh	NET-OUT7 output function selection (lower)		80: S-BSY	C
4496	1190h	NET-OUT8 output function selection (upper)			
4497	1191h	NET-OUT8 output function selection (lower)		73: AREA1	C
4498	1192h	NET-OUT9 output function selection (upper)			
4499	1193h	NET-OUT9 output function selection (lower)		74: AREA2	C
4500	1194h	NET-OUT10 output function selection (upper)			
4501	1195h	NET-OUT10 output function selection (lower)		75: AREA3	C
4502	1196h	NET-OUT11 output function selection (upper)			
4503	1197h	NET-OUT11 output function selection (lower)		72: TIM	C
4504	1198h	NET-OUT12 output function selection (upper)			
4505	1199h	NET-OUT12 output function selection (lower)		68: MOVE	C
4506	119Ah	NET-OUT13 output function selection (upper)			
4507	119Bh	NET-OUT13 output function selection (lower)		69: END	C
4508	119Ch	NET-OUT14 output function selection (upper)			
4509	119Dh	NET-OUT14 output function selection (lower)	71: TLC	C	
4510	119Eh	NET-OUT15 output function selection (upper)			
4511	119Fh	NET-OUT15 output function selection (lower)			
4608	1200h	Communication timeout (upper)	0: Not monitored 1 to 10,000 ms	0	A
4609	1201h	Communication timeout (lower)			
4610	1202h	Communication error alarm (upper)	1 to 10 times	3	A
4611	1203h	Communication error alarm (lower)			

* Acceleration/deceleration rate (ms/kHz) or acceleration/deceleration time (s) can be selected using "Acceleration/deceleration unit" parameter. (initial value: acceleration/deceleration rate).

● **Setting range for IN input function selection**

0: No function	8: MS0	18: STOP	35: R3	43: R11	51: M3
1: FWD	9: MS1	24: ALM-RST	36: R4	44: R12	52: M4
2: RVS	10: MS2	25: P-PRESET	37: R5	45: R13	53: M5
3: HOME	11: MS3	26: P-CLR *	38: R6	46: R14	
4: START	12: MS4	27: HMI	39: R7	47: R15	
5: SSTART	13: MS5	32: R0	40: R8	48: M0	
6: +JOG	16: FREE	33: R1	41: R9	49: M1	
7: -JOG	17: C-ON	34: R2	42: R10	50: M2	

* It cannot be used.

● **Setting range for OUT output function selection**

0: No function	10: MS2_R	35: R3	45: R13	61: -LS_R	72: TIM
1: FWD_R	11: MS3_R	36: R4	46: R14	62: HOMES_R	73: AREA1
2: RVS_R	12: MS4_R	37: R5	47: R15	63: SLIT_R	74: AREA2
3: HOME_R	13: MS5_R	38: R6	48: M0_R	65: ALM	75: AREA3
4: START_R	16: FREE_R	39: R7	49: M1_R	66: WNG	80: S-BSY
5: SSTART_R	17: C-ON_R	40: R8	50: M2_R	67: READY	82: MPS *
6: +JOG_R	18: STOP_R	41: R9	51: M3_R	68: MOVE	
7: -JOG_R	32: R0	42: R10	52: M4_R	69: END	
8: MS0_R	33: R1	43: R11	53: M5_R	70: HOME-P	
9: MS1_R	34: R2	44: R12	60: +LS_R	71: TLC	

* AC power input only.

● **Setting range for NET-IN input function selection**

0: No function	8: MS0	18: STOP	35: R3	43: R11	51: M3
1: FWD	9: MS1	24: ALM-RST	36: R4	44: R12	52: M4
2: RVS	10: MS2	25: P-PRESET	37: R5	45: R13	53: M5
3: HOME	11: MS3	26: P-CLR *	38: R6	46: R14	
4: START	12: MS4	27: HMI	39: R7	47: R15	
5: SSTART	13: MS5	32: R0	40: R8	48: M0	
6: +JOG	16: FREE	33: R1	41: R9	49: M1	
7: -JOG	17: C-ON	34: R2	42: R10	50: M2	

* It cannot be used.

● **Setting range for NET-OUT output function selection**

0: No function	10: MS2_R	35: R3	45: R13	61: -LS_R	72: TIM
1: FWD_R	11: MS3_R	36: R4	46: R14	62: HOMES_R	73: AREA1
2: RVS_R	12: MS4_R	37: R5	47: R15	63: SLIT_R	74: AREA2
3: HOME_R	13: MS5_R	38: R6	48: M0_R	65: ALM	75: AREA3
4: START_R	16: FREE_R	39: R7	49: M1_R	66: WNG	80: S-BSY
5: SSTART_R	17: C-ON_R	40: R8	50: M2_R	67: READY	82: MPS *
6: +JOG_R	18: STOP_R	41: R9	51: M3_R	68: MOVE	
7: -JOG_R	32: R0	42: R10	52: M4_R	69: END	
8: MS0_R	33: R1	43: R11	53: M5_R	70: HOME-P	
9: MS1_R	34: R2	44: R12	60: +LS_R	71: TLC	

* AC power input only.

9 Group send


Multiple servers are made into a group and a query is sent to all servers in the group at once.

■ Group composition

A group consists of one parent server and child servers and only the parent server returns a response.

● Group address

To perform a group send, set a group address to the child servers to be included in the group. The child servers to which the group address has been set can receive a query sent to the parent server.



● Parent server

No special setting is required on the parent server to perform a group send. The address of the parent server becomes the group address. When a query is sent to the parent server from the client, the parent server executes the requested process and then returns a response (same as with the unicast mode).

● Child server


Use a "Group" command to set a group address to each child server. Change the group in the unicast mode. When setting a group, read/write to the upper and lower at the same time.


Register address		Name	Description	READ/ WRITE	Setting range
Dec	Hex				
48	0030h	Group (upper)	Sets the group address.	R/W	-1 : Individual (No group setting) 1 to 31 : Group address (Address number of parent server)
49	0031h	Group (lower)			

memo Since the group setting is not saved in the non-volatile memory even when the "Batch non-volatile memory write" executes, the group setting will be cleared when turning the driver power supply OFF.

■ Function code to execute in a group send

Function code	Function
10h	Writing to multiple holding registers





10 Setting example of the operation

10-1 Positioning operation

As an example, here is a description how to execute the following positioning operation. For details of positioning operation, refer to p.165.

This section explains by using the function code "10h" for data writing and using the function code "06h" for remote I/O writing.

- **Setting example**
 - Address number (Server address) : 1
 - Position (travel amount) : 1,000 steps
 - Operating speed : 5,000 Hz
- **Operation procedure**

1. Send the following query and set the position (travel amount) of the operation data No.0 to 1,000 steps.

Query

Field name		Data	Description
Server address		01h	Server address1
Function code		10h	Writing to multiple holding registers
Data	Register address (upper)	04h	Register address to start writing from = Position No.0 (0400h)
	Register address (lower)	00h	
	Number of registers (upper)	00h	Number of registers to be written from the starting register address
	Number of registers (lower)	02h	
	Number of bytes	04h	Twice the number of registers in the query
	Value written to register address (upper)	00h	Value written to register address = 1,000 steps (0000 03E8h)
	Value written to register address (lower)	00h	
	Value written to register address +1 (upper)	03h	
Value written to register address +1 (lower)	E8h		
Error check (lower)		C1h	Calculation result of CRC-16
Error check (upper)		D1h	

Response

Field name		Data	Description
Server address		01h	Same as query
Function code		10h	
Data	Register address (upper)	04h	
	Register address (lower)	00h	
	Number of registers (upper)	00h	
	Number of registers (lower)	02h	
Error check (lower)		40h	Calculation result of CRC-16
Error check (upper)		F8h	

2. Send the following query and set the operating speed of the operation data No.0 to 5,000 Hz.

Query

Field name		Data	Description
Server address		01h	Server address1
Function code		10h	Writing to multiple holding registers
Data	Register address (upper)	04h	Register address to start writing from = Operating speed No.0 (0480h)
	Register address (lower)	80h	
	Number of registers (upper)	00h	Number of registers to be written from the starting register address
	Number of registers (lower)	02h	
	Number of bytes	04h	Twice the number of registers in the query
	Value written to register address (upper)	00h	Value written to register address = 5,000 Hz (0000 1388h)
	Value written to register address (lower)	00h	
	Value written to register address +1 (upper)	13h	
Value written to register address +1 (lower)	88h		
Error check (lower)		C4h	Calculation result of CRC-16
Error check (upper)		59h	

Response

Field name		Data	Description
Server address		01h	Same as query
Function code		10h	
Data	Register address (upper)	04h	
	Register address (lower)	80h	
	Number of registers (upper)	00h	
	Number of registers (lower)	02h	
Error check (lower)		41h	Calculation result of CRC-16
Error check (upper)		10h	

3. Send the following query and turn START ON.
Positioning operation is started.

Query

Field name		Data	Description
Server address		01h	Server address1
Function code		06h	Writing to a holding register
Data	Register address (upper)	00h	Register address to which writing is executed = Driver input command (007Dh)
	Register address (lower)	7Dh	
	Value written (upper)	00h	Value written to register address = START ON (0008h)
	Value written (lower)	08h	
Error check (lower)		18h	Calculation result of CRC-16
Error check (upper)		14h	

Response

Field name		Data	Description
Server address		01h	Same as query
Function code		06h	
Data	Register address (upper)	00h	
	Register address (lower)	7Dh	
	Value written (upper)	00h	
	Value written (lower)	08h	
Error check (lower)		18h	Calculation result of CRC-16
Error check (upper)		14h	

4. When positioning operation is started, send the following query and turn START OFF again.

Query

Field name		Data	Description
Server address		01h	Server address1
Function code		06h	Writing to a holding register
Data	Register address (upper)	00h	Register address to which writing is executed = Driver input command (007Dh)
	Register address (lower)	7Dh	
	Value written (upper)	00h	Value written to register address = START OFF (0000h)
	Value written (lower)	00h	
Error check (lower)		19h	Calculation result of CRC-16
Error check (upper)		D2h	

Response

Field name		Data	Description
Server address		01h	Same as query
Function code		06h	
Data	Register address (upper)	00h	
	Register address (lower)	7Dh	
	Value written (upper)	00h	
	Value written (lower)	00h	
Error check (lower)		19h	Calculation result of CRC-16
Error check (upper)		D2h	

10-2 Continuous operation

As an example, here is a description how to execute the following continuous operation. For details of continuous operation, refer to p.188.

This section explains by using the function code "10h" for data writing and using the function code "06h" for remote I/O writing.

● Setting example

- Address number (Server address) : 1
- Rotation direction : Forward direction (FWD)
- Operating speed : 5,000 Hz

● Operation procedure

1. Send the following query and set the operating speed of the operation data No.0 to 5,000 Hz.

Query

Field name		Data	Description
Server address		01h	Server address1
Function code		10h	Writing to multiple holding registers
Data	Register address (upper)	04h	Register address to start writing from = Operating speed No.0 (0480h)
	Register address (lower)	80h	
	Number of registers (upper)	00h	Number of registers to be written from the starting register address
	Number of registers (lower)	02h	
	Number of bytes	04h	Twice the number of registers in the query
	Value written to register address (upper)	00h	Value written to register address = 5,000 Hz (0000 1388h)
	Value written to register address (lower)	00h	
	Value written to register address +1 (upper)	13h	
Value written to register address +1 (lower)	88h		
Error check (lower)		C4h	Calculation result of CRC-16
Error check (upper)		59h	

Response

Field name		Data	Description
Server address		01h	Same as query
Function code		10h	
Data	Register address (upper)	04h	
	Register address (lower)	80h	
	Number of registers (upper)	00h	
	Number of registers (lower)	02h	
Error check (lower)		41h	Calculation result of CRC-16
Error check (upper)		10h	

- Send the following query and turn FWD ON.
Continuous operation is started.

Query

Field name		Data	Description
Server address		01h	Server address1
Function code		06h	Writing to a holding register
Data	Register address (upper)	00h	Register address to which writing is executed = Driver input command (007Dh)
	Register address (lower)	7Dh	
	Value written (upper)	40h	Value written to register address = FWD ON (4000h)
	Value written (lower)	00h	
Error check (lower)		28h	Calculation result of CRC-16
Error check (upper)		12h	

Response

Field name		Data	Description	
Server address		01h	Same as query	
Function code		06h		
Data	Register address (upper)	00h		
	Register address (lower)	7Dh		
	Value written (upper)	40h		
	Value written (lower)	00h		
Error check (lower)		28h		Calculation result of CRC-16
Error check (upper)		12h		

- To stop continuous operation, send the following query and turn FWD OFF again.
The motor decelerates to a stop.

Query

Field name		Data	Description
Server address		01h	Server address1
Function code		06h	Writing to a holding register
Data	Register address (upper)	00h	Register address to which writing is executed = Driver input command (007Dh)
	Register address (lower)	7Dh	
	Value written (upper)	00h	Value written to register address = FWD OFF (0000h)
	Value written (lower)	00h	
Error check (lower)		19h	Calculation result of CRC-16
Error check (upper)		D2h	

Response

Field name		Data	Description	
Server address		01h	Same as query	
Function code		06h		
Data	Register address (upper)	00h		
	Register address (lower)	7Dh		
	Value written (upper)	00h		
	Value written (lower)	00h		
Error check (lower)		19h		Calculation result of CRC-16
Error check (upper)		D2h		

10-3 Return-to-home operation

As an example, here is a description how to execute the following return-to-home operation. For details of return-to-home operation, refer to p.179.

● Setting example

- Address number (Server address) : 1
- Operation condition : Initial value

● Operation procedure

1. Send the following query and turn HOME ON.
Return-to-home operation is started.

Query

Field name		Data	Description
Server address		01h	Server address1
Function code		06h	Writing to a holding register
Data	Register address (upper)	00h	Register address to which writing is executed = Driver input command (007Dh)
	Register address (lower)	7Dh	
	Value written (upper)	00h	
	Value written (lower)	10h	
Error check (lower)		18h	Calculation result of CRC-16
Error check (upper)		1Eh	

Response

Field name		Data	Description	
Server address		01h	Same as query	
Function code		06h		
Data	Register address (upper)	00h		
	Register address (lower)	7Dh		
	Value written (upper)	00h		
	Value written (lower)	10h		
Error check (lower)		18h		Calculation result of CRC-16
Error check (upper)		1Eh		

2. When Return-to-home operation is started, send the following query and turn HOME OFF again.

Query

Field name		Data	Description
Server address		01h	Server address1
Function code		06h	Writing to a holding register
Data	Register address (upper)	00h	Register address to which writing is executed = Driver input command (007Dh)
	Register address (lower)	7Dh	
	Value written (upper)	00h	
	Value written (lower)	00h	
Error check (lower)		19h	Calculation result of CRC-16
Error check (upper)		D2h	

Response

Field name		Data	Description
Server address		01h	Same as query
Function code		06h	
Data	Register address (upper)	00h	
	Register address (lower)	7Dh	
	Value written (upper)	00h	
	Value written (lower)	00h	
Error check (lower)		19h	Calculation result of CRC-16
Error check (upper)		D2h	

11 Detection of communication errors

This function detects abnormalities that may occur during RS-485 communication. The abnormalities that can be detected include communication errors, alarms and warnings.

11-1 Communication errors

A communication error record will be saved in the RAM. You can check the communication errors using the **MEXE02** or "Communication error record" command via RS-485 communication.

memo You can also clear the communication error records by turning off the driver power supply.

Type of communication error	Error code	Cause
RS-485 communication error	84h	A transmission error was detected. Refer to "No response" on p.220.
Command not yet defined	88h	An exception response (exception code 01h, 02h) was detected. Refer to p.221.
Execution disable due to user I/F communication in progress	89h	An exception response (exception code 04h) was detected. Refer to p.221.
Not possible to execute because of non-volatile memory processing	8Ah	
Outside setting range	8Ch	An exception response (exception code 03h, 04h) was detected. Refer to p.221.
Command execute disable	8Dh	An exception response (exception code 04h) was detected. Refer to p.221.

11-2 Alarms and warnings

When an alarm generates, the ALM output will turn OFF and the motor will stop. At the same time, the ALM LED (or ALARM LED) will start blinking.

When a warning generates, the WNG output will turn ON. The motor will continue to operate. Once the cause of the warning is removed, the WNG output will turn OFF automatically.

memo You can also clear the warning records by turning off the driver power supply.

■ Communication switch setting error

When setting the transmission rate setting switch (SW2) to positions 8 to F, the transmission rate setting switch error will occur.

■ RS-485 communication error (84h)

The table shows the relationship between alarms and warnings when an RS-485 communication error occurs.


Description of error	Description
Warning	A warning generates when one RS-485 communication error (84h) has been detected. If normal reception occurs while the warning is present, the warning will be reset automatically.
Alarm	An alarm generates when a RS-485 communication error (84h) has been detected consecutively by the number of times set in the "Communication error alarm" parameter.

■ RS-485 communication timeout (85h)

If communication is not established with the client after an elapse of the time set by the "Communication timeout" parameter, a RS-485 communication timeout alarm will generate.


12 Timing charts

■ Communication start



* C3.5 (silent interval) + Tb5 (query processing time (driver)) + Tb2 (transmission waiting time (driver side))

■ Operation start




*1 A message including a query to start operation via RS-485 communication.

*2 C3.5 (silent interval) + Tb5 (query processing time (driver)) + Tb2 (transmission waiting time (driver side))

*3 C3.5 (silent interval) + 4 ms or less

■ Operation stop, speed change




*1 A message including a query to stop operation and another to change the speed via RS-485 communication.

*2 C3.5 (silent interval) + Tb5 (query processing time (driver)) + Tb2 (transmission waiting time (driver side))

*3 The specific time varies depending on the command speed.

*4 The deceleration method to be applied at the time of stopping varies according to the "STOP input action" parameter.

■ General signals




*1 A message including a query for remote output via RS-485 communication.

*2 C3.5 (silent interval) + Tb5 (query processing time (driver)) + Tb2 (transmission waiting time (driver side))

*3 C3.5 (silent interval) + 4 ms or less

■ Configuration



*1 A message including a query for configuration via RS-485 communication.

*2 $C3.5$ (silent interval) + $Tb5$ (query processing time (driver)) + $Tb2$ (transmission waiting time (driver side))

*3 $C3.5$ (silent interval) + 4 ms or less

*4 Internal processing time + 1 s or less

*5 Execute a query after the driver internal processing is completed.

7 Method of control via industrial network

This part explains how to control via industrial network using our network converter.

◆Table of contents

1	Setting the switches.....	258	4	Method of control via MECHATROLINK communication	290	
	1-1	Setting the AC power input	258	4-1	Guidance.....	290
	1-2	Setting the DC power input.....	260	4-2	Basic operation procedure	295
2	Method of control via CC-Link communication.....	262	4-3	Field map of the NETC01-M2	298	
	2-1	Guidance.....	262	4-4	Field map of the NETC01-M3	299
	2-2	Operation example of command selection method.....	267	4-5	Communication formats.....	300
	2-3	Operation example of command fixation method.....	274	5	Details of remote I/O.....	302
3	Method of control via EtherCAT communication.....	281	5-1	Input signals to the driver	302	
	3-1	Guidance.....	281	5-2	Output signals from the driver	303
	3-2	Basic operating procedures	287	6	Command code list	305
			6-1	Group function	305	
			6-2	Maintenance command.....	306	
			6-3	Monitor command	307	
			6-4	Operation data	309	
			6-5	User parameters.....	310	



1 Setting the switches

Switches differ in the AC input driver and the DC input driver. Set properly.



1-1 Setting the AC power input

The figures show the status of factory setting.

● Driver front side



● Driver bottom side



Note When setting any switch, turn off the main power supply and the 24 VDC power supply of the driver and wait for the CHARGE LED to turn off before doing so. The residual voltage may cause electric shock.

memo The set switches are enabled after the 24 VDC power supply is turned on again.

■ Protocol

Using the SW4-No.2 of the function setting switch to OFF. The network converter is selected.

Factory setting OFF

SW4-No.2	Protocol
ON	Modbus RTU mode
OFF	Connecting with network converter

■ Address number (Device address)

Using the address number setting switch (ID) and SW4-No.1 of the function setting switch, set the address number (device address). Make sure each address number (device address) you set for each driver is unique. Up to 16 units can be connected.

Factory setting ID: 0, SW4-No.1: OFF (Device address 0)

Address number	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
ID	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
SW4-No.1	OFF															

■ Transmission rate

Using the transmission rate setting switch (SW2), set the transmission rate to 625,000 bps.

Factory setting 7 (625,000 bps)

■ Termination resistor

Use a termination resistor for the driver located farthest away (positioned at the end) from the network converter. Turn the termination resistor setting switch (TERM.-Nos.1 and 2) ON to set the termination resistor for RS-485 communication (120 Ω).


Factory setting Nos.1 and 2: Both OFF (termination resistor disabled)

TERM.-Nos.1 and 2	Termination resistor (120 Ω)
Both are OFF	Disabled
Both are ON	Enabled



If only one of No.1 or No.2 is turned ON, a communication error may occur.


For example, in the case of the following system, the termination resistor should be set to two drivers.




1-2 Setting the DC power input

The figures show the status of factory setting.

● Driver front side



● Driver top side



memo Be sure to turn off the driver power supply before setting the switches. If the switches are set while the power is still on, the new switch settings will not become effective until the driver power supply is cycled.

■ Protocol

Using the SW3-No.2 of the function setting switch to OFF. The network converter is selected.

Factory setting OFF

SW3-No.2	Protocol
ON	Modbus RTU mode
OFF	Connecting with network converter

■ Address number (Device address)

Using the address number setting switch (SW1) and SW3-No.1 of the function setting switch, set the address number (device address). Make sure each address number (device address) you set for each driver is unique. Up to 16 units can be connected.

Factory setting SW1: 0, SW3-No.1: OFF (Device address 0)

Device number	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
SW1	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
SW3-No.1	OFF															

■ Transmission rate

Using the transmission rate setting switch (SW2), set the transmission rate to 625,000 bps.

Factory setting 7 (625,000 bps)


■ Termination resistor

Use a termination resistor for the driver located farthest away (positioned at the end) from the network converter.
 Turn the termination resistor setting switches (SW3-No.4) ON to set the termination resistor for RS-485 communication (120 Ω).

Factory setting OFF (termination resistor disabled)

SW3-No.4	Termination resistor (120 Ω)
OFF	Disabled
ON	Enabled


For example, in the case of the following system, the termination resistor should be set to two drivers.



2 Method of control via CC-Link communication

2-1 Guidance

If you are new to the **AR** Series FLEX built-in controller type, read this section to understand the operating methods along with the operation flow.



■ Setting condition

● Setting of driver

Address number 0	AC power input
Address number 1	DC power input
Protocol	Network converter
RS-485 communication transmission rate	625,000 bps

● Setting of NETC02-CC

Number of connected driver	2 units
CC-Link baud rate	10 Mbps
STATION No.	No.1
Register arrangement mode	4 word arrangement

● Setting of master station

Setting of network parameter

Remote input (RX)	RX1000
Remote output (RY)	RY1000
Remote register (RW _r)	W0
Remote register (RW _w)	W100
Extended cyclic setting	×2
Remote device station	4 station occupied


Setting of CC-Link master station

CC-Link baud rate	10 Mbps
STATION No.	No.0

Note Before operating the motor, check the condition of the surrounding area to ensure safety.

memo The **NETC02-CC** incorporates a termination resistor for RS-485 communication. This product can be used without setting the termination resistor.

STEP 1 Check the installation and connection




- *1 These cables are provided as our products. Purchase them separately.
- *2 This cable is provided as our product. When the length of the motor cable is not enough, purchase it separately.
- *3 The termination resistor does not come with the product (110 Ω, 1/2 W).

STEP 2 Set the switches of the NETC02-CC

Set the switches provided on the upper side of the **NETC02-CC** as follows. The status becomes as shown in the following figures after setting.

Setting item	Switch	Factory setting
RS-485 communication connection unit: 2	Set N-AXIS to "2"	1
CC-Link baud rate: 10 Mbps	Set B-RATE to "4"	0
CC-Link station No.: 1	Set the ×1 to "1" and the ×10 to "0" of the STATION No.	1 (×1: 1, ×10: 0)
Operation mode: OFF	Set No.1 to No.4 to "OFF"	All OFF




STEP 3 Set the switches of the driver

Set the following with the switches of the driver. The status becomes as shown in the following figures after setting.


Setting item	AC power input	DC power input
Protocol: Network converter	Set No.2 of SW4 to "OFF"	Set No.2 of SW3 to "OFF"
Address number: AC power input driver is "0" DC power input driver is "1"	Set No.1 of SW4 to "OFF" Set ID to "0"	Set No.1 of SW3 to "OFF" Set SW1 to "1"
Termination resistor: AC power input driver is "OFF" DC power input driver is "ON"	Set No.1 and No.2 of TERM. to "OFF"	Set No.4 of SW3 to "ON"
Transmission rate: 625,000 bps	Set SW2 to "7"	Set SW2 to "7"

■ AC power input

● Driver front side




● Driver bottom side




■ DC power input

● Driver front side



● Driver top side




STEP 4 Turn on the power and check the LED

Check that the LED of the driver and network converter are as shown in the figure.

■ AC power input driver


■ DC power input driver

■ Network converter



2-2 Operation example of command selection method

This section explains how to perform the following operations using the command selection method.



■ How to use the request signal

In the operation example, the request signals are used quite differently based on the setting of remote register.

● Operation data, maintenance command

Request signal	Remote register	
	Write	Read
D-REQ0	RWw100	RWr0
	RWw101	RWr1
	RWw102	RWr2
	RWw103	RWr3
D-REQ1	RWw104	RWr4
	RWw105	RWr5
	RWw106	RWr6
	RWw107	RWr7

● Monitor command

Request signal	Remote register	
	Write	Read
D-REQ2	RWw108	RWr8
	RWw109	RWr9
	RWw10A	RWrA
	RWw10B	RWrB
D-REQ3	RWw10C	RWrC
	RWw10D	RWrD
	RWw10E	RWrE
	RWw10F	RWrF

STEP 1 Execute continuous operation in the reverse direction by remote I/O, and check if the operation is performed.

1. Start continuous operation in the reverse direction.
Turn the RVS ON.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	RVS	RY100F	1	Execution of continuous operation
1		RY101F	1	

2. Stop continuous operation.
Turn the RVS OFF.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	RVS	RY100F	0	Stop of continuous operation
1		RY101F	0	

memo If not operated, check the setting of the switches, and assignments of remote I/O and remote register.

STEP 2 Perform positioning operation

1. In order to make easier to check that the operation was properly performed when positioning operation was performed, set the position information to "0."
1) Set the maintenance command "P-PRESET execution (30C5h)" to remote register.

Master station to NETC02-CC

Address number	Address	Input value	Description
0	RWw100	30C5h	Command code (P-PRESET execution)
	RWw101	0h	Address number
	RWw102	1	Data (lower)
	RWw103	0	Data (upper)
1	RWw104	30C5h	Command code (P-PRESET execution)
	RWw105	1h	Address number
	RWw106	1	Data (lower)
	RWw107	0	Data (upper)

memo Unless "1" is set to the data area, the command is not executed.

- 2) Turn the D-REQ ON to write data to the driver.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ0	RY1080	1	Write execution
1	D-REQ1	RY1082	1	

- 3) The response of the D-END is automatically changed to "1" when it is properly processed.

NETC02-CC to master station

Address number	Remote I/O	Address	Response	Description
0	D-END0	RX1080	1	Write completed
1	D-END1	RX1082	1	

- 4) The value written to the driver is displayed when the response of the D-END is changed to "1."
Check the value is matched with the one having set in the above 1).

NETC02-CC to master station

Address number	Address	Response	Description
0	RWr0	30C5h	Command code response (P-PRESET execution)
	RWr1	0h	Address number response
	RWr2	1	Data (lower)
	RWr3	0	Data (upper)
1	RWr4	30C5h	Command code response (P-PRESET execution)
	RWr5	1h	Address number response
	RWr6	1	Data (lower)
	RWr7	0	Data (upper)

- 5) Check it has been written properly, and turn the D-REQ OFF.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ0	RY1080	0	Write execution
1	D-REQ1	RY1082	0	

2. Check the position information is changed to "0" by the "P-PRESET execution" of the maintenance command.
1) Set the "Actual position (2066h)" of the monitor command to remote register.

Master station to NETC02-CC

Address number	Address	Input value	Description
0	RWw108	2066h	Command code (actual position)
	RWw109	0h	Address number
	RWw10A	0	Data (lower)
	RWw10B	0	Data (upper)
1	RWw10C	2066h	Command code (actual position)
	RWw10D	1h	Address number
	RWw10E	0	Data (lower)
	RWw10F	0	Data (upper)

- 2) Turn the D-REQ ON to write data to the driver.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ2	RY1084	1	Start of monitor
1	D-REQ3	RY1086	1	

- 3) The response of the D-END is automatically changed to "1" when it is properly processed.

NETC02-CC to master station

Address number	Remote I/O	Address	Response	Description
0	D-END2	RX1084	1	During monitor
1	D-END3	RX1086	1	

- 4) The value written to the driver is displayed when the response of the D-END is changed to "1." Check the data area is changed to "0."

NETC02-CC to master station

Address number	Address	Response	Description
0	RWr8	2066h	Command code response (actual position)
	RWr9	0h	Address number response
	RWrA	0	Data (lower)
	RWrB	0	Data (upper)
1	RWrC	2066h	Command code response (actual position)
	RWrD	1h	Address number response
	RWrE	0	Data (lower)
	RWrF	0	Data (upper)

- 5) Check it has been written properly, and turn the D-REQ OFF.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ2	RY1084	0	End of monitor
1	D-REQ3	RY1086	0	

3. Set the operation data of positioning operation.
Set the position No.0 and position data "5,000 (1388h)" to remote register.

Master station to NETC02-CC

Address number	Address	Input value	Description
0	RWw100	1200h	Command code (position No.0)
	RWw101	0h	Address number
	RWw102	5,000 (1388h)	Data (lower)
	RWw103		Data (upper)
1	RWw104	1200h	Command code (position No.0)
	RWw105	1h	Address number
	RWw106	5,000 (1388h)	Data (lower)
	RWw107		Data (upper)

4. Write the set data in the above 3 to the driver to check the response.

- 1) Turn the D-REQ ON.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ0	RY1080	1	Write execution
1	D-REQ1	RY1082	1	

- 2) The response of the D-END is automatically changed to "1" when it is properly processed.

NETC02-CC to master station

Address number	Remote I/O	Address	Response	Description
0	D-END0	RX1080	1	Write completed
1	D-END1	RX1082	1	

- 3) The value written to the driver is displayed when the response of the D-END is changed to "1."
Check the value is matched with the one having set in the above 3.

NETC02-CC to master station

Address number	Address	Response	Description
0	RWr0	1200h	Command code response (position No.0)
	RWr1	0h	Address number response
	RWr2	5,000	Data (lower)
	RWr3	(1388h)	Data (upper)
1	RWr4	1200h	Command code response (position No.0)
	RWr5	1h	Address number response
	RWr6	5,000	Data (lower)
	RWr7	(1388h)	Data (upper)

5. Check it has been written properly, and turn the D-REQ OFF.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ0	RY1080	0	Write completed
1	D-REQ1	RY1082	0	

6. Start positioning operation.
Turn the START ON.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	START	RY1003	1	Start of positioning operation
1		RY1013	1	

7. When positioning operation is started, turn the START OFF.
Even if the START is turned OFF, the operation continues until the command position.

NETC02-CC to master station

Address number	Remote I/O	Address	Input value	Description
0	START	RY1003	0	Turn the START OFF
1		RY1013	0	

STEP 3 Monitor the actual position

1. Set the "Actual position (2066h)" of the monitor command to remote register.

Master station to NETC02-CC

Address number	Address	Input value	Description
0	RWw108	2066h	Command code (actual position)
	RWw109	0h	Address number
	RWw10A	0	Data (lower)
	RWw10B	0	Data (upper)
1	RWw10C	2066h	Command code (actual position)
	RWw10D	1h	Address number
	RWw10E	0	Data (lower)
	RWw10F	0	Data (upper)

2. Write the set data in the above 1 to the driver to check the response.
 - 1) Turn the D-REQ ON.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ2	RY1084	1	Start of monitor
1	D-REQ3	RY1086	1	

- 2) The response of the D-END is automatically changed to "1" when it is properly processed.

NETC02-CC to master station

Address number	Remote I/O	Address	Response	Description
0	D-END2	RX1084	1	During monitor
1	D-END3	RX1086	1	

- 3) The response of the D-END is changed to "1," the monitor of the actual position is started. The monitor is continued while the D-REQ is ON.

NETC02-CC to master station

Address number	Address	Response	Description
0	RWr8	2066h	Command code response (actual position)
	RWr9	0h	Address number response
	RWrA	5,000 (1388h)	Data (lower)
	RWrB	(1388h)	Data (upper)
1	RWrC	2066h	Command code response (actual position)
	RWrD	1h	Address number response
	RWrE	5,000 (1388h)	Data (lower)
	RWrF	(1388h)	Data (upper)

3. End the monitor. Turn the D-REQ OFF.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ2	RY1084	0	End of monitor
1	D-REQ3	RY1086	0	

STEP 4 Write the position information to the non-volatile memory.



The non-volatile memory can be rewritten approximately 100,000 times.

1. Set the maintenance command "Batch non-volatile memory write (30C9h)" to remote register.

Master station to NETC02-CC

Address number	Address	Input value	Description
0	RWw100	30C9h	Command code (batch non-volatile memory write)
	RWw101	0h	Address number
	RWw102	1	Data (lower)
	RWw103	0	Data (upper)
1	RWw104	30C9h	Command code (batch non-volatile memory write)
	RWw105	1h	Address number
	RWw106	1	Data (lower)
	RWw107	0	Data (upper)

2. Write the set data in the above 1 to the driver to check the response.

- 1) Turn the D-REQ ON.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ0	RY1080	1	Write execution
1	D-REQ1	RY1082	1	

- 2) The response of the D-END is automatically changed to "1" when it is properly processed.

NETC02-CC to master station

Address number	Remote I/O	Address	Response	Description
0	D-END0	RX1080	1	Write completed
1	D-END1	RX1082	1	

- 3) The value written to the driver is displayed when the response of the D-END is changed to "1". Check the value is matched with the one having set in the above 1).

NETC02-CC to master station

Address number	Address	Response	Description
0	RWr0	30C9h	Command code response (batch non-volatile memory write)
	RWr1	0h	Address number response
	RWr2	1	Data (lower)
	RWr3	0	Data (upper)
1	RWr4	30C9h	Command code response (batch non-volatile memory write)
	RWr5	1h	Address number response
	RWr6	1	Data (lower)
	RWr7	0	Data (upper)

3. Check it has been written properly, and turn the D-REQ OFF.

Master station to NETC02-CC


Address number	Remote I/O	Address	Input value	Description
0	D-REQ0	RY1080	0	Write completed
1	D-REQ1	RY1082	0	



Since the data set via CC-Link communication is saved in the RAM, it is erased when the power is turned off. If the "batch non-volatile memory write" is performed, since the data is saved in the non-volatile memory, it is stored even when the power is turned off.

2-3 Operation example of command fixation method

This section explains how to perform the following operations using the command fixation method.



■ Items of register arrangement (four words arrangement)

● Arrangement of write

Address number	Remote register	Description	Request signal
0	RWw100	Not used	WR-REQ0
	RWw101	Not used	
	RWw102	Position No.0 (lower)	
	RWw103	Position No.0 (upper)	
1	RWw104	Not used	
	RWw105	Not used	
	RWw106	Position No.0 (lower)	
	RWw107	Position No.0 (upper)	

● Arrangement of read and monitor

Address number	Remote register	Description	Request signal
0	RWr0	Actual position (lower)	RD-REQ0
	RWr1	Actual position (upper)	
	RWr2	Position No.0 (lower)	
	RWr3	Position No.0 (upper)	
1	RWr4	Actual position (lower)	
	RWr5	Actual position (upper)	
	RWr6	Position No.0 (lower)	
	RWr7	Position No.0 (upper)	

STEP 1 Execute continuous operation in the reverse direction by remote I/O, and check if the operation is performed

1. Start continuous operation in the reverse direction.
Turn the RVS ON .


Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	RVS	RY100F	1	Execution of continuous operation
1		RY101F	1	

2. Stop continuous operation.
Turn the RVS OFF.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	RVS	RY100F	0	Stop of continuous operation
1		RY101F	0	

 If not operated, check the setting of the switches, and assignments of remote I/O and remote register.

STEP 2 Execute the P-PRESET (maintenance command)

1. Set the present position to "0" using the maintenance command "P-PRESET execution."

Note The maintenance command is performed with the command selection method.

- 1) Set the maintenance command "P-PRESET execution (30C5h)" to remote register.

Master station to NETC02-CC

Address number	Address	Input value	Description
0	RWw100	30C5h	Command code (P-PRESET execution)
	RWw101	0h	Address number
	RWw102	1	Data (lower)
	RWw103	0	Data (upper)
1	RWw104	30C5h	Command code (P-PRESET execution)
	RWw105	1h	Address number
	RWw106	1	Data (lower)
	RWw107	0	Data (upper)

memo Unless "1" is set to the data area, the command is not executed.

- 2) Turn the D-REQ ON to write data to the driver.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ0	RY1080	1	Write execution
1	D-REQ1	RY1082	1	

- 3) The response of the D-END is automatically changed to "1" when it is properly processed.

NETC02-CC to master station

Address number	Remote I/O	Address	Response	Description
0	D-END0	RX1080	1	Write completed
1	D-END1	RX1082	1	

- 4) The value written to the driver is displayed when the response of the D-END is changed to "1." Check the value is matched with the one having set in the above 1).

NETC02-CC to master station

Address number	Address	Response	Description
0	RWr0	30C5h	Command code response (P-PRESET execution)
	RWr1	0h	Address number response
	RWr2	1	Data (lower)
	RWr3	0	Data (upper)
1	RWr4	30C5h	Command code response (P-PRESET execution)
	RWr5	1h	Address number response
	RWr6	1	Data (lower)
	RWr7	0	Data (upper)

- 5) Check it has been written properly, and turn the D-REQ OFF.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	D-REQ0	RY1080	0	Write completed
1	D-REQ1	RY1082	0	

STEP 3 Monitor the value of the driver

Since the register arrangement mode is the four words arrangement, monitor the actual position and read the value of the position No.0.

1. Turn the RD-REQ ON.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	RD-REQ0	RY1092	1	Start of read and monitor
1				

2. When monitor is started, the response of the RD-DAT is automatically changed to "1."

NETC02-CC to master station

Address number	Remote I/O	Address	Response	Description
0	RD-DAT0	RX1092	1	During read and monitor
1				

3. When the response of the RD-DAT is changed to "1," the monitor of the actual position and read of the position No.0 are started.
The monitor is continued while the RD-REQ is ON.

NETC02-CC to master station

Address number	Address	Response	Description
0	RWr0	0	Actual position (lower)
	RWr1	0	Actual position (upper)
	RWr2	0 *	Position No.0 (lower)
	RWr3	0 *	Position No.0 (upper)
1	RWr4	0	Actual position (lower)
	RWr5	0	Actual position (upper)
	RWr6	0 *	Position No.0 (lower)
	RWr7	0 *	Position No.0 (upper)

* The initial values is "0."

Since the monitor of the actual position and read of the position No.0 are continuously performed, keep the RD-REQ to the ON-state.

STEP 4 Perform positioning operation

1. Set the operation data of positioning operation.
Set the position data "5,000 (1388h)" of the position No.0 to remote register.

Master station to NETC02-CC

Address number	Address	Input value	Description
0	RWw100	0	Not used
	RWw101	0	Not used
	RWw102	5,000	Position No.0 (lower)
	RWw103	(1388h)	Position No.0 (upper)
1	RWw104	0	Not used
	RWw105	0	Not used
	RWw106	5,000	Position No.0 (lower)
	RWw107	(1388h)	Position No.0 (upper)

2. Write the set data in the above 1 to the driver to check the response.
 - 1) Turn the WR-REQ ON.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	WR-REQ0	RY1090	1	Start of write
1				

- 2) The response of the WR-DAT is automatically changed to "1" when it is properly processed.

NETC02-CC to master station

Address number	Remote I/O	Address	Response	Description
0	WR-DAT0	RX1090	1	During write
1				

- 3) Since the RD-REQ is kept to the ON-state in the STEP 3, the write value is displayed at the same time the data of the position No.0 is set.
Check the data of the position No.0 is matched with the set value.

NETC02-CC to master station

Address number	Address	Response	Description
0	RWr0	0	Actual position (lower)
	RWr1	0	Actual position (upper)
	RWr2	5,000	Position No.0 (lower)
	RWr3	(1388h)	Position No.0 (upper)
1	RWr4	0	Actual position (lower)
	RWr5	0	Actual position (upper)
	RWr6	5,000	Position No.0 (lower)
	RWr7	(1388h)	Position No.0 (upper)

3. Start positioning operation.
Turn the START ON.

Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	START	RY1003	1	Start of positioning operation
1		RY1013	1	



Since the RD-REQ is kept to the ON-state in the STEP 3, the monitor of the actual position is started at the same time that positioning operation is started.

4. When positioning operation is started, turn the START OFF.
Even if the START is turned OFF, the operation continues until the command position.

NETC02-CC to master station

Address number	Remote I/O	Address	Input value	Description
0	START	RY1003	0	Turn the START OFF
1		RY1013	0	

5. When positioning operation was completed, check the actual position changes to "5,000 (1388h)."

NETC02-CC to master station

Address number	Address	Response	Description
0	RWr0	5,000 (1388h)	Actual position (lower)
	RWr1		Actual position (upper)
	RWr2	5,000 (1388h)	Position No.0 (lower)
	RWr3		Position No.0 (upper)
1	RWr4	5,000 (1388h)	Actual position (lower)
	RWr5		Actual position (upper)
	RWr6	5,000 (1388h)	Position No.0 (lower)
	RWr7		Position No.0 (upper)

Since the data of the position No.0 is continuously written, keep the WR-REQ to the ON-state.

STEP 5 Change the position data of the operation data No.0

1. Set the position data "3,000 (BB8h)" of the position No.0 to remote register.
 Since the WR-REQ is kept to the ON-state in the STEP 4, the write value is displayed at the same time the data of the position No.0 is set.

Master station to NETC02-CC

Address number	Address	Input value	Description
0	RWw100	0	Not used
	RWw101	0	Not used
	RWw102	3,000	Position No.0 (lower)
	RWw103	(BB8h)	Position No.0 (upper)
1	RWw104	0	Not used
	RWw105	0	Not used
	RWw106	3,000	Position No.0 (lower)
	RWw107	(BB8h)	Position No.0 (upper)

Also, since the RD-REQ is kept to the ON-state in the STEP 3, the write value is read at the same time the data of the position No.0 is set.

Check the value is matched with the one having set in the above 1.

NETC02-CC to master station

Address number	Address	Response	Description
0	RWr0	5,000	Actual position (lower)
	RWr1	(1388h)	Actual position (upper)
	RWr2	3,000	Position No.0 (lower)
	RWr3	(BB8h)	Position No.0 (upper)
1	RWr4	5,000	Actual position (lower)
	RWr5	(1388h)	Actual position (upper)
	RWr6	3,000	Position No.0 (lower)
	RWr7	(BB8h)	Position No.0 (upper)

2. Turn the WR-REQ and RD-REQ OFF.


Master station to NETC02-CC

Address number	Remote I/O	Address	Input value	Description
0	WR-REQ0	RY1090	0	Write completed
1				
0	RD-REQ0	RY1092	0	Read and monitor completed
1				

3 Method of control via EtherCAT communication

3-1 Guidance

If you are new to the **AR** Series FLEX built-in controller type, read this section to understand the operating methods along with the operation flow.



● **Operation condition**

Here, the motor is supposed to be operated under the following conditions.

- **NETC01-ECT** node address: 1
- Number of divers connected: 1
- Driver address number: 0
- Driver termination resistor: Enabled


Note

- Before operating the motor, check the condition of the surrounding area to ensure safety.
- Before starting guidance, import the ESI file to the EtherCAT Configuration Tool of the PLC and register the PLC configuration in advance. For details about ESI file, contact your nearest Oriental Motor sales office.

memo The termination resistor for the **NETC01-ECT** is built into the product. This product can be used without setting the termination resistor.


STEP 1 Check the installation and connection

■ AC power input driver



* These cables are provided as our products. Purchase them separately.

■ DC power input driver




*1 This cable is provided as our product. When the length of the motor cable is not enough, purchase it separately.

*2 These cables are provided as our products. Purchase them separately.


STEP 2 Set the parameters and switches of the NETC01-ECT

Set the parameters and switches of the **NETC01-ECT**.

1. Turn on the power to the **NETC01-ECT**.
At this time, since parameters and switches are not set, the ALARM LED will be lit.
Move on the next procedure, and set parameters and switches.
2. Start the **MEXE02** and set the parameters.
Select the NETC EtherCAT compatible.




3. Set the "Connection (axis #)" parameter of the driver connected to the **NETC01-ECT** to "Enable" using the **MEXE02**.
The initial value in the "Connection (axis #0)" parameter is set to "Enable." When the connected driver is one unit and the address number of the driver is "0," it is not required to set the "Connection (axis #)" parameter.



MEXE02 tree view	Parameter name	Description	Initial value
System	Connection (axis #0)	Enables the address number of the driver connected to the NETC01-ECT . [Setting range] Disable Enable	Enable
	Connection (axis #1) to Connection (axis #15)		Disable

4. Set the switches of the **NETC01-ECT**.
Set as the illustration below.

Setting contents	Switch	Factory setting
RS-485 communication transmission rate: 625 kbps	Set SW1 to 7	7
EtherCAT node address: 1	Set ×10 of ECAT ID to 0, ×1 to 1	1 (×10: 0, ×1: 1)



5. Turn off the **NETC01-ECT** power.



- When multiple drivers are connected, set the "Connection (axis #)" parameters as many as the drivers.
- To update the changed "Connection (axis #)" parameter, cycling the power supply is required.
- For the SW1, always set to "7." If the switch is set to the dial of "8" or higher, the communication switch setting error alarm will be generated when turning on the power. And do not set the switch to the dial of "0" to "6" because they cannot be used. (An alarm will not be generated.)

STEP 3 Set the switches of the driver


Set the following with the switches of the driver. For the protocol, select "OFF" (network converter). The status becomes as shown in the following figures after setting.

Setting contents	AC power input	DC power input
Protocol: Network converter	Set No.2 of SW4 OFF	Set No.2 of SW3 OFF
Address number: 0	Set No.1 of SW4 to OFF, set ID to 0	Set No.1 of SW3 to OFF, set SW1 to 0
Termination resistor: ON	Set No.1 and No.2 of TERM. ON	Set No.4 of SW3 ON
Transmission rate: 625,000 bps	Set SW2 to 7	Set SW2 to 7


memo For the address number, set the one with the "Connection (axis #)" parameter of the **NETC01-ECT** set to "Enable."

■ AC power input

● Driver front side




● Driver bottom side




■ DC power input

● Driver front side



● Driver top side




STEP 4 Turn on the power and check the LED

Check that the LED of the driver and **NETC01-ECT** are as shown in the figure.

■ AC power input driver

■ DC power input driver

■ Network converter



- When the C-DAT/C-ERR LED (red) of the driver or the C-ERR LED (red) of the **NETC01-ECT** is lit: Check the transmission rate of RS-485 communication or the address number.
- When the ERR LED (red) of the **NETC01-ECT** is blink: An EtherCAT communication error has been occurred. Check the error content.

STEP 5 Perform continuous operation via remote I/O of EtherCAT communication

Turn FWD of the address number 0 ON with the remote I/O of EtherCAT communication. Continuous operation for the operation data No.0 is started at the 1,000 Hz of starting speed. Initial values of the remote I/O are as follows.

● MainDevice to **NETC01-ECT**

CoE Index	Sub-index	Name	Type	Access	Description							
2600h	0	-	U8	R	Number of Sub-index: 2							
	1	I/O command (lower)	U8	RW	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
					NET-IN7	NET-IN6	NET-IN5	NET-IN4	NET-IN3	NET-IN2	NET-IN1	NET-IN0
	2	I/O command (upper)	U8	RW	No function	FREE	STOP	HOME	START	M2	M1	M0
					Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
					NET-IN15	NET-IN14	NET-IN13	NET-IN12	NET-IN11	NET-IN10	NET-IN9	NET-IN8
				RVS	FWD	-JOG	+JOG	SSTART	MS2	MS1	MS0	

STEP 6 Were you able to operate the motor properly?

How did it go? Were you able to operate the motor properly? If the motor does not function, check the following points:

- Is an alarm generated in the driver or **NETC01-ECT**?
- Are the power supply, the motor, and the RS-485 cable connected securely?
- Are the protocol, address number, transmission rate and termination resistor set correctly?
- Is the "Connection (axis #)" parameter of the **NETC01-ECT** set correctly?
- Is the C-DAT LED of **NETC01-ECT** turned off? Or is the C-ERR LED lit in red? (A RS-485 communication error has been occurred.)
- Is the ERR LED of **NETC01-ECT** blinks in red? (An EtherCAT communication error has been occurred.)
- Is the L/A LED of **NETC01-ECT** turned off? Or is it blinks in green? (An EtherCAT communication error has been occurred.)
- Is the motor excited, or is the setting of the excitation method correct?
- Are the parameters of the driver set correctly?
- Is the operation stop signal input to the driver?

3-2 Basic operating procedures

This section explains how to perform positioning operation and monitor function as basic operating procedures. This is an example of the operating procedure for controlling via EtherCAT communication using the **NETC01-ECT**.

■ Positioning operation

● Setting example

- Driver address number (Device address): 0
- Operation data No.1
- Position (travel amount): 5,000 steps

● Operating procedure

1. Send the following remote register to set the position (travel amount) of the operation data No.1 to 5,000 steps. When the TRIG is turned ON, the data set in the remote register is written.

[Remote register command of **NETC01-ECT**]

CoE Index	Sub-Index	Item	Type	Access	Description							
2800h (address number 0)	0	–	U8	R	Sub-index number: 4							
	1	Axis	U8	RW	Reserved (not used)							
	2	Command	U16	RW	Command code: 1201h (position of operation data No.1)							
	3	Data	INT32	RW	Data: 5,000 (travel amount: 5,000 steps)							
	4	TRIG	U8	RW	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
					–	–	–	–	–	–	–	TRIG

2. When the data writing is completed properly, the TRIG_R is turned ON. At this time, the STATUS remains OFF. Turn the TRIG OFF again after writing.

[Remote register response of **NETC01-ECT**]

CoE Index	Sub-index	Item	Type	Access	Description							
2900h (address number 0)	0	–	U8	R	Sub-index number: 4							
	1	Axis	U8	R	Reserved (not used)							
	2	Command	U16	R	Command code response: 1201h							
	3	Data	INT32	R	Data response: 5,000							
	4	Status	U8	R	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
					–	–	–	–	Command Error	Axis Error	STATUS	TRIG_R



- If the TRIG was turned ON, be sure to turn it OFF again.
- When the data is written with the TRIG, the data is saved in the RAM. If the data is saved in the non-volatile memory, execute the "Batch non-volatile memory (3E85h)" of the maintenance command.

- Send the following remote I/O to turn the M0 and START ON (9h).
Positioning operation is started. If the motor rotates for 5,000 steps, the positioning operation was successful.

[Remote I/O of **NETC01-ECT**]

CoE Index	Sub-Index	Item	Type	Access	Description							
2600h (address number 0)	0	–	U8	R	Sub-index number: 2							
	1	I/O command (lower)	U8	RW	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
					NET-IN7	NET-IN6	NET-IN5	NET-IN4	NET-IN3	NET-IN2	NET-IN1	NET-IN0
2	I/O command (upper)	U8	RW	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
				NET-IN15	NET-IN14	NET-IN13	NET-IN12	NET-IN11	NET-IN10	NET-IN9	NET-IN8	

[NET-IN of **AR Series** (initial value)]

CoE Index	Sub-Index	Item	Type	Access	Description							
2600h (address number 0)	0	–	U8	R	Sub-index number: 2							
	1	I/O command (lower)	U8	RW	NET-IN7	NET-IN6	NET-IN5	NET-IN4	NET-IN3	NET-IN2	NET-IN1	NET-IN0
					No function	FREE	STOP	HOME	START	M2	M1	M0
2	I/O command (upper)	U8	RW	NET-IN15	NET-IN14	NET-IN13	NET-IN12	NET-IN11	NET-IN10	NET-IN9	NET-IN8	
				RVS	FWD	–JOG	+JOG	SSTART	MS2	MS1	MS0	

■ Monitor function

● Setting example

- Driver address number (Device address): 0
- Operation data No.0 (the speed was set to 1,000 [Hz])
- Monitor item: Actual speed [r/min]
- Connected driver: **AR Series**

● Operating procedure

- Send the following remote monitor command to turn the TRIG ON.
The monitor of the actual speed [r/min] of the address number 0 is started.

[Remote monitor command of **NETC01-ECT**]

CoE Index	Sub-Index	Item	Type	Access	Description							
2A00h (address number 0)	0	–	U8	R	Sub-index number: 4							
	1	Axis	U8	RW	Address number: 0							
	2	Command	U16	RW	Command code: 2067h (monitor of actual speed [r/min])							
	3	Data	INT32	RW	Reserved (not used)							
	4	TRIG	U8	RW	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
–					–	–	–	–	–	–	TRIG	

- Send the following remote I/O to turn the FWD (40h) of the address number 0 ON.
Continuous operation in the forward direction is started.

[Remote I/O of **NETC01-ECT**]

CoE Index	Sub-Index	Item	Type	Access	Description							
2600h (address number 0)	0	–	U8	R	Sub-index number: 2							
	1	I/O command (lower)	U8	RW	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
					NET-IN7	NET-IN6	NET-IN5	NET-IN4	NET-IN3	NET-IN2	NET-IN1	NET-IN0
	2	I/O command (upper)	U8	RW	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NET-IN15					NET-IN14	NET-IN13	NET-IN12	NET-IN11	NET-IN10	NET-IN9	NET-IN8	

[NET-IN of **AR Series** (initial value)]

CoE Index	Sub-Index	Item	Type	Access	Description							
2600h (address number 0)	0	–	U8	R	Sub-index number: 2							
	1	I/O command (lower)	U8	RW	NET-IN7	NET-IN6	NET-IN5	NET-IN4	NET-IN3	NET-IN2	NET-IN1	NET-IN0
					No function	FREE	STOP	HOME	START	M2	M1	M0
	2	I/O command (upper)	U8	RW	NET-IN15	NET-IN14	NET-IN13	NET-IN12	NET-IN11	NET-IN10	NET-IN9	NET-IN8
RVS					FWD	–JOG	+JOG	SSTART	MS2	MS1	MS0	

- If the data of the address number 0 is monitored by the remote monitor response, the communication was successful.
The TRIG_R is turned ON while the monitor is performed properly. At this time, the STATUS remains OFF.



The monitor is continued to update while the TRIG of the remote monitor command is being ON.

[Remote monitor response of **NETC01-ECT**]


CoE Index	Sub-Index	Item	Type	Access	Description							
2B00h (address number 0)	0	–	U8	R	Sub-index number: 4							
	1	Axis	U8	R	Address number response: 0							
	2	Command	U16	R	Command code response: 2067h							
	3	Data	INT32	R	Monitor data: 1,000							
	4	Status	U8	R	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
					–	–	–	–	Command Error	Axis Error	STATUS	TRIG_R

- Turn the TRIG OFF again to finish the monitor.

4 Method of control via MECHATROLINK communication

4-1 Guidance

If you are new to this type, read this section to understand the operating methods along with the operation flow. This section explains how to control via MECHATROLINK-II communication in combination with the network converter **NETC01-M2**.



● **Operation condition**

Here, the motor is supposed to be operated under the following conditions.


- Number of drivers connected: 1
- Address number: 0
- Termination resistor: Enabled



Before operating the motor, check the condition of the surrounding area to ensure safety.


STEP 1 Check the installation and connection

■ AC power input driver



* These products are provided as our products. Purchase them separately.

■ DC power input driver




*1 These products are provided as our products. Purchase them separately.

*2 This cable is provided as our product. When the length of the motor cable is not enough, purchase it separately.


STEP 2 Set the parameters and switches of the NETC01-M2

Set the parameters and switches of the **NETC01-M2**.

1. Turn on the power supply to the **NETC01-M2**.
2. Start the **MEXE02** and set the parameters.
Select the "NETC MECHATROLINK-II compatible."



3. Set the "Communication (address number)" parameter of the driver connected to the **NETC01-M2** to "Effective" using the **MEXE02**.



MEXE02 tree view	Parameter name	Description	Initial value
System	Communication (address number 0) to Communication (address number 15)	Enables the address number of the driver connected to the NETC01-M2 . [Setting range] Disable Effective	Disable

- memo**
- Since parameters of the network converter cannot be set via MECHATROLINK communication, set them by using the **MEXE02**.
 - When multiple drivers are connected, set the "Communication (address number)" parameters as many as the drivers.
 - The "Communication (address number)" parameter is enabled after the power is cycled.

4. Set the switches of the **NETC01-M2**.
Refer to the **NETC01-M2 USER MANUAL** for the setting method.
 - MECHATROLINK-II station address
 - RS-485 transmission rate
 - Remote I/O occupancy size
 - Number of transmission bytes
5. Turn off the power supply to the **NETC01-M2**.

STEP 3 Set the switches of the driver


Set the following with the switches of the driver. For the protocol, select "OFF" (network converter). The status becomes as shown in the following figures after setting.

Setting contents	AC power input driver	DC power input driver
Protocol: Network converter	Set No.2 of SW4 to OFF	Set No.2 of SW3 to OFF
Address number: 0	Set No.1 of SW4 to OFF, ID to 0	Set SW1 to 0, No.1 of SW3 to OFF
Termination resistor: ON	Set No.1 and No.2 of TERM to ON	Set No.4 of SW3 to ON
Transmission rate: 625,000 bps	Set SW2 to 7	Set SW2 to 7


memo For the address number, select the one with the "Communication (address number)" parameter of the **NETC01-M2** set to "Effective."

■ AC power input driver

● Driver front side




● Driver bottom side




■ DC power input driver

● Driver front side




● Driver top side



STEP 4 Turn on the power and check the LED

Check that the LED of the driver and **NETC01-M2** are as shown in the figure.

- AC power input driver
- DC power input driver
- Network converter



- When the C-DAT/C-ERR LED (red) of the driver or the C-ERR (red) of the **NETC01-M2** is lit: Check the transmission rate of RS-485 communication or the address number.
- When the ERR (red) of the **NETC01-M2** is lit: An MECHATROLINK communication error has occurred. Check the error content.

STEP 5 Perform continuous operation via remote I/O of MECHATROLINK communication

Turn FWD of the address number 0 ON with the I/O command of MECHATROLINK communication. Continuous operation is started. Initial values of the I/O commands are as follows.

Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
NET-IN15 [RVS]	NET-IN14 [FWD]	NET-IN13 [-JOG]	NET-IN12 [+JOG]	NET-IN11 [SSTART]	NET-IN10 [MS2]	NET-IN9 [MS1]	NET-IN8 [MS0]
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NET-IN7 [Not used]	NET-IN6 [FREE]	NET-IN5 [STOP]	NET-IN4 [HOME]	NET-IN3 [START]	NET-IN2 [M2]	NET-IN1 [M1]	NET-IN0 [M0]

STEP 6 Were you able to operate the motor properly?

How did it go? Were you able to operate the motor properly? If the motor does not function, check the following points:

- Is an alarm generated in the driver or **NETC01-M2**?
- Are the power supply, the motor, and the RS-485 cable connected securely?
- Are the protocol, address number, transmission rate and termination resistor set correctly?
- Is the "Communication (address number)" parameter of the **NETC01-M2** set correctly?
- Is the C-DAT/C-ERR LED turned off of the **NETC01-M2**? Or is it lit in red? (An communication error has been occurred.)
- Is the operation data set correctly?
- Is the motor excited, or is the setting of the excitation method correct?
- Are the parameters of the driver set correctly?
- Is the operation stop signal input to the driver?

4-2 Basic operation procedure

This section explains the execution methods of positioning operation and monitor function as a basic operation procedure.
 As an example, here is an introduction of a procedure to control via MECHATROLINK-II communication using the **NETC01-M2**.

■ Positioning operation

As an example, here is a description how to execute the following positioning operation.

● Setting example

- Address number (Device address): 0
- Operation data No.1
- Position (travel amount): 5,000 steps

● Operation procedure

1. Send the following remote register and set the position (travel amount) of the operation data No.1 to 5,000 steps. The data set to the remote register is written. When writing is complete, TRIG_R is turned ON.

Remote register of the NETC01-M2

Byte	Part	Type	Command	Input example	Description
23	Data field	Remote register	Register address number	0	Address number 0
24				1201h + 4000h = 5201h *	Value to be written to the position of operation data No.1 + TRIG
25			Command code + TRIG		
26					
27			DATA		
28					
29					
30				1388h	Position (travel amount) 5,000 steps

* From the list of "6-4 Operation data" on p.309, we can see that the command code (WRITE) of "Position No.1" is 1201h. Since the command code and the command execute request (TRIG) are written with the same command in MECHATROLINK communication, write "5201h" with the code (4000h) of TRIG added.

2. Check that TRIG_R is turned ON, then send the following remote register and turn TRIG OFF again.

Remote register of the NETC01-M2

Byte	Part	Type	Command	Input example	Description
25	Data field	Remote register	Command code + TRIG	0	Turn TRIG OFF
26					

- memo**
- Be sure to turn TRIG OFF again after turning it ON.
 - Data is stored in RAM when written in command execute request TRIG. When saving the data to the non-volatile memory, execute the "Batch NV memory write" of the maintenance command.

- Send the following remote I/O and turn M0 of the address number 0 and START ON.
Positioning operation is started. When the motor has rotated for 5,000 steps, communication has succeeded.

Remote I/O of the NETC01-M2

Byte	Part	Type	Command	Input example	Description
7	Data field	Remote I/O	Address number "0" remote I/O input	9h	Turn M0 and START ON
8					

Communication format (initial value) of remote I/O input

Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
NET-IN15 [RVS]	NET-IN14 [FWD]	NET-IN13 [-JOG]	NET-IN12 [+JOG]	NET-IN11 [SSTART]	NET-IN10 [MS2]	NET-IN9 [MS1]	NET-IN8 [MS0]
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NET-IN7 [Not used]	NET-IN6 [FREE]	NET-IN5 [STOP]	NET-IN4 [HOME]	NET-IN3 [START]	NET-IN2 [M2]	NET-IN1 [M1]	NET-IN0 [M0]

■ **Monitor function**

● **Setting example**

- Address number (Device address): 0
- Monitor item: Feedback speed [r/min]

● **Operation procedure**

- Send the following remote register and monitor the feedback speed of the address number 0.
Monitoring of the feedback speed of the address number 0 is started.

Remote register of the NETC01-M2

Byte	Part	Type	Command	Input example	Description
23	Data field	Remote register	Register address number	0	Address number 0
24					
25			Command code + TRIG	2067h + 4000h = 6067h *	Monitoring of the feedback speed + TRIG
26					
27			DATA		
28					
29					
30					

* From the list of "6-3 Monitor command" on p.307, we can see that the command code (WRITE) of "Feedback speed monitor" is 2067h. Since the command code and the command execute request (TRIG) are written with the same command in MECHATROLINK communication, write "6067h" with the code (4000h) of TRIG added.

- Send the following remote I/O and turn FWD of the address number 0 ON.
Continuous operation in the forward direction is started.

Remote I/O of the NETC01-M2

Byte	Part	Type	Command	Input example	Description
7	Data field	Remote I/O	Address number "0" remote I/O input	4000h	Turn FWD ON
8					

Communication format (initial value) of remote I/O input

Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
NET-IN15 [RVS]	NET-IN14 [FWD]	NET-IN13 [-JOG]	NET-IN12 [+JOG]	NET-IN11 [SSTART]	NET-IN10 [MS2]	NET-IN9 [MS1]	NET-IN8 [MS0]
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NET-IN7 [Not used]	NET-IN6 [FREE]	NET-IN5 [STOP]	NET-IN4 [HOME]	NET-IN3 [START]	NET-IN2 [M2]	NET-IN1 [M1]	NET-IN0 [M0]

Monitoring of the feedback speed is continued while TRIG is ON.
The read value is reflected to the response area of the remote register.

Remote register of the NETC01-M2

Byte	Part	Type	Response	Output example	Description
23	Data field	Remote register	Register address number response	0	Address number 0
24					
25			Command code response + TRIG response + STATUS	6067h	Monitoring of the feedback speed
26					
27					
28			DATA response	003Ch	Read value (example: 60 r/min)
29					
30					

- To finish monitoring, send the following remote register and turn TRIG OFF again.

Remote register of the NETC01-M2

Byte	Part	Type	Command	Input example	Description
25	Data field	Remote register	Command code + TRIG	0	Turn TRIG OFF
26					

memo In MECHATROLINK-II communication, only one type of data can be monitored for one driver because of the performance of the network converter. To monitor drivers with multiple axes, change the address number before executing monitoring.

4-3 Field map of the NETC01-M2

Update (asynchronous) of the remote I/O data is performed with the "DATA_RWA" command (50h).
When the remote I/O occupancy size is 16 bit mode and the number of transmission bytes is 32 bytes (factory setting), the I/O field map is as follows. For other I/O field maps, refer to the **NETC01-M2 USER MANUAL**.

Byte	Part	Type	Command	Response	
1	Header field	–	DATA_RWA (50h)	DATA_RWA (50h)	
2		–	OPTION	ALARM	
3		–		STATUS	
4		–			
5	Data field	–	Reserved	Connection status	
6		–			
7		Remote I/O		Address number "0" remote I/O input	Address number "0" remote I/O output
8				Address number "1" remote I/O input	Address number "1" remote I/O output
9				Address number "2" remote I/O input	Address number "2" remote I/O output
10				Address number "3" remote I/O input	Address number "3" remote I/O output
11				Address number "4" remote I/O input	Address number "4" remote I/O output
12				Address number "5" remote I/O input	Address number "5" remote I/O output
13				Address number "6" remote I/O input	Address number "6" remote I/O output
14				Address number "7" remote I/O input	Address number "7" remote I/O output
15				Address number "8" remote I/O input	Address number "8" remote I/O output
16				Address number "9" remote I/O input	Address number "9" remote I/O output
17				Address number "10" remote I/O input	Address number "10" remote I/O output
18				Address number "11" remote I/O input	Address number "11" remote I/O output
19				Address number "12" remote I/O input	Address number "12" remote I/O output
20				Address number "13" remote I/O input	Address number "13" remote I/O output
21			Address number "14" remote I/O input	Address number "14" remote I/O output	
22			Address number "15" remote I/O input	Address number "15" remote I/O output	
23		Remote register		Register address number	Register address number response
24				Command code + TRIG	Command code response + TRIG response + STATUS
25				DATA	DATA response
26					
27					
28					
29					
30					
31			–	Reserved	Reserved

4-4 Field map of the NETC01-M3

Update (asynchronous) of the remote I/O data is performed with the "DATA_RWA" command (20h). When the remote I/O occupancy size is 16 bit mode and the number of transmission bytes is 32 bytes (factory setting), the I/O field map is as follows. For other I/O field maps, refer to the **NETC01-M3 USER MANUAL**.

Byte	Type	Command	Response
0	–	DATA_RWA (20h)	DATA_RWA (20h)
1	–	WDT	RWDT
2	–	CMD_CTRL	CMD_STAT
3	–		
4	–	Reserved	Connection status
5	–		
6	Remote I/O		
7			
8		Address number "1" remote I/O input	Address number "1" remote I/O output
9			
10		Address number "2" remote I/O input	Address number "2" remote I/O output
11			
12		Address number "3" remote I/O input	Address number "3" remote I/O output
13			
14		Address number "4" remote I/O input	Address number "4" remote I/O output
15			
16		Address number "5" remote I/O input	Address number "5" remote I/O output
17			
18		Address number "6" remote I/O input	Address number "6" remote I/O output
19			
20		Address number "7" remote I/O input	Address number "7" remote I/O output
21			
22	Remote register	Register address number	Register address number response
23			
24		Command code + TRIG	Command code response + TRIG response + STATUS
25			
26			
27		DATA	DATA response
28			
29			
30	–	Reserved	Reserved
31	–		

4-5 Communication formats

The following are communication formats between the driver and **NETC01-M2 (NETC01-M3)**.

■ Remote I/O input

Details of remote I/O ⇨ p.302

● In case of 8 axes connection mode [16 bit mode]

[]: Initial value

Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
NET-IN15 [RVS]	NET-IN14 [FWD]	NET-IN13 [-JOG]	NET-IN12 [+JOG]	NET-IN11 [SSTART]	NET-IN10 [MS2]	NET-IN9 [MS1]	NET-IN8 [MS0]
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NET-IN7 [Not used]	NET-IN6 [FREE]	NET-IN5 [STOP]	NET-IN4 [HOME]	NET-IN3 [START]	NET-IN2 [M2]	NET-IN1 [M1]	NET-IN0 [M0]

● In case of 16 axes connection mode [8 bit mode]

[]: Initial value

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NET-IN7 [Not used]	NET-IN6 [FREE]	NET-IN5 [STOP]	NET-IN4 [HOME]	NET-IN3 [START]	NET-IN2 [M2]	NET-IN1 [M1]	NET-IN0 [M0]

■ Remote I/O output

Details of remote I/O ⇨ p.302

● In case of 8 axes connection mode [16 bit mode]

[]: Initial value

Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
NET-OUT15 [TLC]	NET-OUT14 [END]	NET-OUT13 [MOVE]	NET-OUT12 [TIM]	NET-OUT11 [AREA3]	NET-OUT10 [AREA2]	NET-OUT9 [AREA1]	NET-OUT8 [S-BSY]
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NET-OUT7 [ALM]	NET-OUT6 [WNG]	NET-OUT5 [READY]	NET-OUT4 [HOME-P]	NET-OUT3 [START_R]	NET-OUT2 [M2_R]	NET-OUT1 [M1_R]	NET-OUT0 [M0_R]


● In case of 16 axes connection mode [8 bit mode]

[]: Initial value

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NET-OUT7 [ALM]	NET-OUT6 [WNG]	NET-OUT5 [READY]	NET-OUT4 [HOME-P]	NET-OUT3 [START_R]	NET-OUT2 [M2_R]	NET-OUT1 [M1_R]	NET-OUT0 [M0_R]

■ Remote register input

● Command [NETC01-M2 (NETC01-M3) to driver]




● Description

Name	Description	Setting range
TRIG	This is a handshake trigger to execute a command code. When TRIG is changed from 0 to 1, the command code and DATA are executed.	0: No action 1: Execute
Command code	Specifies the command codes of reading and writing of parameters, monitoring, and maintenance.	–
DATA	This is the data writing to the driver (little endian).	–

■ Remote register output

● Response [Driver to NETC01-M2 (NETC01-M3)]



● Description

Name	Description	Setting range
STATUS	Indicates the result of execution of the command code.	0: Normal 1: Abnormal
TRIG_R	This is a handshake trigger to indicate completion of execution of the command code. When execution of the command code is complete, TRIG_R changes from 0 to 1.	0: Not processed 1: Execution completed
Command code	The response returns the command code of the command.	–
DATA_R	This is the data reading from the driver (little endian).	–

5 Details of remote I/O

Remote I/Os are common to all network converters.

5-1 Input signals to the driver

The input signals shown below can be assigned to the NET-IN0 to NET-IN15 of the remote I/O using the parameters. Refer to the following table for the assignments of the NET-IN0 to NET-IN15. The value in [] is the initial value. For details on parameter, refer to “6-5 User parameters” on p.310.

Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
NET-IN15 [RVS]	NET-IN14 [FWD]	NET-IN13 [-JOG]	NET-IN12 [+JOG]	NET-IN11 [SSTART]	NET-IN10 [MS2]	NET-IN9 [MS1]	NET-IN8 [MS0]
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NET-IN7 [No function]	NET-IN6 [FREE]	NET-IN5 [STOP]	NET-IN4 [HOME]	NET-IN3 [START]	NET-IN2 [M2]	NET-IN1 [M1]	NET-IN0 [M0]

Signal name	Function	Setting range
No function	Set when the input terminal is not used.	–
FWD	Execute continuous operation in the positive direction.	0: Deceleration stop
RVS	Execute continuous operation in the negative direction.	1: Operation
HOME	Execute return-to-home operation.	0: No operation 1: Start operation
START	Execute positioning operation.	
SSTART	Execute sequential positioning operation.	
+JOG	Execute JOG operation in the positive direction.	
-JOG	Execute JOG operation in the negative direction.	
MS0 to MS5	Execute direct positioning operation of the operation data No. set by the I/O parameter.	
FREE	Stop the motor excitation and release the electromagnetic brake.	0: No operation 1: Motor non-excitation, electromagnetic brake release
C-ON	Switch the motor excitation between excitation and non-excitation.	0: Motor non-excitation 1: Motor excitation
STOP	Stop of the motor operation.	0: No operation 1: Stop operation
ALM-RST	Reset the current alarm.	0: No operation 1: Reset alarm
P-PRESET	Execute position preset.	0: No operation 1: Execute preset
P-CLR	This cannot be used.	–
HMI	Release of the function limitation of the MEXE02 or OPX-2A .	0: Function limitation 1: Function limitation release
R0 to R15	General signals. Use these signals when controlling the system via RS-485 communication.	0: OFF 1: ON
M0 to M5	Selects the operation data No. using these six bits. Refer p.93 for details on the combination.	0: OFF 1: ON (Operation data Nos.0 to 63 can be selected.)



- Do not assign the same input signal to multiple input terminals. When the same input signal is assigned to multiple input terminals, the function will be executed if any of the terminals becomes active.
- This function is executed when the ALM-RST input is turned from ON (1) to OFF (0).
This function is executed when the P-PRESET input is turned from OFF (0) to ON (1).
- When the C-ON input and HMI input are not assigned to the input terminals, these inputs will always be set to ON (1). When assigning to both direct I/O and remote I/O, the function will be executed when both of them are set to ON (1).

5-2 Output signals from the driver

The output signals shown below can be assigned to the NET-OUT0 to NET-OUT15 of the remote I/O using the parameters.
Refer to the following table for the assignments of the NET-OUT0 to NET-OUT15. The value in [] is the initial value.
For details on parameter, refer to “6-5 User parameters” on p.310.

Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8
NET-OUT15 [TLC]	NET-OUT14 [END]	NET-OUT13 [MOVE]	NET-OUT12 [TIM]	NET-OUT11 [AREA3]	NET-OUT10 [AREA2]	NET-OUT9 [AREA1]	NET-OUT8 [S-BSY]
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
NET-OUT7 [ALM]	NET-OUT6 [WNG]	NET-OUT5 [READY]	NET-OUT4 [HOME-P]	NET-OUT3 [START_R]	NET-OUT2 [M2_R]	NET-OUT1 [M1_R]	NET-OUT0 [M0_R]

Signal name	Function	Data read
No function	Set when the output terminal is not used.	–
FWD_R	Output in response to the FWD input.	0: OFF 1: ON
RVS_R	Output in response to the RVS input.	
HOME_R	Output in response to the HOME input.	
START_R	Output in response to the START input.	
SSTART_R	Output in response to the SSTART input.	
+JOG_R	Output in response to the +JOG input.	
–JOG_R	Output in response to the –JOG input.	
MS0_R to MS5_R	Output in response to the MS0 to MS5 input.	
FREE_R	Output in response to the FREE input.	
C-ON_R	Output in response to the C-ON input.	
STOP_R	Output in response to the STOP input.	
R0 to R15	Output the status of the general signal R0 to R15.	
M0_R to M5_R	Output in response to the M0 to M5 input.	
+LS_R	Output in response to the +LS input.	
–LS_R	Output in response to the –LS input.	
HOMES_R	Output in response to the HOMES input.	
SLIT_R	Output in response to the SLIT input.	
ALM	Output the alarm status of the driver (normally open).	0: Alarm not present 1: Alarm present
WNG	Output the warning status of the driver.	0: Warning not present 1: Warning present
READY	Output when the driver is ready.	0: Not ready 1: Ready
MOVE	Output while the motor operates.	0: Motor stopped 1: Motor operating
END	Output when the positioning operation is completed.	0: Motor operating 1: Motor operating completion

Signal name	Function	Data read
HOME-P	Output when the motor is in home.	0: Not home 1: Home
TLC	Output when the load is outside of the motor torque range.	0: Inside torque range 1: Outside torque range
TIM	Output once every 7.2° rotation of the motor output shaft.	0: OFF 1: ON
AREA1 to AREA3	Output when the motor is within the area.	0: Outside area 1: Inside area
S-BSY	Output when the driver is in internal processing state.	0: OFF 1: ON
MPS *	Output while the driver main power is on.	0: OFF 1: ON

* AC power input only

6 Command code list

Command codes are common to all network converters.

6-1 Group function

The driver has a group function. Multiple devices are made into a group and a operation command is sent to all devices in the group at once.

■ Group composition

A group consists of one parent device and child devices.

■ Group address

To perform a group send, set a group address to the child devices to be included in the group. The child devices to which the group address has been set can receive a command sent to the parent device. The operation command will be sent to the child devices in the same group by sending it to the parent device.

● Parent device

No special setting is required on the parent device to perform a group send. The address of the parent device becomes the group address.

● Child device

Use a "Group (1018h)" to set a group address to each child device.

memo Only remote I/O input can execute the group function. Read from commands and parameters or write to commands and parameters cannot be executed.

■ Group setting


The group setting is not saved in the non-volatile memory even when the maintenance command "Batch non-volatile memory write" executes.

Command code		Name	Description	Initial value
Read	Write			
24 (0018h)	4120 (1018h)	Group	Sets the group address. [Setting range] -1: Individual (No group setting) 0 to 15: Group address (Address number of parent device) *	-1


* Set in the 0 to 11 range when using the **NETC01-CC**, and set in the 0 to 15 range when using other network converter.

■ Example for setting of the group function

Set as follows when making a group by setting the driver of address number 0 to the parent device and by setting the driver of address number 1 and 2 to the child devices.



This is a timing chart for when assigning the START to NET-IN3 (remote I/O) of the driver in the group.



memo When inputting a remote I/O to the parent device, the motors of the parent device and child devices will operate. The motors will not operate if the remote I/O is input to the child devices.

6-2 Maintenance command

These commands are used to clear the alarm records and warning records. They are also used to execute the batch processing for the non-volatile memory.

Command code	Name	Description	Setting range
12480 (30C0h)	Reset alarm	Resets the alarms that are present. Some alarms cannot be reset with the "reset alarm."	1: Execute
12482 (30C2h)	Clear alarm records	Clears alarm records.	
12483 (30C3h)	Clear warning records	Clears warning records.	
12484 (30C4h)	Clear communication error records	Clears communication error records.	
12485 (30C5h)	P-PRESET execute	Updates the command position to the value of the "Preset position" parameter.	
12486 (30C6h)	Configuration	Executes the parameter recalculation and the setup.	
12487 (30C7h)	All data initialization	Resets the operation data and parameters saved in the non-volatile memory to the initial value. Note that "Communication parity", "Communication stop bit", and "Transmission waiting time" parameters are not initialized.	
12488 (30C8h)	Batch non-volatile memory read	Reads the operation data and parameters saved in the non-volatile memory, to the RAM. All operation data and parameters previously saved in the RAM are overwritten.	
12489 (30C9h)	Batch non-volatile memory write	Writes the operation data and parameters saved in the RAM to the non-volatile memory.	

memo The non-volatile memory can be rewritten approximately 100,000 times.

6-3 Monitor command

These commands are used to monitor the driver condition.

Command code	Name	Description
8256 (2040h)	Present alarm	Monitors the present alarm code.
8257 (2041h)	Alarm record 1	Monitors the alarm records 1 to 10.
8258 (2042h)	Alarm record 2	
8259 (2043h)	Alarm record 3	
8260 (2044h)	Alarm record 4	
8261 (2045h)	Alarm record 5	
8262 (2046h)	Alarm record 6	
8263 (2047h)	Alarm record 7	
8264 (2048h)	Alarm record 8	
8265 (2049h)	Alarm record 9	
8266 (204Ah)	Alarm record 10	
8267 (204Bh)	Present warning	Monitors the present warning code.
8268 (204Ch)	Warning record 1	Monitors the warning records 1 to 10.
8269 (204Dh)	Warning record 2	
8270 (204Eh)	Warning record 3	
8271 (204Fh)	Warning record 4	
8272 (2050h)	Warning record 5	
8273 (2051h)	Warning record 6	
8274 (2052h)	Warning record 7	
8275 (2053h)	Warning record 8	
8276 (2054h)	Warning record 9	
8277 (2055h)	Warning record 10	
8279 (2057h)	Communication error code record 1	Monitors the communication error records 1 to 3 that have occurred in the past.
8280 (2058h)	Communication error code record 2	
8281 (2059h)	Communication error code record 3	

Command code	Name	Description
8282 (205Ah)	Communication error code record 4	Monitors the communication error records 4 to 10 that have occurred in the past.
8283 (205Bh)	Communication error code record 5	
8284 (205Ch)	Communication error code record 6	
8285 (205Dh)	Communication error code record 7	
8286 (205Eh)	Communication error code record 8	
8287 (205Fh)	Communication error code record 9	
8288 (2060h)	Communication error code record 10	
8289 (2061h)	Present selected data No.	Monitors the operation data No. currently selected.
8290 (2062h)	Present operation data No.	Monitors the operation data No. corresponding to the data used in the current positioning operation. This address is used in linked-motion operation and sequential positioning operation. While the motor is stopped, the last used operation data number is indicated.
8291 (2063h)	Command position	Monitors the command position.
8292 (2064h)	Command speed	Monitors the current command speed. (r/min)
8294 (2066h)	Actual position	Monitors the actual position.
8295 (2067h)	Actual speed	Monitors the actual speed. (r/min)
8297 (2069h)	Remaining dwell time	Monitors how much of the dwell time used in the linked-motion 2 operation remains.
8298 (206Ah)	Direct I/O and electromagnetic brake status	Monitors the each direct I/O signal and electromagnetic brake status. Refer to the following table for the assignments.

■ Direct I/O and electromagnetic brake status [8298 (206Ah)]

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	IN1	IN0	–	–	SLIT	HOMES	–LS	+LS
1	–	–	IN7	IN6	IN5	IN4	IN3	IN2
2	–	–	OUT5	OUT4	OUT3	OUT2	OUT1	OUT0
3	–	–	–	–	–	–	–	MB

6-4 Operation data

Up to 64 operation data can be set (data Nos.0 to 63).

When the operation data is changed, a recalculation and setup will be performed after the operation is stopped and the changed value will be update.

Command code		Name	Setting range	Initial value
Read	Write			
512 (0200h) to 575 (023Fh)	4608 (1200h) to 4671 (123Fh)	Position No.0 to Position No.63	-8,388,608 to 8,388,607 step	0
576 (0240h) to 639 (027Fh)	4672 (1240h) to 4735 (127Fh)	Operating speed No.0 to Operating speed No.63	0 to 1,000,000 Hz	1,000
640 (0280h) to 703 (02BFh)	4736 (1280h) to 4799 (12BFh)	Operation mode No.0 to Operation mode No.63	0: Incremental 1: Absolute	0
704 (02C0h) to 767 (02FFh)	4800 (12C0h) to 4863 (12FFh)	Operation function No.0 to Operation function No.63	0: Single-motion 1: Linked-motion 2: Linked-motion 2 3: Push	0
768 (0300h) to 831 (033Fh)	4864 (1300h) to 4927 (133Fh)	Acceleration No.0 to Acceleration No.63	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *1 *2	1,000
832 (0340h) to 895 (037Fh)	4928 (1340h) to 4991 (137Fh)	Deceleration No.0 to Deceleration No.63	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *1 *2	1,000
896 (0380h) to 959 (03BFh)	4992 (1380h) to 5055 (13BFh)	Push current No.0 to Push current No.63	0 to 1,000 (1=0.1 %)	200
960 (03C0h) to 1023 (03FFh)	5056 (13C0h) to 5119 (13FFh)	Sequential positioning No.0 to Sequential positioning No.63	0: Disable 1: Enable	0
1024 (0400h) to 1087 (043Fh)	5120 (1400h) to 5183 (143Fh)	Dwell time No.0 to Dwell time No.63	0 to 50,000 (1=0.001 s)	0

*1 This item is effective when the "Acceleration/deceleration type" parameter is set to "Separate." If this parameter is set to "Common", the values of the "Common acceleration" and "Common deceleration" parameters will be used (initial value: separate).

*2 Acceleration/deceleration rate (ms/kHz) or acceleration/deceleration time (s) can be selected using "Acceleration/deceleration unit" parameter. (initial value: acceleration/deceleration rate).

6-5 User parameters

■ Timing for parameter to update

The parameters are saved in the RAM or non-volatile memory. The data saved in the RAM will be erased once the DC power is turned off. On the other hand, the parameters saved in the non-volatile memory will be retained even after the DC power supply is turned off.

When turning the driver DC power ON, the parameters saved in the non-volatile memory will be sent to the RAM. Then, the recalculation and setup for the parameters are executed in the RAM.

The parameters are written in the RAM area when setting via industrial network. To save the parameters written in the RAM to non-volatile memory, execute the "Batch non-volatile memory write" of the maintenance command. The parameters set with the **MEXE02** will be saved in the non-volatile memory if "data writing" is performed.

When a parameter is changed, the timing for updating the new value varies depending on the parameter. See the following three types.

In this manual, each update timing is represented in an alphabet.

Notation	Update timing
A	Recalculation and setup are immediately executed when the parameter is written.
B	Recalculation and setup are executed when the operation is stopped.
C	Recalculation and setup are executed after Configuration is executed or the DC power supply is turned on again.



- The parameters are written in the RAM area when setting via industrial network. If parameters, which are required turning on the power again in order to update, are changed, be sure to save them in the non-volatile memory before turning off the power.
- The non-volatile memory can be rewritten approximately 100,000 times.

■ I/O parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
256 (0100h)	4352 (1100h)	STOP input action	0: Immediate stop 1: Deceleration stop 2: Immediate stop & Current OFF 3: Deceleration stop & Current OFF	1	A
257 (0101h)	4353 (1101h)	Hardware overtravel	0: Disable 1: Enable	1	A
258 (0102h)	4354 (1102h)	Overtravel action	0: Immediate stop 1: Deceleration stop	0	A
259 (0103h)	4355 (1103h)	END signal range	0 to 180 (1=0.1°)	18	A
260 (0104h)	4356 (1104h)	Position complete output offset	-18 to 18 (1=0.1°)	0	A
261 (0105h)	4357 (1105h)	AREA1 positive direction position	-8,388,608 to 8,388,607 step	0	A
262 (0106h)	4358 (1106h)	AREA1 negative direction position			
263 (0107h)	4359 (1107h)	AREA2 positive direction position			
264 (0108h)	4360 (1108h)	AREA2 negative direction position			
265 (0109h)	4361 (1109h)	AREA3 positive direction position	-8,388,608 to 8,388,607 step	0	A
266 (010Ah)	4362 (110Ah)	AREA3 negative direction position			

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
267 (010Bh)	4363 (110Bh)	Minimum ON time for MOVE output	0 to 255 ms	0	A
268 (010Ch)	4364 (110Ch)	LS contact configuration	0: Make (N.O.) 1: Brake (N.C.)	0	C
269 (010Dh)	4365 (110Dh)	HOMES logic level			C
270 (010Eh)	4366 (110Eh)	SLIT logic level			C
2048 (0800h)	6144 (1800h)	MS0 operation No. selection	0 to 63	0	B
2049 (0801h)	6145 (1801h)	MS1 operation No. selection		1	
2050 (0802h)	6146 (1802h)	MS2 operation No. selection		2	
2051 (0803h)	6147 (1803h)	MS3 operation No. selection		3	
2052 (0804h)	6148 (1804h)	MS4 operation No. selection		4	
2053 (0805h)	6149 (1805h)	MS5 operation No. selection		5	
2054 (0806h)	6150 (1806h)	HOME-P output function selection	0: Home output 1: Return-to-home complete output	0	A

■ Motor parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
288 (0120h)	4384 (1120h)	RUN current	0 to 1,000 (1=0.1 %)	1,000	A
289 (0121h)	4385 (1121h)	STOP current	0 to 500 (1=0.1 %)	500	A
290 (0122h)	4386 (1122h)	Position loop gain	1 to 50	10	A
291 (0123h)	4387 (1123h)	Speed loop gain	10 to 200	180	A
292 (0124h)	4388 (1124h)	Speed loop integral time constant	100 to 2,000 (1=0.1 ms)	1,000	A
293 (0125h)	4389 (1125h)	Speed filter	0 to 200 ms	1	B
294 (0126h)	4390 (1126h)	Moving average time	1 to 200 ms	1	B
2064 (0810h)	6160 (1810h)	Filter selection	0: Speed filter 1: Moving average filter	0	C
2065 (0811h)	6161 (1811h)	Speed difference gain 1	0 to 500	45	A
2066 (0812h)	6162 (1812h)	Speed difference gain 2	0 to 500	45	A
2067 (0813h)	6163 (1813h)	Control mode	0: Normal mode 1: Current control mode	0	C
2068 (0814h)	6164 (1814h)	Smooth drive	0: Disable 1: Enable	1	C

■ Operation parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
320 (0140h)	4416 (1140h)	Common acceleration	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
321 (0141h)	4417 (1141h)	Common deceleration	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
322 (0142h)	4418 (1142h)	Starting speed	0 to 1,000,000 Hz	500	B
323 (0143h)	4419 (1143h)	JOG operating speed	1 to 1,000,000 Hz	1,000	B
324 (0144h)	4420 (1144h)	Acceleration/deceleration rate of JOG	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
325 (0145h)	4421 (1145h)	JOG starting speed	0 to 1,000,000 Hz	500	B
326 (0146h)	4422 (1146h)	Acceleration/deceleration type	0: Common 1: Separate	1	B
327 (0147h)	4423 (1147h)	Acceleration/deceleration unit	0: ms/kHz 1: s	0	C
2080 (0820h)	6176 (1820h)	Automatic return operation	0: Disable 1: Enable	0	C
2081 (0821h)	6177 (1821h)	Operation speed of automatic return	1 to 1,000,000 Hz	1,000	B
2082 (0822h)	6178 (1822h)	Acceleration (deceleration) of automatic return	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
2083 (0823h)	6179 (1823h)	Starting speed of automatic return	0 to 1,000,000 Hz	500	B
2084 (0824h)	6180 (1824h)	JOG travel amount	1 to 8,388,607 step	1	B

* Acceleration/deceleration rate (ms/kHz) or acceleration/deceleration time (s) can be selected using "Acceleration/deceleration unit" parameter. (initial value: acceleration/deceleration rate).

■ Home operation parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
352 (0160h)	4448 (1160h)	Home-seeking mode	0: 2-sensor mode 1: 3-sensor mode 2: Push mode	1	B
353 (0161h)	4449 (1161h)	Operating speed of home-seeking	1 to 1,000,000 Hz	1,000	B
354 (0162h)	4450 (1162h)	Acceleration/deceleration of home-seeking	1 to 1,000,000 (1=0.001 ms/kHz or 1=0.001 s) *	1,000	B
355 (0163h)	4451 (1163h)	Starting speed of home-seeking	1 to 1,000,000 Hz	500	B
356 (0164h)	4452 (1164h)	Position offset of home-seeking	-8,388,608 to 8,388,607 step	0	B
357 (0165h)	4453 (1165h)	Starting direction of home-seeking	0: Negative direction 1: Positive direction	1	B
358 (0166h)	4454 (1166h)	SLIT detection with home-seeking	0: Disable 1: Enable	0	B
359 (0167h)	4455 (1167h)	TIM signal detection with home-seeking	0: Disable 1: Enable	0	B
360 (0168h)	4456 (1168h)	Operating current of home-seeking with push-motion	0 to 1,000 (1=0.1 %)	1,000	B

* Acceleration/deceleration rate (ms/kHz) or acceleration/deceleration time (s) can be selected using "Acceleration/deceleration unit" parameter. (initial value: acceleration/deceleration rate).

■ Alarm parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
384 (0180h)	4480 (1180h)	Overload alarm	1 to 300 (1=0.1 s)	50	A
385 (0181h)	4481 (1181h)	Excessive position deviation alarm at current ON	1 to 30,000 (1=0.01 rev)	300	A
388 (0184h)	4484 (1184h)	Return-to-home incomplete alarm	0: Disable 1: Enable	0	C
2112 (0840h)	6208 (1840h)	Excessive position deviation alarm at current OFF	1 to 30,000 (1=0.01 rev)	10,000	A

■ Warning parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
416 (01A0h)	4512 (11A0h)	Overheat warning	40 to 85 °C	85	A
417 (01A1h)	4513 (11A1h)	Overload warning	1 to 300 (1=0.1 s)	50	A
418 (01A2h)	4514 (11A2h)	Overspeed warning	1 to 5,000 r/min	4,500	A
419 (01A3h)	4515 (11A3h)	Overvoltage warning	<ul style="list-style-type: none"> • AC power input: 120 to 450 V • DC power input: 150 to 630 (1=0.1 V) 	AC power input: 435 DC power input: 630	A
420 (01A4h)	4516 (11A4h)	Undervoltage warning	<ul style="list-style-type: none"> • AC power input: 120 to 280 V • DC power input: 150 to 630 (1=0.1 V) 	AC power input: 120 DC power input: 180	A
421 (01A5h)	4517 (11A5h)	Excessive position deviation warning at current ON	1 to 30,000 (1=0.01 rev)	300	A

■ Coordinates parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
448 (01C0h)	4544 (11C0h)	Electronic gear A	1 to 65,535	1	C
449 (01C1h)	4545 (11C1h)	Electronic gear B	1 to 65,535	1	C
450 (01C2h)	4546 (11C2h)	Motor rotation direction	0: Positive direction=CCW 1: Positive direction=CW	1	C
451 (01C3h)	4547 (11C3h)	Software overtravel	0: Disable 1: Enable	1	A
452 (01C4h)	4548 (11C4h)	Positive software limit	-8,388,608 to 8,388,607 step	8,388,607	A
453 (01C5h)	4549 (11C5h)	Negative software limit	-8,388,608 to 8,388,607 step	-8,388,608	A
454 (01C6h)	4550 (11C6h)	Preset position	-8,388,608 to 8,388,607 step	0	A
455 (01C7h)	4551 (11C7h)	Wrap setting	0: Disable 1: Enable	0	C
456 (01C8h)	4552 (11C8h)	Wrap setting range	1 to 8,388,607 step	1,000	C

■ Common parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
480 (01E0h)	4576 (11E0h)	Data setter speed display	0: Signed 1: Absolute value	0	A
481 (01E1h)	4577 (11E1h)	Data setter edit	0: Disable 1: Enable	1	A

■ I/O function [Input] parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
2176 (0880h)	6272 (1880h)	IN0 input function selection	Refer to the following table.	3: HOME	C
2177 (0881h)	6273 (1881h)	IN1 input function selection		4: START	
2178 (0882h)	6274 (1882h)	IN2 input function selection		48: M0	
2179 (0883h)	6275 (1883h)	IN3 input function selection		49: M1	
2180 (0884h)	6276 (1884h)	IN4 input function selection		50: M2	
2181 (0885h)	6277 (1885h)	IN5 input function selection		16: FREE	
2182 (0886h)	6278 (1886h)	IN6 input function selection		18: STOP	
2183 (0887h)	6279 (1887h)	IN7 input function selection		24: ALM-RST	
2192 (0890h)	6288 (1890h)	IN0 input logic level setting	0: Make (N.O) 1: Brake (N.C.)	0	C
2193 (0891h)	6289 (1891h)	IN1 input logic level setting			
2194 (0892h)	6290 (1892h)	IN2 input logic level setting			
2195 (0893h)	6291 (1893h)	IN3 input logic level setting			
2196 (0894h)	6292 (1894h)	IN4 input logic level setting			
2197 (0895h)	6293 (1895h)	IN5 input logic level setting			
2198 (0896h)	6294 (1896h)	IN6 input logic level setting			
2199 (0897h)	6295 (1897h)	IN7 input logic level setting			

Setting range for IN input function selection

0: No function	8: MS0	18: STOP	35: R3	43: R11	51: M3
1: FWD	9: MS1	24: ALM-RST	36: R4	44: R12	52: M4
2: RVS	10: MS2	25: P-PRESET	37: R5	45: R13	53: M5
3: HOME	11: MS3	26: P-CLR*	38: R6	46: R14	
4: START	12: MS4	27: HMI	39: R7	47: R15	
5: SSTART	13: MS5	32: R0	40: R8	48: M0	
6: +JOG	16: FREE	33: R1	41: R9	49: M1	
7: -JOG	17: C-ON	34: R2	42: R10	50: M2	

* It cannot be used.

■ I/O function [Output] parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
2208 (08A0h)	6304 (18A0h)	OUT0 output function selection	Refer to the following table.	70: HOME-P	C
2209 (08A1h)	6305 (18A1h)	OUT1 output function selection		69: END	
2210 (08A2h)	6306 (18A2h)	OUT2 output function selection		73: AREA1	
2211 (08A3h)	6307 (18A3h)	OUT3 output function selection		67: READY	
2212 (08A4h)	6308 (18A4h)	OUT4 output function selection		66: WNG	
2213 (08A5h)	6309 (18A5h)	OUT5 output function selection		65: ALM	

Setting range for OUT output function selection

0: No function	10: MS2_R	35: R3	45: R13	61: -LS_R	72: TIM
1: FWD_R	11: MS3_R	36: R4	46: R14	62: HOMES_R	73: AREA1
2: RVS_R	12: MS4_R	37: R5	47: R15	63: SLIT_R	74: AREA2
3: HOME_R	13: MS5_R	38: R6	48: M0_R	65: ALM	75: AREA3
4: START_R	16: FREE_R	39: R7	49: M1_R	66: WNG	80: S-BSY
5: SSTART_R	17: C-ON_R	40: R8	50: M2_R	67: READY	82: MPS *
6: +JOG_R	18: STOP_R	41: R9	51: M3_R	68: MOVE	
7: -JOG_R	32: R0	42: R10	52: M4_R	69: END	
8: MS0_R	33: R1	43: R11	53: M5_R	70: HOME-P	
9: MS1_R	34: R2	44: R12	60: +LS_R	71: TLC	

* AC power input only.

■ I/O function [RS-485] parameter

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
2224 (08B0h)	6320 (18B0h)	NET-IN0 input function selection	Refer to "Setting range for NET-IN input function selection" on p.317.	48: M0	C
2225 (08B1h)	6321 (18B1h)	NET-IN1 input function selection		49: M1	
2226 (08B2h)	6322 (18B2h)	NET-IN2 input function selection		50: M2	
2227 (08B3h)	6323 (18B3h)	NET-IN3 input function selection		4: START	
2228 (08B4h)	6324 (18B4h)	NET-IN4 input function selection		3: HOME	
2229 (08B5h)	6325 (18B5h)	NET-IN5 input function selection		18: STOP	
2230 (08B6h)	6326 (18B6h)	NET-IN6 input function selection		16: FREE	
2231 (08B7h)	6327 (18B7h)	NET-IN7 input function selection		0: No function	
2232 (08B8h)	6328 (18B8h)	NET-IN8 input function selection		8: MS0	
2233 (08B9h)	6329 (18B9h)	NET-IN9 input function selection		9: MS1	
2234 (08BAh)	6330 (18BAh)	NET-IN10 input function selection		10: MS2	

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
2235 (08BBh)	6331 (18BBh)	NET-IN11 input function selection	Refer to the following table.	5: SSTART	C
2236 (08BCh)	6332 (18BCh)	NET-IN12 input function selection		6: +JOG	
2237 (08BDh)	6333 (18BDh)	NET-IN13 input function selection		7: -JOG	
2238 (08BEh)	6334 (18BEh)	NET-IN14 input function selection		1: FWD	
2239 (08BFh)	6335 (18BFh)	NET-IN15 input function selection		2: RVS	
2240 (08C0h)	6336 (18C0h)	NET-OUT0 output function selection	Refer to "Setting range for NET-OUT output function selection" on p.318.	48: M0_R	C
2241 (08C1h)	6337 (18C1h)	NET-OUT1 output function selection		49: M1_R	
2242 (08C2h)	6338 (18C2h)	NET-OUT2 output function selection		50: M2_R	
2243 (08C3h)	6339 (18C3h)	NET-OUT3 output function selection		4: START_R	
2244 (08C4h)	6340 (18C4h)	NET-OUT4 output function selection		70: HOME-P	
2245 (08C5h)	6341 (18C5h)	NET-OUT5 output function selection		67: READY	
2246 (08C6h)	6342 (18C6h)	NET-OUT6 output function selection		66: WNG	
2247 (08C7h)	6343 (18C7h)	NET-OUT7 output function selection		65: ALM	
2248 (08C8h)	6344 (18C8h)	NET-OUT8 output function selection		80: S-BSY	
2249 (08C9h)	6345 (18C9h)	NET-OUT9 output function selection		73: AREA1	
2250 (08CAh)	6346 (18CAh)	NET-OUT10 output function selection		74: AREA2	
2251 (08CBh)	6347 (18CBh)	NET-OUT11 output function selection		75: AREA3	
2252 (08CCh)	6348 (18CCh)	NET-OUT12 output function selection		72: TIM	
2253 (08CDh)	6349 (18CDh)	NET-OUT13 output function selection		68: MOVE	
2254 (08CEh)	6350 (18CEh)	NET-OUT14 output function selection		69: END	
2255 (08CFh)	6351 (18CFh)	NET-OUT15 output function selection	71: TLC		

● Setting range for NET-IN input function selection

0: No function	8: MS0	18: STOP	35: R3	43: R11	51: M3
1: FWD	9: MS1	24: ALM-RST	36: R4	44: R12	52: M4
2: RVS	10: MS2	25: P-PRESET	37: R5	45: R13	53: M5
3: HOME	11: MS3	26: P-CLR *	38: R6	46: R14	
4: START	12: MS4	27: HMI	39: R7	47: R15	
5: SSTART	13: MS5	32: R0	40: R8	48: M0	
6: +JOG	16: FREE	33: R1	41: R9	49: M1	
7: -JOG	17: C-ON	34: R2	42: R10	50: M2	

* It cannot be used.

● **Setting range for NET-OUT output function selection**

0: No function	10: MS2_R	35: R3	45: R13	61: -LS_R	72: TIM
1: FWD_R	11: MS3_R	36: R4	46: R14	62: HOMES_R	73: AREA1
2: RVS_R	12: MS4_R	37: R5	47: R15	63: SLIT_R	74: AREA2
3: HOME_R	13: MS5_R	38: R6	48: M0_R	65: ALM	75: AREA3
4: START_R	16: FREE_R	39: R7	49: M1_R	66: WNG	80: S-BSY
5: SSTART_R	17: C-ON_R	40: R8	50: M2_R	67: READY	82: MPS *
6: +JOG_R	18: STOP_R	41: R9	51: M3_R	68: MOVE	
7: -JOG_R	32: R0	42: R10	52: M4_R	69: END	
8: MS0_R	33: R1	43: R11	53: M5_R	70: HOME-P	
9: MS1_R	34: R2	44: R12	60: +LS_R	71: TLC	

* AC power input only.

■ **Communication parameter**

Command code		Description	Setting range	Initial value	Update
READ	WRITE				
2304 (0900h)	6400 (1900h)	Communication timeout	0: Not monitored 1 to 10,000 ms	0	A
2305 (0901h)	6401 (1901h)	Communication error alarm	1 to 10 times	3	A

8 Appendix


◆ Table of contents

1	Timing charts.....	320
2	Specifications	331
3	General specifications	332
	3-1 AC power input	332
	3-2 DC power input	333
4	Regulations and standards.....	334
	4-1 UL Standards, CSA Standards	334
	4-2 CE Marking (AC power input type).....	334
	4-3 CE Marking (DC power input type)	335
	4-4 Republic of Korea, Radio Waves Act.....	335




1 Timing charts

■ Power supply input (AC power input)




* When the C-ON input is not assigned or when the C-ON input is assigned as normally closed.

■ Power supply input (DC power input)




* When the C-ON input is not assigned or when the C-ON input is assigned as normally closed.

■ **C-ON input**




■ **STOP input**

- When the "STOP input action" parameter is "Immediate stop."




* The specific time varies depending on the load, operating speed, speed filter and other.

- When the "STOP input action" parameter is "Deceleration stop."




* The specific time varies depending on the load, operating speed, speed filter and other.

■ **FREE input**




■ **ALM-RST input**

● **When an alarm generates and the motor maintains excitation**




* ALM output is normally closed. It is ON during normal operation and it turns OFF when an alarm generates.

● **When an alarm generates and the motor does not maintain excitation**




* ALM output is normally closed. It is ON during normal operation and it turns OFF when an alarm generates.


■ HMI input



■ P-PRESET input




■ Single-motion operation (Positioning operation)




* The specific time varies depending on the load, operating speed, speed filter and other.

■ Linked-motion operation (Positioning operation)



* The specific time varies depending on the load, operating speed, speed filter and other.

■ Linked-motion 2 operation (Positioning operation)




*1 The specific time varies depending on the load, operating speed, speed filter and other.

*2 This is the value of the dwell time to be set in operation data No.1.


■ **Push operation**

- When the positioning operation is completed before turning to the "push-motion" status




* The specific time varies depending on the load, operating speed, speed filter and other.

- When the positioning operation is started from the "push-motion" status




■ Direct positioning operation




* The specific time varies depending on the load, operating speed, speed filter and other.

■ Sequential positioning operation




* The specific time varies depending on the load, operating speed, speed filter and other.

■ Continuous operation




* The specific time varies depending on the load, operating speed, speed filter and other.

■ JOG operation




* The specific time varies depending on the load, operating speed, speed filter and other.

■ Return-to-home operation




■ **Automatic return operation**

● **When the automatic return operation is performed using the main power supply (AC power input)**




* The specific time varies depending on the load, operating speed, speed filter and other.

● **When the automatic return operation is performed using the C-ON input**




* The specific time varies depending on the load, operating speed, speed filter and other.

● Operation is terminated with the STOP input



* The specific time varies depending on the load, operating speed, speed filter and other.

● When the C-ON input is turned OFF while performing the automatic return operation



* The specific time varies depending on the load, operating speed, speed filter and other.

2 Specifications

Check on the Oriental Motor Website for the product specifications.

3 General specifications

3-1 AC power input

		Motor	Driver
Degree of protection		IP65 (Excluding the mounting surface and connectors.) IP20 (Double shaft type)	IP20
Operation environment	Ambient temperature	-10 to +50 °C (+14 to +122 °F) *1 (non-freezing) Harmonic geared type: 0 to +40 °C (+32 to +104 °F) *1 (non-freezing)	0 to +55 °C (+32 to +131 °F) *2 (non-freezing)
	Humidity	85 % or less (non-condensing)	
	Altitude	Up to 1,000 m (3,300 ft.) above sea level	
	Surrounding atmosphere	No corrosive gas, dust, water, or oil	
Storage environment	Ambient temperature	-20 to +60 °C (-4 to +140 °F) (non-freezing)	-25 to +70 °C (-13 to +158 °F) (non-freezing)
	Humidity	85 % or less (non-condensing)	
	Altitude	Up to 3,000 m (10,000 ft.) above sea level	
	Surrounding atmosphere	No corrosive gas, dust, water, or oil	
Shipping environment	Ambient temperature	-20 to +60 °C (-4 to +140 °F) (non-freezing)	-25 to +70 °C (-13 to +158 °F) (non-freezing)
	Humidity	85 % or less (non-condensing)	
	Altitude	Up to 3,000 m (10,000 ft.) above sea level	
	Surrounding atmosphere	No corrosive gas, dust, water, or oil	
Insulation resistance		100 MΩ or more when 500 VDC megger is applied between the following places: <ul style="list-style-type: none"> • Case - Motor and sensor windings • Case - Electromagnetic brake windings 	100 MΩ or more when 500 VDC megger is applied between the following places: <ul style="list-style-type: none"> • Protective Earth Terminals - Power supply terminals • Signal I/O terminals - Power supply terminals
Dielectric strength		Sufficient to withstand the following places for 1 minute. <ul style="list-style-type: none"> • Case - Motor and sensor windings 1.5 kVAC 50/60 Hz • Case - Electromagnetic brake windings 1.5 kVAC 50/60 Hz 	Sufficient to withstand the following for 1 minute. <ul style="list-style-type: none"> • Protective Earth Terminals - Power supply terminals 1.5 kVAC 50/60 Hz • Signal I/O terminals - Power supply terminals 1.8 kVAC 50/60 Hz

*1 When installing a motor to a heat sink of a capacity at least equivalent to an aluminum plate [250×250 mm (9.84×9.84 in.), thickness 6 mm (0.24 in.)].

*2 When installing a driver to a heat sink of a capacity at least equivalent to an aluminum plate [200×200 mm (7.87×7.87 in.), thickness 2 mm (0.08 in.)].

3-2 DC power input

		Motor	Driver
Degree of protection		IP65 (Excluding the mounting surface and connectors.) IP20 (Double shaft type, models that the "motor identification" in the product model name is "S")	IP20
Operation environment	Ambient temperature	–10 to +50 °C (+14 to +122 °F) *1 (non-freezing) Harmonic geared type: 0 to +40 °C (+32 to +104 °F) *1 (non-freezing)	0 to +50 °C (+32 to +122 °F) (non-freezing)
	Humidity	85 % or less (non-condensing)	
	Altitude	Up to 1,000 m (3,300 ft.) above sea level	
	Surrounding atmosphere	No corrosive gas, dust, water, or oil	
Storage environment	Ambient temperature	–20 to +60 °C (–4 to +140 °F) (non-freezing)	–25 to +70 °C (–13 to +158 °F) (non-freezing)
	Humidity	85 % or less (non-condensing)	
	Altitude	Up to 3,000 m (10,000 ft.) above sea level	
	Surrounding atmosphere	No corrosive gas, dust, water, or oil	
Shipping environment	Ambient temperature	–20 to +60 °C (–4 to +140 °F) (non-freezing)	–25 to +70 °C (–13 to +158 °F) (non-freezing)
	Humidity	85 % or less (non-condensing)	
	Altitude	Up to 3,000 m (10,000 ft.) above sea level	
	Surrounding atmosphere	No corrosive gas, dust, water, or oil	
Insulation resistance		100 MΩ or more when 500 VDC megger is applied between the following places: <ul style="list-style-type: none"> • Case - Motor and sensor windings • Case - Electromagnetic brake windings 	100 MΩ or more when 500 VDC megger is applied between the following places: <ul style="list-style-type: none"> • Frame Ground Terminal - Power supply terminals
Dielectric strength		Sufficient to withstand the following places for 1 minute: <ul style="list-style-type: none"> • Case - Motor and sensor windings 1.0 kVAC 50/60 Hz *2 • Case - Electromagnetic brake windings 1.0 kVAC 50/60 Hz *2 	Sufficient to withstand the following places for 1 minute: <ul style="list-style-type: none"> • Frame Ground Terminal - Power supply terminals 500 VAC 50/60 Hz

*1 When installing a motor to a heat sink of a capacity at least equivalent to an aluminum plate [100×100 mm (3.94×3.94 in.), thickness 6 mm (0.24 in.)].

*2 0.5 kVAC for the **ARM14**, **ARM15**, **ARM24**, and **ARM26**

4 Regulations and standards

4-1 UL Standards, CSA Standards

This product is recognized by UL under UL and CSA Standards.
 The driver is not provided with the electronic motor overload protection and the motor overtemperature protection specified in UL and CSA Standards.

4-2 CE Marking (AC power input type)

This product is affixed with the mark under the following directives.

■ Low Voltage Directive

Installation conditions


Item	Motor	Driver
Overvoltage category	II	II
Pollution degree	3 (2 for double shaft)	2
Degree of protection	IP65 (Excluding the mounting surface and connector part)	IP20
Protection against electric shock	Class I	Class I

- This product cannot be used in IT power distribution systems.
- Isolate the motor cable, the power supply cable and other drive cables from the signal cables by means of double insulation.
- The temperature of the driver's heat sink may exceed 90 °C (194 °F) depending on the driving condition. Observe the followings.
 - Be sure to perform test operation and check the driver temperature.
 - Do not use the driver near combustibles.
 - Do not touch the driver while operating.
- Use a circuit breaker conforming to EN or IEC Standards.
- The driver is not provided with the electronic motor overload protection and the motor overtemperature protection specified in EN Standards.
- The driver is not provided with the ground fault protection circuit. Wire the product in accordance with "Example of wiring to power supply considering ground fault protection." Also observe the followings.
 - Earth leakage breaker: Rated sensitivity current 30 mA
 - When connecting to a power supply of Overvoltage category III, use an insulation transformer to ground its secondary side (N for single-phase).
 - Fault loop impedance: Equal to or less than the value in table


Power supply specifications of driver	Fault loop impedance
Single-phase 100-120 VAC	500 Ω
Single-phase 200-240 VAC	1,000 Ω

● Example of wiring to power supply considering ground fault protection

- TN power distribution systems



- TT power distribution systems



■ EMC Directive

Refer to “4-9 Conformity to the EMC Directive” on p.44 for details about conformity.

■ RoHS Directive

This product does not contain the substances exceeding the restriction values.

4-3 CE Marking (DC power input type)

This product is affixed with the mark under the following directives.

■ EMC Directive

Refer to “4-8 Conformity to the EMC Directive” on p.75 for details about conformity.

■ RoHS Directive

This product does not contain the substances exceeding the restriction values.

4-4 Republic of Korea, Radio Waves Act

This product is affixed with the KC Mark under the Radio Waves Act, the Republic of Korea.

- Unauthorized reproduction or copying of all or part of this Manual is prohibited.
If a new copy is required to replace an original manual that has been damaged or lost, please contact your nearest Oriental Motor sales office.
- Oriental Motor shall not be liable whatsoever for any problems relating to industrial property rights arising from use of any information, circuit, equipment or device provided or referenced in this manual.
- Characteristics, specifications, and dimensions are subject to change without notice.
- While we make every effort to offer accurate information in the manual, we welcome your input. Should you find unclear descriptions, errors or omissions, please contact your nearest Oriental Motor sales office.
- **Orientalmotor**, **αSTEP**, and **FLEX** are registered trademarks or trademarks of Oriental Motor Co., Ltd., in Japan and other countries.

Modbus is a registered trademark of Schneider Automation Inc.

CC-Link is a registered trademark of the CC-Link Partner Association.

EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

MECHATROLINK is a registered trademark of the MECHATROLINK Members Association.

Other product names and company names mentioned in this manual may be registered trademarks or trademarks of their respective companies and are hereby acknowledged. The third-party products mentioned in this manual are recommended products, and references to their names shall not be construed as any form of performance guarantee. Oriental Motor is not liable whatsoever for the performance of these third-party products.

© Copyright ORIENTAL MOTOR CO., LTD. 2024

Published in March 2024

- Please contact your nearest Oriental Motor office for further information.

ORIENTAL MOTOR U.S.A. CORP.
Technical Support Tel:800-468-3982
8:30am EST to 5:00pm PST (M-F)

ORIENTAL MOTOR (EUROPA) GmbH
Schiesstraße 44, 40549 Düsseldorf, Germany
Technical Support Tel:00 800/22 55 66 22

ORIENTAL MOTOR (UK) LTD.
Unit 5 Faraday Office Park, Rankine Road,
Basingstoke, Hampshire RG24 8QB UK
Tel:+44-1256347090

ORIENTAL MOTOR (FRANCE) SARL
Tel:+33-1 47 86 97 50

ORIENTAL MOTOR ITALIA s.r.l.
Tel:+39-02-93906347

ORIENTAL MOTOR ASIA PACIFIC PTE. LTD.
Singapore
Tel:1800-842-0280

ORIENTAL MOTOR (MALAYSIA) SDN. BHD.
Tel:1800-806-161

ORIENTAL MOTOR (THAILAND) CO., LTD.
Tel:1800-888-881

ORIENTAL MOTOR (INDIA) PVT. LTD.
Tel:1800-120-1995 (For English)
1800-121-4149 (For Hindi)

TAIWAN ORIENTAL MOTOR CO., LTD.
Tel:0800-060708

SHANGHAI ORIENTAL MOTOR CO., LTD.
Tel:400-820-6516

INA ORIENTAL MOTOR CO., LTD.
Korea
Tel:080-777-2042

ORIENTAL MOTOR CO., LTD.
4-8-1 Higashiueno, Taito-ku, Tokyo
110-8536 Japan
Tel:+81-3-6744-0361
www.orientalmotor.co.jp/ja